

HOB COM

under MVS and OS/390

System Manual

November 2000

HOB electronic GmbH & Co. KG
Brandstätterstr. 2-10
D-90513 Zirndorf



(00 49) 911 / 96 66-290



(00 49) 911 / 96 66-299

E-Mail: support@hob.de

Inhalt

1. GENERAL REMARKS	8
1.1. OVERVIEW.....	8
1.2. THE HOB COM PROGRAMS.....	9
1.3. THE HOB COM DOCUMENTATION.....	9
1.4. CONVENTIONS	10
2. INSTALLATION GUIDE	12
2.1. STEPS FOR A FIRST INSTALLATION.....	12
2.2. LOADING THE MAGNETIC TAPE.....	13
2.3. DEFINITION OF THE PROGRAM HOB COM IN THE PROGRAM PROPERTY TABLE	15
2.4. STARTING HOB COM	16
3. DEFINING TERMINALS AND PRINTERS	18
3.1. STANDARD 3270-TERMINALS AND PRINTERS	18
3.2. DEFINING THE REAL E-TERMINALS IN VTAM	19
3.3. DEFINING A LAPTOP/PC WITH HOB COM ASYNCHRONOUS	21
3.4. COMMUNICATION OVER TCP/IP - DEFINITION OF A TN3270 SESSION	27
3.5. DEFINING THE MAJORNODE HOB COM: THE APPLICATION HOB COM AND THE VIRTUAL TERMINALS AND PRINTERS IN VTAM.....	29
3.6. DEFINING THE VIRTUAL TERMINALS IN THE APPLICATIONS	31
3.7. DEFINING THE VIRTUAL PRINTERS IN THE APPLICATIONS.....	35
4. CONNECTING THE TERMINALS	38
4.1. REPLACING A TERMINAL WITH A HOB E-TERMINAL	38
4.2. CONNECTING THE HOB E-TERMINAL.....	38
4.3. CONNECTING TO A 3174 CONTROL UNIT.....	38
4.4. CONNECTING TOKEN RING TERMINALS.....	39
5. Creating terminal and usergroups	40
5.1. In general.....	40
5.2. Identification by announcing to HOB COM	40
6. TERMINAL CONTROL TABLE FOR HOB COM	42
6.1. TABLE STRUCTURE	42

6.2. THE ACB NAME FOR HOB COM.....	43
6.3. TABLE WITH TERMINAL ENTRIES - XCTERMA -	44
6.4. TABLE WITH PRINTER TYPES - XCPRTAB -	47
6.5. GROUP ENTRIES FOR TERMINALS - XCTEGRO -	49
6.6. SCREEN LAYOUT - XCUSSOUT -	51
6.7. TABLE WITH ABBREVIATIONS - XCUSSCOM -	52
6.8. TABLE WITH PRINTER FORM DEFINITIONS - XCPRPAR -	53
6.9. TABLE WITH BATCH TASK COMMANDS - XCUSSBTA -	60
6.10. PERSONAL ENTRIES - XCPERSTA -	64
6.11. LOGON MASK BY S- AND X-SCREENS- XCSYSCTL -	65
6.12. JCL-ENTRIES - XCJCLTAB -	66
6.13. PASSWORD FOR LAPTOPS - LTKEY -	69
6.14. EXIT ROUTINE - XCUPNAM -	70
6.15. AUTHORIZATION FOR HOB COM OPERATOR COMMANDS -XCCOMASK -	73
6.16. HOB COM SCREENMASK	73
6.17. HOB COM PASSWORD - XCPASSW -	80
7. DEFINING PCS WITH HOBLINK 3270 - Y-PROTOCOL -	81
7.1. GENERAL REMARKS CONCERNING THE INSTALLATION.....	81
7.2. PASSWORD IN THE HOB COM TCT.....	81
7.3. PERSONAL ENTRY IN THE HOB COM TCT.....	81
7.4. LOGMODE	83
7.5. USSTAB.....	83
8. PRINTING WITH HOB COM	85
8.1. PRINTING FROM CICS ON STANDARD 3270 TERMINAL.....	85
8.2. PRINTING FROM CICS ON E-TERMINAL PRINTER.....	87
8.3. PRINTING FROM JES ON E-TERMINAL PRINTER.....	88
8.4. Printing over HOB COM on the system printer.....	89
8.5. PRINTING A HARDCOPY ON E-TERMINAL PRINTER.....	90
8.6. PRINTING A LOCAL HARDCOPY ON E-TERMINAL PRINTERS	90
8.7. PRINTING FROM HOB COM OVER TCP/IP	91
9. HOB COM AND TCP/IP	92
9.1. HOB COM DEFINITIONS FOR THE TCP/IP CONNECTION	92

9.2. TN3270 CONNECTIONS TO HOBCOM.....	94
9.3. TN3270E CONNECTIONS TO HOBCOM	96
9.4. PRINTING OVER LPD	102
9.5. Printing on NC.....	105
9.6. PRINTING ON A USER NAME	107
9.7. PRINTING OVER SMB	108
10. HOBCOM DRIVER ROUTINES	113
10.1. \$SPOOL.....	113
10.2. \$PUN	114
10.3. \$PRINT.....	114
10.4. \$SCREEN.....	114
10.5. \$TCT	115
10.6. \$DIALOG	115
10.7. \$VSAM.....	115
10.8. \$PDS	116
11. MESSAGES	117
11.1. GENERAL REMARKS	117
11.2. HOBCOM CONSOLE MESSAGES ON THE HOBCOM TERMINAL	118
11.3. HOBCOM CONSOLE MESSAGES UNDER MVS (XCM, XCT)	120
11.4. COBA MESSAGES	127
11.5. COVTC/COVTOP MESSAGES.....	129
11.6. NOTE MESSAGES	131
11.7. PR3287 MESSAGES.....	133
11.8. PR3770 MESSAGES.....	137
11.9. MESSAGES OF THE XCTCPIP2 PROGRAM.....	141
A. APPENDIX	147
A.1. SAMPLE JOBS	147
A.2. Sample for Terminal Groups	149
A.3. CHANGING THE PRINTER DRIVERS	152
A.4. EXAMPLE FOR AN EXIT-ROUTINE	155
A.5. ERROR MESSAGES WHEN USING LAPTOPS	159
A.6. HOBCOM OPERATOR COMMANDS	160

A.7. HOB COM PROGRAM PARAMETERS	162
A.8. HOB COM PRINT PROGRAM COMMANDS	163
A.9. HOB COM MODETABS	164
A.10. HOB COM USSTABS.....	165
A.11. STANDARD ASSIGNMENT OF HOB COM DRIVER ROUTINES	171
A.11 THE HOB COM CHARACTER SET.....	172

INDEX
174

1. GENERAL REMARKS

1.1. OVERVIEW

With HOB COM, you have a HOST Software available, that gives you a variety of advantages with one module. It can be used in processors with 370 or 390 architecture, that means in 9370-, 4381-, 3090-, 9672- and ES/9000 processors and is supported by MVS/XA and MVS/ESA. HOB COM runs under MVS as VTAM application, it needs ACF/VTAM and occupies one region. It can communicate with all 3270 monitors and 3270 printers. HOB COM reaches its full performance volume with HOB-E-terminals or PCs running HOBLink 3270.

For communication with different terminal types two different protocols are used: the basis protocol with 3270 data flow that can be transmitted NON-SNA as well as SNA, and the X-protocol, that presumes SNA. Under MVS both protocols are supported, the activation results through a corresponding logmode.

For the Communication with several terminal types, four different protocols can be used.

Protocol	SNA / NON-SNA	Mode	Communication with
basics protocol (S - Protocol)	3270 - data stream SNA or NON-SNA	CUT or DFT	HOB S-Terminal, IBM 3270 - Terminal, HOBLink 3270 HOBLink J-Term, 3270-emulations of other manu - facturers, TN3270E-terminal sessions, 3270-printer, TN3270E-printer-session
E - Protocol	SNA or NON-SNA	CUT	HOB E - Terminals
X - Protocol	SNA	DFT	HOB DFT - Terminals
Y - Protocol	SNA	DFT	HOBLink 3270, HOBLink J-Term

These protocols you can activate by the corresponding logmode.

A further advantage of HOB COM is the comfortable printing control. You have the possibility, to send all printing from all applications to a printer that can be connected to any terminal. This pertains especially to the 3287 print (i.e. from CICS or RSCS), 3770 print and print out of the VM spool. HOB COM gives you a comfortable printing control for this purpose that allows i.e. changes in the form parameter online, and to grip into running batch print uses at any time. Besides, printer drivers are integrated into HOB COM that fit to a large number of printers that are on the common market.

Coax-Printers, that normally work only as 3287-printers, can also be used for 3770 print with HOB COM. When a printers is connected to a HOB-E-terminal, many different print drivers are available. Contrary to this, only standard 3287 functions are supported at printing over standard terminals or coax printers.

Special functions, such as passing on of HOB COM- or printer-specific control signs, can be performed through the so-called Hex-Feature. The ^ sign is used to pass on escape sequences to the printer. Form parameters can be established in the HOB COM-TCT that e.g. control the number of lines per page, the number of characters per inch, the type face etc. These parameters can be set by all print programs with PARAM= and can be changed during printing with SET PARAM=. HOB COM offers you data transmission compression and selection in communication with the real terminal or with 3270-machines, as well as during print data transmission. Through a number of HOB COM operator commands, one can be informed of the condition of HOB COM uses at any time.

It is possible to test your own terminal contents or those of other users for errors with the extra program STTE. It can be used by the central User Service for optimal telephonical help. As VTAM application HOB COM can communicate with PCs (Laptops) as well that use the emulation HOBLink for HOB COM

asynchron. The PC communicates via the asynchrone interface, via modem oder via accustic-cuppler with a PAD, that translates the data stream in X.25-protocol. The data stream then reaches HOB COM over NCP and NPSI and thus enables your PC the same advantages as a HOB-E-terminal.

HOB COM works together excellent with the HOB emulation HOBLink 3270. As transfer protocol an HOB specific protocol, the Y protocol is used. This protocol is similar to the HOB X protocol, but it allows additionally data encryption, a better copression and a faster transmission of the data.

HOB COM under MVS supports TCP/IP and allows printing on a print client (LPD) and the communicati-on with TN3270E applications (terminal and printer). Here HOB COM serves as a gateway between the SNA data stream on the host and the IP in the net.

You will find a detailed description of the HOB COM programs COBA, NOTE, COVTC/COV TOP, PR3287 and PR3770 in the HOB COM User's Manual.

1.2. THE HOB COM PROGRAMS

The HOB COM programs can be divided in two main categories:

- Programs, establishing a connection to the application:

COVTC/COV TOP allows communication of the terminal with other applications

- Programs, at least peripherally handling printers:

COBA allows starting, checking and terminating batch programs

NOTE allows saving screen contents and printing of hardcopies

PR3287 emulates a 3287 printer

PR3770 emulates a 3770 printer and enables printing from power as an RJE station

1.3. THE HOB COM DOCUMENTATION

The HOB COM Documentation consists of two manuals

System Manual

The system manual which you read concurrently turns to the administrator of the host system. It will inform you about installation and configuration of HOB COM. Information about the usage of HOB COM that are already contained in the User Manual is not contained in the System Manual once more.

User Manual

The User Manual turns to the users of the terminals or PCs that are connected to HOB COM. The User Manuals describes the commands that are possible in HOB COM, shows you how to print with HOB COM and explains the error messages that HOB COM displays.

1.4. CONVENTIONS

In this manual these styles are used :

i *In this place useful notes are given.*



***In this place important notes and additional information is given, that should be considered.
The stop signal warns you of all actions that have wide effects!***

User entries, screen displays of HOB COM and Listings are printed in this type face and are marked with a frame.

Numerous HOB COM commands can be abbreviated. In this case the smallest possible entry is marked with bold face.

Example: **CO DISPLAY TASKS**
Smallest Entry: **CO D TAS**

Parts of the command syntax which are not variable are written in uppercase.

Parts of the commands which can be selected by the users or which depend on the configuration of the host system are written in lowercase.

Function keys are designated as **F1**, **F2** etc. (Some keyboards are labeled with PF1, PF2, etc.)

2. INSTALLATION GUIDE

2.1. STEPS FOR A FIRST INSTALLATION

Storage Requirements

Since the available (virtual) main storage is managed dynamically, HOB COM checks at startup how much memory is available. Decisive is the value in the REGION parameter in the appropriate job resp. in the appropriate EXEC statement.

Because of the dynamic management of the (virtual) storage no precise specifications of the storage requirements can be made. The amount of main storage required increases with the number of terminals turned on and the number of virtual screens operating. How much storage you will actually need can best be estimated based on practical experience with the system (for this the HOB COM operator command 'D STOR' may be useful).

The priority of the HOB COM partition should lie between that of VTAM and other VTAM applications. In other words, HOB COM should be given a lower priority than VTAM, and it is advisable to assign HOB COM a higher priority than CICS and other similar VTAM applications.

Before the HOB terminals can be operated, the following steps must be executed:

- a) define the major node HOB COM
- b) define the real terminals in VTAM
- c) define the virtual terminals in the applications
- d) define the virtual printers in the applications
- e) connect the terminals
- f) load the magnetic tape
- g) fit the HOB COM TCT
- h) start HOB COM

2.2. LOADING THE MAGNETIC TAPE

You receive a magnetic tape to install the HOB COM programm phase and to load the VTAM tables.

2.2.1. Content of the HOB COM installation tape

Standard- Label	HDR	HOB COM LOADLIB	EOF	HDR	HOB COM. MACLIB	EOF	HDR	HOB COM. LIB1	EOF	

There are 3 libraries on the HOB COM installation tape:

HOB COM.LOADLIB	LOAD-Bibliothek, contains the programm phases XCHOB COM and XCHOB CST
XCHOB COM XCHOB CST	main program that is started via job control is reloaded to start sub tasks
HOB COM.MACLIB	Macro Library, contains the macros for die HOB COM table
HOB COM.LIB1	Source Library, contains the table XCTCT, MODETABs and USSTABs.
	Meaning of these files:
HOBCTCT	= XCTCT = System Table for HOB COM, in which user specific entries are kept (compare chapter 5)
MODTABCO	Modetab for NCCF
MODTABCX	MODTABCX Modetab for X-terminals
MODTABLT	MODTABLT Modetab for laptops
USSTABN1	USSTABN1 USSTAB for NON-SNA-terminals with immediate shut-off
USSTABN2	USSTAB for NON-SNA-terminals with delayed shut-off
USSTABS1	USSTAB for SNA-terminals with immediate shut-off
USSTABS2	USSTAB for SNA-terminals with delayed shut-off
USSTABSA	USSTAB for SNA-terminals under VTAM version 1, with delayed shut-off
USSTABX	USSTABX USSTAB for X-terminals
USSTABLT	USSTABLT USSTAB for laptops
Jxxxx	sample jobs

2.2.2. Loading the HOB COM Programm Phase

In the first step the three data sets have to be allocated. The following amount of space is sufficient:

```
HOB COM.LINKLIB SPACE=(CYL,(2,1,3)),DCB=(RECFM=U,BLKSIZE=23200)
HOB COM.MACLIB SPACE=(CYL,(1,1,10)),DCB=(RECFM=FB,BLKSIZE=6160) ,LRECL=80)
HOB COM.LIB1 SPACE=(CYL,(1,1,10)),DCB=(RECFM=FB,BLKSIZE=6160) ,LRECL=80)
```

Then the program phase is loaded together with the libraries.

Example Job:

```
//TAPINHC JOB (ACCT) , 'HOB COM-LESEN' ,MSGLEVEL=(1,1) ,MSGCLASS=X
//***** LOADS HOB COM FROM THE TAPES INTO THE LIBRARIES
//COPY EXEC PGM=IEBCOPY
//SYSPRINT DD SYSOUT=*
//TAPE1 DD DSN=HOB COM.LOADLIB ,LABEL=(1,SL) ,DISP=SHR ,
// UNIT=3400-9 ,VOL=SER=HOB COM
//TAPE2 DD DSN=HOB COM.MACLIB ,LABEL=(2,SL) ,DISP=SHR ,
// UNIT=3400-9 ,VOL=SER=HOB COM
//TAPE3 DD DSN=HOB COM.LIB1 ,LABEL=(3,SL) ,DISP=SHR ,
// UNIT=3400-9 ,VOL=SER=HOB COM
//TARG1 DD DSN=HOB COM.LINKLIB ,DISP=SHR
//TARG2 DD DSN=HOB COM.MACLIB ,DISP=SHR
//TARG3 DD DSN=HOB COM.LIB1 ,DISP=SHR
//SYSIN DD *
COPY INDD=TAPE1 ,OUTDD=TARG1
COPY INDD=TAPE2 ,OUTDD=TARG2
COPY INDD=TAPE3 ,OUTDD=TARG3
/*
//
```

When using UCC1 please give the label:

```
//LABEL=EXPDT=98000
```

i For performance reasons it may be advantageous to copy the HOB COM modules into an authorized library and to define HOB COM as non-swappable (HOB COM ENTRY in SYS1.PARMLIB - SCHEDxx).

Our tape was invoked with the help of the following job steps:

```
.
.
.
//*****
//STEP4 EXEC PGM=IEBCOPY
//SYSPRINT DD SYSOUT=*
//IN1 DD DSN=HOB COM.LINKLIB ,DISP=SHR
//OUT1 DD DSN=HOB COM.TEMPLIB ,VOL=SER=MVSDL2 ,UNIT=3380 ,
// DISP=(NEW,CATLG) ,SPACE=(CYL,(1,1,3)) ,
// DCB=(RECFM=U,BLKSIZE=23200)
//SYSIN DD *
COPY I=IN1 ,O=OUT1
```

```

SELECT MEMBER=XCHOB COM,XCHOB CST
/
//*****      LOAD ALL ON THE TAPE
//STEP5       EXEC PGM=IEBCOPY

//SYSPRINT DD   SYSOUT=*

//IN1         DD   DSN=HOB COM.TEMPLIB,DISP=SHR
//IN2         DD   DSN=HOB COM.MACLIB,DISP=SHR
//IN3         DD   DSN=HOB COM.LIB1,DISP=SHR
//TAPE1        DD   DSN=HOB COM.LOADLIB,UNIT=TAPE,
//              VOL=SER=HOB COM,LABEL=( ,SL),DISP=(NEW,KEEP)
//TAPE2        DD   DSN=HOB COM.MACLIB,UNIT=TAPE,
//              VOL=SER=HOB COM,LABEL=( 2,SL),DISP=(NEW,KEEP)
//TAPE3        DD   DSN=HOB COM.LIB1,UNIT=TAPE,
//              VOL=SER=HOB COM,LABEL=( 3,SL),DISP=(NEW,KEEP)
//SYSIN        DD   *
COPY I=IN1,O=TAPE1
COPY I=IN2,O=TAPE2
COPY I=IN3,O=TAPE3
/*

```

2.3. DEFINITION OF THE PROGRAM HOB COM IN THE PROGRAM PROPERTY TABLE

In the Program Property Table the following entries are necessary:

```

. . . . .
BROWSE -- SYS1.PARMLIB(SCHEDXX) - 01.00 -----LINE 00000090 COL 001
080
COMMAND ==>                                SCROLL ==>
PAGE
/*              HOB COM                      */
PPT PGMNAME(XCHOB COM)                      /* PROGRAM NAME          */
KEY(8)                      /* PROTECTION KEY         */
NOSWAP                      /* NON-SWAPPABLE          */
AFF(1)                      /* NO PROCESSOR AFFINITY  */
*****
*

```

The entry NOSWAP means, that with HOB COM no Swap is performed. If this entry is not made, the performance may deteriorate.

i The entry AFF(1) means, that HOB COM runs only on one processor. This entry is mandatory, if more than one processor exists.

2.4. STARTING HOB COM

Before you can start HOB COM, your XCTCT must be adjusted (chapter 5).

Please note that all E-terminals and standard 3270 printers as well as the ACB name and the valid HOB COM password must be entered.

To start HOB COM you need a job. Example:

```
//GOHOB COM JOB , 'GOHOB COM' , CLASS=A , REGION=512K , TIME=1440
//JOB LIB DD DSN=HOB COM.LINK LIB , DISP=SHR
//LOAD EXEC PGM=XCHOB COM
//SYSPRINT DD SYSOUT=*
//SYSUDUMP DD SYSOUT=*
//HOB CDUMP DD SYSOUT=*
//PARAM DD *
PHASE :XCTCT
//
```

At the JOBLIB instruction give the parameter UNIT if necessary.

The XCTCT is read via the file that is appointed to the PARAM label (compare chapter 3). If no XCTCT is to be loaded you may enter:

```
//PARAM DD DUMMY
```

If HOB COM is to be started in a procedure, DD * is not valid. Please create a file with the following contents:

```
PHASE :XCTCT
```

Enter the name of this file in the startjob replacing DD *.

3. DEFINING TERMINALS AND PRINTERS

3.1. STANDARD 3270-TERMINALS AND PRINTERS

3.1.1. Defining a 3270-Terminal

HOB COM assumes principally, that a terminal that wants to logon is a HOB-E-Terminal.

When a standard IBM Terminal should logon or when a E-Terminal should be used as a standard IBM-Terminal, HOB COM must be informed of this through the parameter data(s):

Example:

```
LOGON APPLID(application name) DATA(S)
```

At the definition of a real terminal an application name for the LOGON can be transferred, but not the parameter DATA(S). Therefore a standard IBM terminal, that should logon immediately to HOB COM with LOGAPPL=HOB COM, must get an entry in the TCT in macro XCTSTE (see chapter 5), to identify it as a S-terminal.

We recommend, to enter a real standard-IBM-terminal without LOGAPPL-Entry, but with a VTAM-USSTAB-command, with which the parameter DATA(S) is transferred.

Example for a SNA terminal:

```
HOBC      USSCMD  CMD=HOB COM, REP=LOGON, FORMAT=PL1
USSPARM   PARM=APPLID, DEFAULT=HOB COM
USSPARM   PARM=LOGMODE, DEFAULT=HOB LME02
USSPARM   PARM=DATA, DEFAULT=( S, OPT )
```

Example for a NON-SNA terminal:

```
HOBC      USSCMD  CMD=HOB COM, REP=LOGON, FORMAT=PL1
USSPARM   PARM=APPLID, DEFAULT=HOB COM
USSPARM   PARM=LOGMODE, DEFAULT=D4B32782
USSPARM   PARM=DATA, DEFAULT=( S )
```

3.1.2. Defining a 3270-Printer

The definition of a 3270 printer is principally the same as the definition of a standard-IBM-terminal.

As a printer can't use an USSTAB-command to logon, it must always be defined with the help of the macro XCTPRI in the XCTCT (see chapter 5)!

3.2. DEFINING THE REAL E-TERMINALS IN VTAM

The HOB E terminal is to be defined in VTAM as an IBM 3278 Model 2 terminal. This terminal can communicate only with the program HOB COM; and as a result, logon commands cannot be passed directly to VTAM.

The terminals are logged on directly to HOB COM with the support of terminal definition in VTAM.

In order to assure that the terminals will be automatically shut off in case HOB COM has not been started or if for some other reason HOB COM is not available, a USSTAB should be defined. The content of the USSTAB is sent to the terminal, if the terminal is not logged on to HOB COM.

The real terminals are defined in VTAM as IBM 3278 model 2 terminals.

Example of a NON-SNA definition:

CON00	LBUILD		
N01	LOCAL	CUADDR=380 ,	X
		TERM=3277 ,	X
		DLOGMOD=S3270 ,	X
		FEATUR2=(MODEL2,NOSELPEN) ,	X
		ISTATUS=ACTIVE ,	X
		LOGAPPL=HOB COM ,	X
		USSTAB=USSTABN2	

Example of a SNA definition:

COS00	VBUILD	TYPE=LOCAL	
COP00	PU	CUADDR=3A0	
S02	LU	LOCADDR=002 ,	X
		SSCPFM=USSSCS ,	X
		DLOGMOD=D4A32782 ,	X
		ISTATUS=ACTIVE ,	X
		LOGAPPL=HOB COM ,	X
		USSTAB=USSTABSA	

3.2.1. LOGMODE for SNA- and NON-SNA Terminals

The communication mode between terminal and application program (here HOB COM) is specified with support of logon mode tables.

The same logon mode used for the IBM 3278 model 2 terminals should be chosen for the HOB E terminal.

VTAM-Standard-MODETAB ISTINCLM entries can be used; the logmode used depends on the control unit.

If the terminal HOB 88 E/89 E is to be connected to a NON-SNA unit, the entry S3270 or D4B32782 can be used.

If the terminal is to be connected to a SNA unit, use one of the following entries: D4A32782, D4C32782 or D6327802. (Use the entry which corresponds to your control unit.)

If you want a different report format as the standard model 2, the last place of the logmode has to be fit accordingly:

Example: D4C32782 stands for model 2, D4C32875 stands for model 5.

3.2.2. USSTAB for SNA- bzw. NON-SNA-Terminals

Five different USSTAB entries are listed in the appendix, choose the appropriate one and assemble it. These USSTAB entries are part of the HOB COM installation tape, see chapter 2.

The USSTAB requires that a distinction be made between terminals connected to an SNA control unit and NON-SNA control unit. A NON-SNA control unit is indicated as type A (A in second position of the terminal status line).

An SNA control unit is indicated as type B (B in second position of the terminal status line).

The display printer adapter of the 4321, 4331 or 4361 CPUs is handled as a NON-SNA control unit.

An example is given for each type of control unit; one with immediate shut off and one with delayed shut off. When using an SNA control unit please note the following:

The parameter specification LOGAPPL=HOB COM in the VTAM table causes the terminal to be connected to the HOB COM application when HOB COM is started.

The session will not be started, if VTAM Version 1 or 3 is installed, the terminal is running in the REMOTE status and the terminal is switched off (normal case). HOB COM sends the message:

```
XCT00050 D=
      LOG-ERR   RTNCD=10   FDBK2=01
      SENCE=080A0000
```

And as a result a terminal connected to an SNA control unit, if it determines after having been switched on that no session has been established, sends the command 'CODIS'.

The instruction 'CODIS' is converted to a logon in the VTAM application HOB COM with the help of the USSTABSA.

Under VTAM Version 2 the terminal logon in HOB COM occurs after the terminal is switched on.

If VTAM Version 2 is installed, use the USSTABS1 or USSTABS2 table. The table with delayed switch off should be preferred when using remote terminals, since VTAM also sends messages specified in the USSTAB after line error etc. before the terminal is logged on in HOB COM.

The following tables can be found in the appendix:

USSTABN1	USSTAB for NON-SNA control units; the terminal is switched off immediately
USSTABN2	USSTAB for NON-SNA control units; the terminal is switched off with delay
USSTABS1	USSTAB for SNA control units; the terminal is switched off immediately.
USSTABS2	USSTAB for SNA control units; the terminal is switched off with delay.
USSTABSA	USSTAB for SNA control units and VTAM version 1; the terminal is switched off with delay.

3.3. DEFINING A LAPTOP/PC WITH HOB COM ASYNCHRONOUS

3.3.1. General Remarks for an Installation

We suggest the following steps for installation:

1. Apply for the NUI at Telekom early (this takes the longest time)
2. Fit the NCP
3. Load the HOB COM installation tape
4. Establish VTAM-entries (they can partly be found on the HOB COM installation tape)
5. fit HOB COM-TCT (with password)
6. start up HOB COM.
7. fit the HOBLINK setup for HOB COM asynchron

3.3.2. Entry in the NCP

The entries for LLCLIST, IDBLKP, PAD and TRAN have a special meaning for the laptop. Other than that, the SVC lines that could be used are made available:

* STAGE 1 OF THE X.25				
*				
LINE08	X.25.NET	NETTYPE=1,	NETWORK IS DATAPAC	
		DM=YES,	LAPB DM IS USED	X
		CPHINDX=1		
	X.25.VCCPT	INDEX=1,		X
		MAXPKTL=128,	MAX PACKET LENGTH	X
		VWINDOW=7		
	X.25.OUFT	INDEX=1		
	X.25.MCH	ADDRESS=008,	LIA TO DATEX-P-NODE	X
		LCGDEF=(0,15),	NUMBER OF VC'S	X
		FRMLGTH=131,		X
		LLCLIST=(LLC0,LLC2,LLC3,LLC4,LLC5),	TYPE OF SVC	X
		LCN0=NOTUSED		X
		IDBLKG=065,	NUMBER OF GATE	X
		IDBLKC=066,	NUMBER OF PCNE	X
		IDBLKP=067,	NUMBER OF PAD	X
		MWINDOW=7,	SDLC WINDOW SIZE	X
		NPRETRY=10,	NUMBER TIMEOUT RECOV.	X
		PAD=INTEG,	PAD SUPPORT INTEGRATED	X
		GATE=GENERAL,	PAD CAN SEND INTERRUPT PACKET	X
		STATION=DTE,	NCP PORT WILL OPERATE AS DTE	X
		SPEED=64000,		X
		TRAN=NO,	NO TRANSLATION FOR LAPTOP	X
		TPTIMER=3	T1 - TIMER	
.				
.				
.				
X258L05	X25.LINE	LCN=5,	LOG. CHANNEL 5 WITHIN GROUP 8	X
		VCCINFX=1,		X
		OUFINDX=1,		X
		CALL=INOUT,	CALL IN AND OUT	X
		TYPE=S	SVC	
X258P05	X25.PU	PUTYPE=(1,2)		
*				
X258L06	X25.LINE	LCN=6,	LOG. CHANNEL 6 WITHIN GROUP 8	X
		VCCINFX=1,		X
		OUFINDX=1,		X
		CALL=INOUT,	CALL IN AND OUT	X
		TYPE=S	SVC	
X258P06	X25.PU	PUTYPE=(1,2)		
*				
X258L07	X25.LINE	LCN=7,	LOG. CHANNEL 7 WITHIN GROUP 8	X
		VCCINFX=1,		X
		OUFINDX=1,		X
		CALL=INOUT,	CALL IN AND OUT	X
		TYPE=S	SVC	
X258P07	X25.PU	PUTYPE=(1,2)		

LLCLIST this list must in any case contain LLC5 for the PAD

IDBLKP this number must be entered in der switched major node for IDBLK; for older NCPs, that do not yet support the value 067, '003' is to be entered

PAD PAD=INTEG is absolutely necessary

TRAN no translation may be done for the laptop, therefore TRAN=NO is absolutely necessary

X258L05 - X258L07
 are alle SVC-Lines des Kanals. All present SVCs must be entered at the laptop definition!

Macro X.25.VC can also be used instead of the macros X25.LINE and X25.PU.

3.3.3. Entry in the Switched Major Node

Statements for IDBLK, the ID numbers, the LU names, the Modtab and the Usstab are contained in the switched major node:

```

* $$ JOB JNM=X25TE02,CLASS=A,DISP=D
* $$ LST DISP=D,CLASS=C,DEST=( ,SYSGEO)
// JOB X25TE02
// EXEC LIBR
  ACCESS SUBLIB=GEOLIB.SYSLIB
  CATALOG X25TE02.B REPLACE=YES
X25TE02  VBUILD TYPE=SWNET
X25T01C  PU  ADDR=01,
          IDBLK=067,
          IDNUM=00006,
          PUTYPE=1,
          MAXDATA=265,
          MAXOUT=7,
          SSCPFM=USSSCS,
          ISTATUS=ACTIVE
X25T01L  LU  LOCADDR=000,
          SSCPFM=USSSCS,
          MODETAB=MODTABLT,
          USSTAB=USSTABLT,
          ISTATUS=ACTIVE
X25T02C  PU  ADDR=01,
          IDBLK=067,
          IDNUM=00004,
          PUTYPE=1,
          MAXDATA=265,
          MAXOUT=7,
          SSCPFM=USSSCS,
          ISTATUS=ACTIVE
X25T02L  LU  LOCADDR=000,
          SSCPFM=USSSCS,
          MODETAB=MODTABLT,
          USSTAB=USSTABLT,
          ISTATUS=ACTIVE
X25T03C  PU  ADDR=01,
          IDBLK=067,
          IDNUM=00002,
          PUTYPE=1,
          MAXDATA=265,
          MAXOUT=7,
          SSCPFM=USSSCS,
          ISTATUS=ACTIVE
X25T03L  LU  LOCADDR=000,
          SSCPFM=USSSCS,
          MODETAB=MODTABLT,
          USSTAB=USSTABLT,
          ISTATUS=ACTIVE

/+
/*
/&
* $$ EOJ

```

IDBLK must contain the number from the NCP IDBLKP entry; older NCPs use '003'

IDNUM the ID numbers are given by the NCP at intervals of 2

X25T01L- X25T03L
 these LU names are simultaneously the HOB COM TCT master entries for laptops

MODETAB here the name of the modetab for laptops is given, thus MODTABLT

USSTAB here the name of the Usstab for laptops is given, thus USSTABLT

3.3.4. Logmode for Laptops

To logon to HOB COM laptops use the logmode ENTRYC. It is described in the Modetab MODTABLT, that you find in the appendix and on the installation tape.

3.3.5. USSTAB for Laptops (USSTABLT)

```
* $$ JOB JNM=USSTABLT,CLASS=A,DISP=D
* $$ LST DISP=D,CLASS=C,DEST=( ,SYSGEO)
// JOB USSTABLT
// EXEC PROC=SPACEMGR
// LIBDEF PHASE,CATALOG=GEOLIB.SYSLIB,TEMP
// OPTION CATAL,NODECK
   PHASE USSTABLT
// EXEC ASSEMBLY,SIZE=128K
      TITLE 'USSTABLT - NORMAL-USSTAB FOR LAPTOP'
      PRINT NOGEN
USSTABLT USSTAB
LTC1    USSCMD CMD=LTC1,REP=LOGON,FORMAT=PL1
          USSPARM PARM=APPLID,DEFAULT=HOB CM C1
LTC2    USSCMD CMD=LTC2,REP=LOGON,FORMAT=PL1
          USSPARM PARM=APPLID,DEFAULT=HOB CM C2
*
MESSAGES EQU      *
          USSMSG MSG=1,BUFFER=MESS01      ;WRONG FORMAT
          USSMSG MSG=2,BUFFER=MESS02      ;COMMAND UNKNOWN
          USSMSG MSG=3,BUFFER=MESS03      ;PARAMETER UNKNOWN
          USSMSG MSG=4,BUFFER=MESS04      ;PARAMETER INVALID
          USSMSG MSG=5,BUFFER=MESS05      ;FUNCION NOT SUPPORTED
          USSMSG MSG=6,BUFFER=MESS06      ;SEQUENCE ERROR
          USSMSG MSG=7,BUFFER=MESS07      ;BIND REJECT PROM APL
          USSMSG MSG=8,BUFFER=MESS08      ;INSUFFICIENT MAIN STORAGE
          USSMSG MSG=12,BUFFER=MESS0C     ;OPERAND MISSING
          USSMSG MSG=13,BUFFER=MESS0D     ;VTAM ECHO
*
END        USSEND
*
MESS01     EQU      *                                ;VTAM-MESSAGE 1
          DC        AL2(5)                          ;LENGTH
          DC        X'4100010141'                    ;MESSAGE
MESS02     EQU      *                                ;VTAM-MESSAGE 2
          DC        AL2(5)                          ;LENGTH
          DC        X'4100010242'                    ;MESSAGE
MESS03     EQU      *                                ;VTAM-MESSAGE 3
          DC        AL2(5)                          ;LENGTH
```

```

MESS04    DC      X'4100010343'          ;MESSAGE
          EQU      *                      ;VTAM-MESSAGE 4
          DC      AL2(5)                  ;LENGTH
          DC      X'4100010444'          ;MESSAGE
MESS05    EQU      *                      ;VTAM-MESSAGE 5
          DC      AL2(5)                  ;LENGTH
          DC      X'4100010545'          ;MESSAGE
MESS06    EQU      *                      ;VTAM-MESSAGE 6
          DC      AL2(5)                  ;LENGTH
          DC      X'4100010646'          ;MESSAGE
MESS07    EQU      *                      ;VTAM-MESSAGE 7
          DC      AL2(5)                  ;LENGTH
          DC      X'4100010747'          ;MESSAGE
MESS08    EQU      *                      ;VTAM-MESSAGE 8
          DC      AL2(5)                  ;LENGTH
          DC      X'4100010848'          ;MESSAGE
MESS0C    EQU      *                      ;VTAM-MESSAGE C
          DC      AL2(5)                  ;LENGTH
          DC      X'4100010C4C'          ;MESSAGE
MESS0D    EQU      *                      ;VTAM-MESSAGE D
          DC      AL2(5)                  ;LENGTH
          DC      X'4100010D4D'          ;MESSAGE
*
          END
/*
// EXEC LNKEDT
/&
* $$ EOJ

```

LTC1, LTC2 USSTAB commands to logon an application, in our case the HOBCOM machines HOBCMC1 or HOBCMC2; one of these commands ist to be entered into the PAD setup of the PC!

HOBCMC1, HOBCMC2
 two different VTAM APPL names Please note, that you may not change the messages in this USSTAB!

Pease note, that you may not change the mesages in this USSTAB!

Further information on laptops can be found in chapters 5.3 and 5.12 and in the appendix.

3.4. COMMUNICATION OVER TCP/IP - DEFINITION OF A TN3270 SESSION

The connection to HOB COM from PCs can be made over TCP/IP with a TN3270 application.

Requirements for doing this:

- TCP/IP for MVS on the host
- TN3270 capable application on the PC
- TCP/IP on the PC

For the communication in the TN3270- application the IP address of the host has to be entered.

e.g.: 194.45.234.100

Additionally the correct port number has to be entered,

For HOB COM e.g. PORT 1026

To make a port known an OPEN command has to be entered:

e.g. in HOB COM

```
OPEN TCPIP TELNET PORT=1026
```

Ports, that are already used by other programs e.g. port 23 may not be used. The port entry has to correspond with the entry made in the emulation.

When you make this OPEN TCPIP already has to be started and active.

After you close and restart TCP/IP, it is not sufficient to make a second OPEN in HOB COM. A CLOSE has to be made before.

In HOB COM

```
CLOSE TCPIP TELNET PORT=1026
```

If the job name of the TCPIP on the host is "TCPIP", no additional entry in the TCT is necessary.

If you use a different job name, this name has to be made known for HOB COM in the HOB COM TCT over the macro XCTCPIP.

Example:

```

XCTCTANF XTCTGEN TERMA=XCTERMA,      X
                PRTAB=XCPRTAB,        X
                TEGRO=XCTEGRO,        X
                USSOUT=XCUSSOUT,      X
                USSCOM=XCUSSCOM,      X
                PRPAR=XCPRPAR,        X
                USSBTA=XCUSSBTA,      X
                JCLTAB=XCJCLTAB,      X
                DIANAM=XCDIANAM,      X
                TCPIP=XCTCPIP,          X
                COMASK=XCCOMASK,      X
                PASSW=XCPASSW

```

The new table XCTCPIP has to be added after a table that already exists (e.g. under the END mark of XCDIANAM)

XCTCPIP	DS	0F	
	XCTCPIP	NSERVER=aaa.bb.ccc.d,	X
		JNTCPIP=jobname	X
		DOMAIN=domainname,	X
		HOST=hostname,	X
		TIMEOUT=15	
DC	AL2(0)	;End mark of the table	

- aaa.bb.ccc.d TCP/IP address of the name server.
The parameter NSERVER is only necessary, if HOB COM is to print on print clients. For printing over HOBLINK 3270 using the Y protocol, this entry is not necessary, because the session is built from HOB COM here.
- Jobname Name of the JOB, that has started TCP/IP.
This parameter is optional, but if the job name is not TCPIP it has to be entered.
- hostname the TCP/IP name of the host, which executes HOB COM
This parameter is optional.
- Domainname the name of the TCP/IP domain, in which the host "hostname" is located.
This parameter is optional.

In order to create a TN3270 session to HOB COM the authorization for using S sessions or Y sessions is required. This authorization is granted over a HOB COM password, an additional HOB COM feature. The password offering the required number of sessions can be bought over the HOB support.

3.5. DEFINING THE MAJORNODE HOBCOM: THE APPLICATION HOBCOM AND THE VIRTUAL TERMINALS AND PRINTERS IN VTAM

For the application program HOBCOM as well as for each virtual screen of a HOB E terminal and a virtual printer applications are defined:

Example:

HOBCOML1	VBUILD	TYPE=APPL	
HOBCOM	APPL	ACBNAME=HOBCOM,	X
		AUTH= (ACQ , PASS) ,	X
		EAS=30	
*			
N011	APPL	ACBNAME=N011,	X
		AUTH= (ACQ , NOPASS) ,	X
		EAS=1 ,	X
		DLOGMOD=D4C32782	
*			
N012	APPL	ACBNAME=N012,	X
		AUTH= (ACQ , NOPASS) ,	X
		EAS=1 ,	X
		DLOGMOD=D4C32782	
*			
N013	APPL	ACBNAME=N013,	X
		AUTH= (ACQ , NOPASS) ,	X
		EAS=1 ,	X
		DLOGMOD=D4C32782	
*			
N014	APPL	ACBNAME=N014,	X
		AUTH= (ACQ , NOPASS) ,	X
		EAS=1 ,	X
		DLOGMOD=D4C32782	
*			
N01P	APPL	ACBNAME=N01P,	X
		AUTH= (ACQ , NOPASS) ,	X
		VPACING=1 ,	X
		EAS=2	

The name of a major node (in the above example HOBCOML1) cannot have the same name as the applications.

The MAXAPPL parameter in VTAM must be large enough to accomodate all of the applications. Each virtual screen and each printer is considered to be an application. Therefore, one real terminal together with a printer will have 5 applications (four virtual screens and one printer).

The name of the major node (which has been defined for HOBCOM) must also be listed in VTAM.

Convention:

You can use any name you like for virtual terminals and printers in HOBCOM. However, to simplify the assignment of terminal names try to adhere to the following guidelines:

Each terminal is assigned a name with a maximum of seven characters. For each of the four virtual screens (P1 to P4) an additional digit from 1 and 4 is appended to the name. The name of the printer can be had by adding a 'p' to the terminal name.

If the termnal already has an 8-character name, the first character is to be deleted before appending 1 to 4 or p to the name.

Since names are not allowed to begin with numbers, the first digit can be replaced by a \$ sign.

Examples:

The name of the real terminal is N01.

The virtual screens are to be assigned the names: N011, N012, N013, N014.

The virtual printer will be assigned the name N01P.

The application HOB COM controls all real screens, therefore, you should specify a value for EAS.

EAS=n n... maximal number of screens operating under HOB COM.

Choose a value which is 20% higher. For instance, if you want to have 10 screens enter 12.

The virtual screens operate with only one application, therefore, specify EAS=1 for each virtual screen.

The virtual printer can go into session with many applications, therefore you can enter EAS=n.

When defining virtual screens you should specify a DLOGMOD parameter.

Application programs which interrogate the BIND parameter can then determine which mode of communication is being used. TSO and VCNA are examples of application programs that do this; other programs, e.g. CICS, generate the BIND parameters themselves and do not query the default values.

`DLOGMOD=D4C32782`

The above parameter should be specified, since the virtual terminals are by definition SNA terminals, regardless of how the real terminals are defined.

If a terminal is to operate in the 7 color mode (using COVTC), the logmode D4C32792 is to be substituted for the logmode D4C32782. If this entry is not contained in your standard MODTAB, the entry from the MODTABCO can be used. In addition to MODTAB=MODTABCO, the following entry must be made:

`DLOGMOD=D4C32792`

3.6. DEFINING THE VIRTUAL TERMINALS IN THE APPLICATIONS

The virtual screens always communicate as SNA units (LUTYPE 2), even if the real terminals are connected to a NON-SNA-control unit.

Output-Chaining, i.e. splitting up the output messages into several blocks, which must be executed for the SNA control unit, is not necessary and is suppressed.

3.6.1. CICS

There are two possible ways to define real terminals, virtual terminals or virtual printers in CICS:

1. through an entry in the CICS TCT
2. automatic generating using AUTOINSTALL or RDO

With AUTOINSTALL, an entry is generated in the CICS-TCT at the moment of LOGON that is erased at LOGOFF. This method is only possible when the terminal is not entered in the CICS TCT.

3.6.1.1. Definition in the CICS TCT

The virtual terminals must be listed in the Terminal Control Table (TCT).

It is not necessary to define the real terminal!

Using the parameter NETNAME= you specify the name of the virtual terminal as it is defined in VTAM.

N011	DFHTCT TYPE=TERMINAL,	X
	ACCMETH=VTAM,	X
	TRMTYPE=LUTYPE2,	X
	TRMMODL=2,	X
	FEATURE=(DCKYBD),	X
	GMMSG=YES,	X
	PGESTAT=PAGE,	X
	PAGESIZE=(24,80),	X
	TCTUAL=255,	X
	TIOAL=(2048,4096),	X
	RUSIZE=2560,	X
	CHNASSY=YES,	X
	RELREQ=(NO,YES),	X
	TRMSTAT=TRANSCIEVE,	X
	TRMIDNT=N011,	X
	NETNAME=N011,	X
	TRMPRTY=0	

The virtual terminals are defined as LUTYPE 2.

Using the parameter TCTUAL you specify the same value used in your installation.

If you want to allow different screen models you must explicitly enter this:

Example for model 5:

N022	DFHTCT TYPE=TERMINAL,	X
	ACCMETH=VTAM,	X
	TRMTYPE=LUTYPE2,	X
	FEATURE=(DCKYBD),	X
	GMMSG=YES,	X
	PGESTAT=PAGE,	X
	PAGESIZE=(24,80),	X
	TCTUAL=255,	X
	TIOAL=(2048,4096),	X
	DEFSCRN=(24,80),	X
	ALTSCRN=(27,132),	X
	RUSIZE=2560,	X
	BUFFER=1532,	X
	CHNASSY=YES,	X
	RELREQ=(NO,YES),	X
	TRMSTAT=TRANSCIVE,	X
	TRMIDNT=N022,	X
	NETNAME=N022,	X
	TRMPRTY=0	

In addition the PCT in the transaction, that the assigned Terminal model will be using, must be defined in the entry Macro 'DEFSCREEN=ALTSCREEN'!

If the model should be valid for all transactions, the definition can be carried over into the initial macro.

3.6.1.2. Definition using AUTOINSTALL or RDO

Two tables are important for AUTOINSTALL and RDO: TYPETERM and TERMINAL.

Example:

TYPETERM(TYPETAB1)	GROUP(TYPG)
RESOURCE=TYPE	DEVICE(LUTYP2) TERMMODEL(2) SESSIONTYPE()
	PRINTERTYPE()
MAPPING-PROPERTIES	PAGESIZE(24,80) ALTPAGE(0,0) ALTSUFFIX()

PAGING-PROPERTIES	AUTOPAGE(YES)
DEVICE-PROPERTIES	DEFSCREEN(24,80) ALTSCREEN(0,0) APLKYBD(NO)
	HIGHLIGHT(NO)
SESSION-PROPERTIES	ASCII(NO) SENDSIZE(255) RECEIVESIZE(255)
	BRACKET(YES) LOGMODE(0)

When LOGMODE=0 is entered, the dynamic generation of the terminal is performed according to the BIND parameter. When a name instead of zero is given, the terminal with this TYPETERM-Definition will only then be generated, when the name of the logmode is the same as the name registered in LOGMODE=name. At logon the name of the logmode is transferred from VTAM to CICS.

The VTAM BIND informations are alone not sufficient to generate a TCT entry. CICS finds most of the necessary information in the TERMINAL table.

When you use RDO, CICS is given the necessary information with the help of the DEFINE command.

Example:

```

TYPETERM(TYPETAB1) GROUP(TERMG) AUTOINSTMODEL(NO) AUTOINSTNAME( )
TERMINAL-IDENTIFIERS TYPETERM(TYPETAB1) NETNAME(SNAN021)

ASSOCIATED PRINTERS      .....
PIPELINE PROPERTIES      .....
OPERATOR DEFAULTS        .....
TERMINAL USAGE           .....
.....
SESSION SECURITY         .....

```

If AUTOCONN(YES) has been given, the terminal logs automatically on at a CICS EMERGENCY RE-START, without having to rerun the autoinstall procedure. The already given definitions remain as long as at least one session exists. When there is no active session, the TCT entry is erased.

TCT entries that have been made with the help of AUTOINSTALL will also be erased at a CICS warmstart and at a coldstart.

Please note:

When using your own autoinstall entries, you must make sure, that the correct LOGMODE entries are available in VTAM, i.e. the correct MODETAB must be given.

CICS checks if the bind parameter and the TYPETERM parameter correspond when LOGON is requested. If they greatly differ (i.e. LUTYP3 instead of LYTP2), the request will be denied. That means, that CICS first compares the LOGMODE Informations with all of its model descriptions and then chooses the one that fits best!

With LOGMODE entries you need to watch entries like DEFSCREEN, ALTSCREEN and ALTPAGE!

That means:

To define the real terminals (that, according to our examples, use the logmodes D4A32872 and D4B32872) and the virtual printer (that work with DSC2K or SCS) the default group of the TYPETERM definitions (i.e. DFHTYPE) will be chosen (TYPETERM definitions of the DFHTYPE group are found in the manual "CICS/VSE 2.1 Resource Definitions (Online)" on page 302).

If a Logmode that is not in DFHTYPE, i.e. D4C32792 (for SNA extended datastream, Model 2) or D4C32785 (for SNA, without extended datastream, Model 5) shall be used for a virtual terminal, then an own TYPETERM must be defined for this!

Besides this you must heed that at using such a logmode in VTAM, the correct MODETAB was given at the definition of the virtual terminal (SAPPL)!

Example:

For a virtual terminal with SNA, extended datastream and Model 4, a TYPETERM is prepared: DFHLZ2E4. This expects SNX32784 as LOGMODE. At the definition of the virtual terminal must, in this case, be heeded, that the MODETAB is entered, in which this LOGMODE (given in the VTAM definition) is to be found! This is the case with MODETAB IESINCLM.

If no MODETAB is given with SAPPL, VTAM uses the MODETAB ISTINCLM.

3.6.2. TSO

In TSO there are no corresponding tables, the mode of the communication is taken from the BIND parameters. Therefore, you must make certain, that in the definition of the virtual terminals in VTAM you have

specified the correct logmode (and the corresponding modetab, if it can't be found in the standard mode-tab):

```
MODETAB=MODTABCO
DLOGMOD=D4C32782
```

If you wish to operate TSO in the seven color mode, you must make the following entry:

```
DLOGMOD=SNX32702
```

3.6.3. IMS

In IMS the virtual terminals are defined as Logical-Unit-Type 2.

Example:

```
TYPE    UNITYPE=SLUTYPE2,MODEL=2,OPTIONS=TRANRESP,          X
        FEAT=( PFK,NOCD,NOPEN)
TERMINAL NAME=N011
TERMINAL NAME=N012
.
```

3.6.4. ROSCOE

In ROSCOE there are no corresponding tables, the mode of the communication is taken from the BIND parameters. Therefore, you must make certain, that in the definition of the virtual terminals in VTAM you have specified the correct logmode (and the corresponding modetab, if it can't be found in the standard modetab):

```
MODETAB=MODTABCO
DLOGMOD=D4C32782
```

3.6.5. HCF

In HCF there are no corresponding tables, the mode of the communication is taken from the BIND parameters.

Therefore, you must make certain, that in the definition of the virtual terminals in VTAM you have specified the correct logmode: a logmode valid for an SNA terminal with a screen size of 1920-characters.

Example:

```
HPS1920    MODEENT    LOGMODE=PS1920,FMPROF=X'03',          X
                PRIPROT=X'B1',SECPROT=X'90',COMPROT=X'3080',  X
                RUSIZES=X'8587',                                X
                PSERVIC=X'020000000000185000007E00'
```

3.7. DEFINING THE VIRTUAL PRINTERS IN THE APPLICATIONS

You can connect a HOB printer directly to your HOB E terminal.

If the printer is to be accessed via VTAM, you must define it as an application in VTAM.

3.7.1. Definition for the 3287 Emulation

Using program PR3287 you can print directly from your applications on a HOB COM printer. However, you must first define the HOB COM printer in your applications.

3.7.1.1. Definition in CICS

In CICS you can specify the HOB printer as LUTYPE1 or LUTYPE3.

Example of a LUTYPE 1

N01P	DFHTCT TYPE=TERMINAL,	X
	ACCMETH=VTAM,	X
	TRMTYPE=SCSPRT,	X
	TRMMODL=2,	X
	COMPAT=NO,	X
	ERRATT=NO,	X
	PAGESIZE=(24,80),	X
	PGESTAT=AUTOPAGE,	X
	TCTUAL=255,	X
	TIOAL=160,	X
	TRMSTAT=RECEIVE,	X
	TRMIDNT=N01P,	X
	NETNAME=N01P,	X
	TRMPRTY=0	

Example of a LUTYPE 3

N01P	DFHTCT TYPE=TERMINAL,	X
	ACCMETH=VTAM,	X
	TRMTYPE=LUTYPE3,	X
	COMPAT=NO,	X
	ERRATT=NO,	X
	PAGESIZE=(24,80),	X
	PGESTAT=AUTOPAGE,	X
	TCTUAL=255,	X
	TIOAL=160,	X
	TRMSTAT=TRANSCEIVE,	X
	TRMIDNT=N01P,	X
	NETNAME=N01P,	X
	TRMPRTY=0	

3.7.1.2. Definition in DSPRINT

In DSPRINT you define the HOB printers as IBM 3287 printers. You can address them as LUTYPE1 or LUTYPE3.

Example of a definition:

```
FD NAME=QABP3NAM,LENGTH=8,STARTLOC=57,PICTURE=8,'N01P'
FD NAME=QABP3OQA,LENGTH=4,STARTLOC=65,PICTURE=1,B'0'
FD NAME=QABP3LQA,LENGTH=4,STARTLOC=69,PICTURE=1,B'0'
FD NAME=QABP3BFS,LENGTH=2,STARTLOC=73,PICTURE=3,B'768'
FD NAME=QABP3WID,LENGTH=1,STARTLOC=75,PICTURE=3,B'132'
FD NAME=QABP3PLN,LENGTH=1,STARTLOC=76,PICTURE=2,B'72'
FD NAME=QABP3TMG,LENGTH=1,STARTLOC=77,PICTURE=1,B'2'
FD NAME=QABP3BMG,LENGTH=1,STARTLOC=78,PICTURE=1,B'2'
FD NAME=QABP3HPP,LENGTH=1,STARTLOC=79,PICTURE=3,B'132'
FD NAME=QABP3TYP,LENGTH=1,STARTLOC=80,PICTURE=1,B'1'
```

3.7.1.3. Definition in IMS

In IMS you define the HOB printers as IBM 3287 printers. You can address them as LUTYPE1 or LUTYPE3.

3.7.2. Definition for the 3770 Emulation

Using program PR3770 you can print directly from your spooling system on a HOB COM printer. HOB COM printers emulate RJE-stations and must be defined accordingly.

3.7.2.1. Definition in JES2

To print directly from JES2, you must specify your printer in the JES2 definitions.

Example:

```
LOGON1 APPLID=JES2
&MAXSESS=nnnn
&NUMLINES=nnnn
&NUMLOGS=1
&NUMRJE=nnnn
&NUMTPBF=(nnnn,mmmm)
&TPIDCT=31
*
LINE1 UNIT=SNA
RMTnnnn DEVTYPE=LUTYPE1,BUFSIZE=512,NUMPRT=1,NUMRDR=0,NUMPU=0,
LUNAME=N01P,COMPRESS=NO,COMPACT=NO,CONS=YES
$TRMTnnnn,A=Y
Rnnnn.PR1 PRWIDTH=132,COMP=NO,CMPCT=NO,CCTL=YES
```

Enter the name of the VTAM application as APPLID. MAXSESS defines the maximum number of VTAM sessions; NUMLINES is the number of lines; NUMLOGS is the number of JSE2/VTAM interfaces; NUMRJE is the number of the RJE stations; NUMTPBF is the number of the JSE2 TP buffers.

3.7.2.2. Definition in JES3

In JES3 you define the HOB COM printer as 3776-RJE stations.

Example:

```
COMMDEFN,APPLID=JES3,LU=5  
CONSOLE,JNAME=RMT01,TYPE=RJP,DEST=NONE,LEVEL=15  
DEVICE,DTYPE=RMTPRINT,JNAME=RMT01PR1,XLATE=NO  
RJPWS,N=RMT01,RD=0,PR=1,G=RMT01,AUTO=N,COMPACT=NO,C=R
```

The VTAM ACB name and the maximum number of LUs are to be entered in the first line.

4. CONNECTING THE TERMINALS

4.1. REPLACING A TERMINAL WITH A HOB E-TERMINAL

If you have not yet replaced your terminal with an E terminal, you can enter the following string on the terminal attached to the transmission line which is to be used for the HOB E terminal:

```
8AA?<
```

The A's must be entered as capital letters. This lets you determine, if the installation has been successfully completed.

If the installation has been successfully carried out, the following five-line string from HOB COM is displayed:

```
B0?<?C12?????Ö%?<<<§<§<§ HOB COM <§<§<§ COMMUNICATIONS- AND DIALOG-
SYSTEM ;Ö<§ HOB <§<§<§ä!äü P1*&%äüäü P2*&% äüäü P3*&% äüäü P4*&% äü
<!<§<§<§<§ ä$LINE.N01 *!§<§ä&*ÖÖ *ÖÖ *ÖÖ *ÖÖ *ää P1*&§ ----+----1----
+----2----+----3----+----4----+----5----+----6----+----7----+----8*&_
*ÖÖ??*ÖÖ??*ÖÖ??*ÖÖ??*ÖÖ??*ÖÖ??*ÖÖ?????4!<?ü>??ü1??$%
```

You can now connect the HOB E terminal.

4.2. CONNECTING THE HOB E-TERMINAL

The sockets for connecting power, system, keyboard and printer are located on the rear panel of the terminal.

Attach the power cord, the COAX cable and the keyboard cable in the corresponding sockets on the back of the terminal. A diagram is included in the operating instructions.


Press the green button located on the front of the terminal (if need be switch on the power switch on the rear of the terminal). If HOB COM and the terminal have been installed correctly, the HOB COM console panel will appear on the screen.

4.3. CONNECTING TO A 3174 CONTROL UNIT

The file transfer aid bit must be set in the 3174 control unit if a HOB E terminal is connected to it (query 125: 6th bit).

4.4. CONNECTING TOKEN RING TERMINALS

Token Ring Terminals are connected according to the following scheme:



5. Creating terminal and usergroups

With HOB COM you have the possibility to group several user or terminals. Therefore it is possible to assign authorizations in groups.

5.1. In general

The assignment of the terminals/persons to the groups you define in the HOB COM table XCTCT. (see the following paragraph). Therefore are entries in the following tables necessary:

- XCTEGRO
- XCPERS
- XCTCT

An example for that you can find in the appendix of this manual.

The table XCTEGRO

In the table XCTEGRO you define with the macro XCTEGRO the characteristics of a usergroup. You can define command abbreviations and the appearance of the HOB COM basic mask as well as the authorization for HOB COM operator commands.

The table XCTERMA

In the table XCTERMA you define with the macros XCTCT, XCTSTE and XCTPRI to which group a terminal should be belong.

The table XCPERSTA

In the table XCPERSTA you define with the macro XCPERS to which group a person should be belong.

5.2. Identification by announcing to HOB COM

The announcing on HOB COM differs from the protocol that the user uses for the communication with HOB COM.

E-Protocol

An identification isn't necessary by announcing on HOB COM. In several HOB COM programs, e.g. STTE it is an identification necessary.

Y-Protocol

An identification is required by announcing on HOB COM. But there exists the possibility to deposit use-rid and password on the client so that an identification happens automatically. An identification of the user isn't necessary in any HOB COM program (like STTE, see above).

S-Protocol and X-Protocol

The system administrator has to define how the announcing on HOB COM take place. You find more information in the paragraph 6.11. LOGON MASK BY S- AND X-SCREENS- XCSYSCTL - on page 65.

6. TERMINAL CONTROL TABLE FOR HOBCOM

6.1. TABLE STRUCTURE

The Terminal-Control-Table is needed to manage the terminals under HOBCOM.

In addition to the terminal entries, it contains information on the HOBCOM printers and the different form definitions for print output.

The HOBCOM-XCTCT offers more comfort when using HOBCOM: you can enhance the layout of the HOBCOM opening panel, define abbreviations for the commands, and enter commands to automatically start and stop HOBCOM tasks.

The XCTCT consists of several individual tables and starts at the label XCTCTANF and the macro XTCTGEN.

Structure of the XTCTGEN macro:

XCTCTANF	XTCTGEN	ACBNAM=name,	X
		TERMA=XCTERMA,	X
		PRTAB=XCPRTAB,	X
		TEGRO=XCTEGRO,	X
		USSOUT=XCUSSOUT,	X
		USSCOM=XCUSSCOM,	X
		PRPAR=XCPRPAR,	X
		USSBTA=XCUSSBTA,	X
		PERSTA=XCPERSTA,	X
		JCLTAB=XCJCLTAB,	X
		LTKEY=password,	X
		UPNAM=XCUPNAM,	X
		COMASK=XCCOMASK,	X
		PASSW=XCPASSW	

This macro addresses the individual tables. If one or more of the tables is not to be used, omit the corresponding entry.

The meanings of the parameters are listed below:

ACBNAM=	ACB-Name for HOBCOM (1)
TERMA=	address of the terminal table (2)
TEGRO=	address of the terminalgroup table
PRTAB=	address of the printer table (3)
USSOUT=	address of the console mask (4)
USSCOM=	address of the console commands (5)
PRPAR=	address of the printer parameters (6)
USSBTA=	address of the batch task commands (7)
APPLTA=	address of the applications table
PERSTA=	address of the user entries (10)
JCLTAB=	address of the JCL table (11)
LTKEY=	address of the laptop password
UPNAM=	address of the exit routine
COMASK=	address of the HOBCOM operator commands (13)
PASSW=	address of the HOBCOM password

The numbers in paranthesis refer to error messages. With the given number, one can identify the erroneous parameter.

What each of the tables does, is described in the following chapters.

A standard TCT is supplied which may be modified if required. On the installation tape, it is located in the source library HOB COM.LIB1.

The XCTCT should be modified to meet your requirements, assembled and cataloged in the HOB COM library.

A DD statement for the MACLIB must be inserted in the Job for the compilation of the XCTCT. For example,

```
//      SYSLIB DD DSN=HOB COM.MACLIB, DISP=SHR
```

The name of the table is read when HOB COM is started. For example, if the table is called XCTCT, the following card will be read:

```
PHASE : XCTCT
```

The card is read from the file allocated to the label PARAM. No message is output, if no valid input was read or if the table could not be loaded.

As soon as the table has been successfully loaded, HOB COM acknowledges it with the following message:

```
XCM00005 PHASE XCTCT      LOADED
```

Dynamic re-loading is possible. For more information refer to the HOB COM Operator Guidelines.

In the appendix of this manual and on your installation tape in the HOB COM.LIB1 you will find a sample job for starting HOB COM.

6.2. THE ACB NAME FOR HOB COM

The default value for the ACB name is CODIS. If your ACB (access method control block) in VTAM is to be given a name other than CODIS, it can be entered in ACBNAME. The name may be up to eight characters in length. This ACB will be opened when HOB COM is started.

When you have entered a password for HOB COM special functions, among other things the ACB name will be compared in this password.

An example:

```
XCTCTANF XTCTGEN ACBNAM=HOB COM,          X
                TERMA=XCTERMA,            X
                .
                .
```

6.3. TABLE WITH TERMINAL ENTRIES - XCTERMA -

After the XCTERMA label, the E-Terminals and Token Ring Terminals names will be entered. These entries are necessary, so that the HOBCOM can tell which type terminal it is and which printer type is connected to which terminal. Any number of terminals can be defined at one time. The terminals are defined with the VCTCT macro.

The following entries are needed for E-Terminals (entries in paranthesis are optional):

XCTERMA	DS	OF	;ADDRESSES OF THE TERMINALS
	XCTCT	TERM=terminalname,	X
		PRINT=printertype,	X
		DISCON=YES,	X
		LASTTE=YES	

terminalname Any name 8 characters in length can be entered as terminal name. This name appears in the HOBCOM console as terminal name.

X'xxx' Enter the terminal address with which it was dedicated to the virtual machine. If remote terminals are to be defined, enter a channel number which does not exist. For different remote transmission lines, use different channel numbers, or construct a virtual control unit for each remote transmission line. Control units have up to 32 addresses beginning with 00, 20, 40, 60, 80 ... to E0.

printertype the printer type entry is 2 digit numeric and refers to the table containing the printer types starting at the label XCPRTAB. The last two settings of the printer type are to be entered here.

The 3270 terminals are defined with the macro XCTSTE:

XCTSTE	TERM=terminalname,	X
	FLAG=flag	

terminalname As terminal name enter the name that has been registered in VTAM for the real terminal.

flag The following etries are possible as flags:

OPT optimized data transmission

NOMDREAD modified fields are not read again, when the program questions them

FULLREAD sets up READ BUFFER (disadvantage: more data is send over the li-
nes)

i This entry is not necessary when the terminal logs on with a command that contains the parameter data(s).

3270 printers are defined with the help of the macro XCTPRI:

XCTPRI	TERM=terminalname,	X
	PRINT=0100	

terminalname as terminal name enter the name that is given in VTAM for the real printer.

0100 The print driver 100 is absolutely necessary at this time! ben!

The last terminal of the series (i.e. E-terminals, standard 3270 terminals and 3270 printers) is entered with LASTTE=YES.

Example:

```
XCTERMA DS      0F
        XCTCT   TERM=N01,PRINT=10
        XCTSTE  TERM=S01,FLAG=OPT
        XCTPRI  TERM=P01,PRINT=100
        XCTCT   TERM=N02,PRINT=06,LASTTE=YES
```

N0n and S01 are real terminal names and P01 is a printer name as defined in VTAM. You will find possible printer types for E-terminals in the following chapter.

The macros XCTLTM and XCTLTS are used for entering laptops:

```
XCTERMA DS      0F
        XCTLTM  TERM=X25T01L
        XCTLTM  TERM=X25T02L
        XCTLTM  TERM=X25T03L
        XCTLTS  TERM=LAPTOP01,PRINT=99
        XCTLTS  TERM=LAPTOP02,LTKEYP=AB,PRINT=09
        XCTLTS  TERM=LAPTOP03,PRINT=06
```

XCTLTM master entries for laptops = LU-Einträge in switched major node

XCTLTS slave entries for laptops = PSEUDO-LU name in PAD-Setup;

If someone should receive a personal laptop password, here you have the possibility to give the parameter LTKEYP. This parameter inverts the third byte and replaces the fourth byte of LTKEY.

Examples:

1. Neither the parameter LTKEY nor the parameter LTKEYP is set. In this case, the host password '00000000' must be entered in the laptop.
2. The parameter LTKEY is set, the parameter LTKEYP is not. Now the character chain that has been given as LTKEY has to be entered as host password.
3. The parameter LTKEY is not set, but the parameter LTKEYP is. In this case, the host password in the laptop must be set together as follows:

```
1st and 2nd byte  00 each
3rd Byte  FF (= 00 inverted)
4th Byte  LTKEYP
```

4. Both parameters are set. The host password in the laptop PC is set together as follows:

```
1st and 2nd byte  1st and 2nd byte of LTKEY
3rd Byte  3rd byte inverted from LTKEY
4th Byte  LTKEYP
```

Example (see above):

LTKEY=ABCD5678

3rd byte of LTKEY: 56 = 0101 0110,

inverted: 1010 1001 = A9

LTKEYP=AB

--> Host-Password: ABCDA9AB

6.4. TABLE WITH PRINTER TYPES - XCPRTAB -

The existing printer types can be found after the XCPRTAB label. These Entries remain unchanged. The following printer types are available:

<i>TCT-Entry</i>	<i>Printer Type</i>	<i>HOB Printer</i>
0006	Siemens	HOB 150 IP 200 IP
0007	Mannesmann	HOB 270 B 400 L
0008	Mannesmann	HOB 140 BC
0009	Epson, without graphics, feed 1/180 inch	look 0012
0010	HP Laser (also Mannesmann, Kyocera and Epson with HP emulation)	HOB 4 LP 6 LP 8 LP II resp. II D 8 LP III resp. III D 16 LP
0011	typewheel printer	HOB SM 13
0012	Epson, with Grafik, feed 1/180 inch (also Mannesmann and HP-Laser with Epson emulation)	HOB 220 MPQ 220 MP + resp. MP/2 + 270 F 275 MPQ resp. MPQ 2 350 MP 540 IP 550 IP 8 LP III(Epson emulation) 220 IP/2-EZ (NEC emulation)
0042	Epson, with graphics, feed in 1/216 inch (also Mannesmann, Kyocera and HP-Laser with HP-emulation)	120 180 20 1060 LC 6 LP (Epson emulation)
0049	Epson, without graphics, feed in in 1/216 inch	HOB 220 IP
0099	other printers	HOB 240 IP 450 B (with barcode module) 500 L

If you must add non existing printer drivers into your TCT (i.e. at changes of CODIS on HOB COM) you can find the necessary examples in the appendix.

In this table the Baudrate can be adjusted. All printer types are defined in the following form:

PRINTxx	EQU	*	
	DC	X'00xx'	PRINTER TYPE xx
	DC	X'0C'	BAUDRATE
	DC	X'00'	FREE
	DC	C'\$COP006'	NAME DRIVER PROGRAM

You can make a further entry with the wanted Baudrate when necessary. The terminal will then be adjusted to this Baudrate when turned on.

Following entries are for the diverse baudrates:

Entry	Baudrate
X'00'	110
X'02'	300
X'04'	600
X'06'	1200
X'08'	2400
X'0A'	4800
X'0C'	9600
X'0E'	19200

According to the Terminal, the number of the extra entered printer types is then to be entered under the XCTERMA label:

```
XCTERMA  XCTCT  TERM=TERM555 , PRINT=xx
```

The Driver 20

The Driver 20 manages the same printers as the driver 10. By this new driver instead of the ROMAN-8 font, the font PC-850 is used. It should always be used, when HP printer are used together with HOBLink 3270. HOBLink 3270 sends this driver as default.

In the HOB COM-TCT the driver should be registered as follows:

```
PRINT20      EQU      *                ;PRINTER-ART  20
              DC      X'0020'          ;PRINTER-ART  20
              DC      X'0E'             ;BAUD-RATE
              DC      X'00'             ;FREE
              DC      X'$COP0020'       ;DRIVER NAME
```

The Driver 100

It is possible, to adress a S - printer with a normal 3270 data stream from MVS-HOB COM. Prerequisite is a bind to VM HOB COM over TCP/IP. To do this, in MVS-HOB COM the driver \$COP0100 is linked.

In the XCTCT a driver by XCPRTAB is installed :

```
PPRI          EQU      *                ;PRINTER-ART 100
              DC      X'0100'          ;PRINTER-ART 100
              DC      X'0C'             ;BAUD-RATE
              DC      X'00'             ;FREE
              DC      X'$COP0100'       ;DRIVER NAME
```

An entry with the macro XCTPRI does not be made for the printer TN3270E - printer.

6.5. GROUP ENTRIES FOR TERMINALS - XCTEGRO -

The label XCTEGRO serves to define terminal groups.

When the XCTERMA table is opened, it is determined if a terminal belongs to a group, and if it does, to which group it belongs.

XCTERMA	DS	0F		;ADDRESSES OF TERMINALS	
	XCTCT		TERM=terminalname,ADDR=X'xxx' ,		X
			PRINT=printertyp ,		X
			GROUP=glabel-XCTEGRO		

The group name, the name of the terminal mask assigned to the group as well as the name of the appropriate command table are to be entered in the macro XCTEGRO:

XCTEGRO	DS	0F			
	DC	H'0'			
	DC	Y(XCTEGROE-XCTEGRO)		;LENGTH OF TABLE	
	XCTEGRO		LABEL=glabel,NAME=gruppe,USSOUT=gussout ,		X
			USSCOM=gusscom,COMASK=(operator-commands)		
			TIMEOUT=n,MASKP=n,PnCOM=usscom-command		
XCTEGROE	EQU	*			

glabel Group label
You can choose this name freely and is used in the macro XCTCT.

group group name
You can choose this name freely and is used in the macro XCPERS.

gussout name of corresponding console mask

gusscom name of corresponding command table

operator-commands additionally allowed operator commands (see p. 73)

For each group a basic mask and a set of command abbreviations can be defined. In addition, authorization for HOB COM operator commands can be extended on a group basis. If no such entries are made, HOB COM uses the standard definitions from XCUSSOUT and XCUSSCOM.

An example for a group entry with own group labels is in the appendix.

TIMEOUT=n n is a number between 1 sec. and 2 billion sec. (Hex value in one full word). When this parameter is used the sessions will be closed by HOB COM after n seconds when the connection is broken by the end device (HOBLink J-Term or HOBLink 3270), i.e. not normally close with the LOGOFF command. The value 0 is the default value, that means no timeout.

MASKP=n n=8 for P1
4 for P2
2 for P3
1 for P1

n is a flag (Bit) for a mask. The Bits can be combined as you like. The default value for n is 15. This mask controls which P keys are allowed.

If MASKP=8 is entered only P1 is allowed. Changing to P2, P3 and P4 is not possible then.

P1COM= These parameters specify, which commands
P2COM= or command abbreviations are performed automatically
P3COM= when this P key is pressed.
P4COM= This makes it possible to suppress that the HOB COM basic mask appears on this P key. When the user logs on the desired application appears immediately. You can enter a valid command abbreviation (the group was assigned to an USSCOM) or a command in one string.

Example:

```

XCTEGRO DS 0F
DC H'0'
DC Y(XCTEGROE-XCTEGRO) ;LENGTH OF TABLE
XCTEGRO LABEL=G1LABEL, X
NAME=GRUPPE1, X
USSOUT=G1USSOUT, X
USSCOM=G1USSCOM, X
TIMEOUT=120, X
MASKP=12, X
P1COM=TSO, X
P2COM='EXEC COVTC PA=CICS,SA=*,LOGM=D4C32792'
XCTEGRO LABEL=G2LABEL, X
NAME=GRUPPE2, X
USSOUT=G2USSOUT, X
USSCOM=G2USSCOM, X
TIMEOUT=60, X
MASKP=8, X
P1COM=TSO
XCTEGROE EQU *
```

With the help of the macro XCTCT terminals are assigned to a group, with the help of the macro XCPERS persons are assigned to a group. If a person belongs to a group, it is possible to suppress certain P keys by parameter of the macro XCTEGRO or it is possible to get with a certain P key immediately the application without showing the HOB COM-picture (USSCOM) or the session will be canceled after a certain if when the connection between host and pc is broken.

6.6. SCREEN LAYOUT - XCUSSTOUT -

If you wish, an output message (similar to a USSTAB) can be displayed on the HOB COM console. To do this entries in the VCTCT are necessary.

Starting at line 7 of the HOB COM console, you can define any screen layout you wish. One possibility is to list and explain the command abbreviations entered in the table after the label XCUSSTCOM.

Standard definitions are entered after the label XCUSSTOUT. You can change these to fit your needs. You may use all 256 byte values since the output is in HOB mode. The length of the output is contained in a half word, followed by the output message.

The standard TCT contains explanations of the command abbreviations inside a frame. This output message has a length of 7 screen lines. The length of this part of the mask is defined in a half word: 7 X 80 characters = 560 Bytes.

DC	AL2 (560)
----	-------------

Your own frame design may not exceed 14 screen lines (line 22 is reserved for data entry) - AL2(1120). The length of the mask determines how many lines of output messages you will be able to view on your screen. The more lines you have defined, the less you will be able to see of the output messages. If you wish to see the output messages, press the PF2 key. This removes your mask from the screen making the output messages visible; pressing PF3 returns your frame to the screen.

The following character definitions might be helpful to you, when you are designing a screen layout:

X'11' = upper left-hand corner
 X'1B' = horizontal line
 X'52' = upper right-hand corner
 X'56' = vertical line
 X'12' = lower left-hand corner
 X'53' = lower right-hand corner

In the appendix you will find a description of all signs available for the HOB modus.

6.7. TABLE WITH ABBREVIATIONS - XCUSSCOM -

After the label XCUSSCOM abbreviations can be defined. The abbreviations (similar to USSTAB) facilitate the invocation of HOB COM functions.

The commands are entered using the macro XCUSS.

XCUSS ABB=abbreviation, COM= 'command '	X
--	---

abbreviation enter the abbreviation here

command the command must always be entered in apostrophes. If you wish to use apostrophes in the command, you must enter two apostrophes.

The last command is followed by a byte containing X'FF' to indicate the end of the table.

Example:

XCUSSCOM EQU *	
XCUSS ABB=TSO ,	X
COM= 'EXEC COVTOP PA=TSO , PF , MOVSP , MSG= ' 'ABCD' ' '	
XCUSS ABB=CICS ,	X
COM= 'EXEC COVTC PA=CICS1 , PF , INV '	
DC X'FF'	

Command abbreviations can now be used in the ground mask. The entire command will be shown when the PF4 key is pushed instead of the Data release key.

6.8. TABLE WITH PRINTER FORM DEFINITIONS - XCPRPAR -

The printer/form definitions are entered after the label XCPRPAR. By specifying the appropriate parameter when invoking the print program (NOTE, PRVM), you may use any print form when printing on a HOB COM printer.

The following parameters are currently entered in the table:

a) generally valid printer parameters:

FORM1	36 lines/page and 12 characters/inch (96 and 158 characters per line, respectively)
FORM2	36 lines/page and 10 characters/inch (80 and 132 characters per line, respectively)
FSP10	72 lines/page and 10 characters/inch (80 and 132 characters per line, respectively)
FSP10H	72 lines/page and 10 characters/inch (80 and 132 characters per line, respectively) and "hex feature", that means that hexadecimal characters can be passed to the printer.
FSP17	72 lines/page and 17 characters per inch (132 and 217 characters per line, respectively)

b) Special parameters for the HOB 8 LP:

LASEREL	elite type
LASERLP	line printer type
LASERCU	italic type
FQUERT1	DIN A4 horizontal line printer type

c) Special parameters for the HOB 8 LP2 and the HOB 8 LPEZ2

HOBELITE	elite type
HOB LP	line printer type
HOB CU	italic type
FQUERT1	DIN A4 horizontal line printer type
FQUERT2	DIN A4 horizontal courier type
GOTHIC	Gothic
GOTHICCU	Gothic italic type
COURIER	Courier type

p) Special parameters for 3270 printer

3270Q	A4 (sized) paper (297 x 210mm), horizontal format, 17 signs / inch
3270H	A4 (sized) paper (297 x 210mm), vertical format, 12 signs / inch

Definition of further parameters:

You can create print parameters to implement forms to suit your own needs.

A print parameter is a character string with the following structure:

1 Half word length of the entire parameter

8 bytes parameter name

1 Byte length of the following print record

n Bytes print record

1 Byte length of the following print record

n Bytes print record

.

.

etc.

A print parameter can also be created using the macros XPRPDEF or XCFOR:

Macro XPRPDEF:

```
XPRPDEF  NAME=name, ( SPACING=nn, ) ( LPP=nn, ) ( FEATURE=HEX, ) X
          ( LABEND=label )
```

NAME enter the name of the print parameter here. The name may be up to 8 characters in length.

SPACING the number of characters per inch is to be entered here. The default value is 12. LPP enter the number of lines per page here. This value is not passed to the printer, but rather serves as a HOBCOM internal counter. The default value is 72.

FEATURE if you specify FEATURE=HEX here, the two characters following X'5F' are interpreted as hexadecimal values. This entry is useful, when you want to send control characters to the printer.

LABEND a label can be entered here, as long as entries for the current print parameters follow the Macro XPRPDEF. These entries must be made as DC (define constant) statements.

If you wish to make additional entries, use the macro XCFOR. A print parameter can be entered using the macro XCFOR, if it consists of only one print statement. Otherwise, the individual strings must be defined using DC (define constant) statements (see the examples at the end of this chapter).

Macro XCFOR:

```
XCFOR  ABB=name, PAR=print_record
```

name enter the name of the print parameter here; the name may be up to eight characters in length.

print_record enter the character string of the print record here. (The structure of a print record is described below.)

Structure of a Print Record:

The first byte of a print record contains the feed byte. All values between X'00' and X'7F' (0 to 127) are interpreted as the number of line feeds to be made before the first line is printed.

X'00' = print without line feed

X'01' = print with normal line feed

X'05' = print with 5 blank lines between printed lines

All values between X'80' and X'FF' (128 to 255) have special functions:

X'80' = a page feed occurs before printing starts

X'81' = indicates that attributes are to be passed on for the following lines. Attributes can be set for each character.

The following attributes can be evaluated by the printer:

X'40' = shadow print: the characters are printed in shadow mode

(displayed on the screen as extra bright characters)

X'20' = bold overprint: the characters are printed as italics

(displayed as reverse video on the screen)

X'10' = underscore print: the characters are underlined

(also displayed on the screen as underlined characters)

You can combine the attribute bits as you wish. The printer driver routine evaluates the attributes accordingly. For example, if you specify X'50', the characters will be printed in shadow print and underlined.

X'83' = indicates that alpha characters with horizontal feed follow.

Alpha characters 40H and greater are printed without horizontal feed.

The feed is represented by the values 1 to 63 X'01' to X'3F' which indicate multiples of 1/12th of an inch. The byte X'00' is followed by an attribute which is valid until the next attribute parameter is encountered (see above for attribute structure). A special attribute record (feed X'81') may not be specified for such a record.

- X'8C' = the following half word (2 bytes) is interpreted as the number of the paper cassette or paper bin for printers with 2 sheet feeders or more.
- X'8D' = the following half word is interpreted as a feed. The value is specified as a multiple of 1/48th of an inch. When the next page feed takes place, the correct positioning at the beginning of the page takes place.
- X'8E' = a feed to the end of the current page takes place. If a page feed follows, it is ignored.
X'8F' = all stored lines which have not yet been output are printed. The data record after the feed byte is ignored.
- X'8F' = all saved, not printed records will be printed. The record after the feed byte are ignored
- X'90' = the characters following this value are sent directly to the printer without be evaluated. This allows you to specify control characters for your printer.
- X'A0' = the following half word (2 bytes) will be evaluated as shaft nummer (two page entry)
- X'A1' = The following characters will be exchanged at printing. This way, a german character can be exchanged for a french character or for a graphic character.

Example:

X'A1DB65CB626A9052B5D0B0C0B3'

DB is exchanged with 65, CB with 62, 6A with 90 etc. These values refer to the EBCDIC character set; they are interpreted by the driver once more and are changed into an ASCII character for the printer.

If you want to use this option, please contact the HOB Software

Support and ask for the translation tables.

- X'A3' = This control sign enables the addressing of a form parameter from the TCT. If, for example, the print use invokes the formparameter 'DRTEST', a print line with the contents ^: ^A3DRTEST must be sent. Hex feature must be set for this.
- X'A4' = Translation table EBCDIC into ASCII, follows pairs of 2 Bytes, that determine the character to be translated and the character in which will be translated. (EBCDIC into ASCII-characters).
^: ^A4^C1^41^C2^42^;
The character A will be translated into hexa 41 and the character B into hexa 42.
The text ABCD becomes the text hexa 4142 CD.
- X'A5' = output long line
it is possible that more than one dataset X'A5' (mixed with X'90') follows, which will be output without attribut interpretation or carriage return. The characters will be interpreted as EBCDIC.
- X'E0' = acoustic alert at the printer. the next byte determines the number of alert signals at the printer (1 to 255, length of the alert signal)
- X'FD' = This control sign enables the following in connection with a second Byte: a) a comparison of the printer name out of the printer program invoke with a given printer name --> X'FDOO'

b) a comparison of the terminal driver out of the printer program invokes with the given driver --> X'FD01'

The following print directions will only be given in agreement.

Example:

DC	AL1 (PPFOR32B-PPFOR32A)	; LENGTH
PPFOR32A EQU	*	; BEGIN OF LINE
DC	X'FD00'	; CONDITION DRIVER
DC	X'001000'	; DRIVER (10)
DC	X'01'	; FEED
PPFOR32B EQU	*	; END

The feed only happens, when for the terminal, on which the chosen printer is attached to, driver 10 (for laserprinter) is entered.

X'FE' =	this feed byte contains the same values as X'FF', however, only the parameters which were previously set are changed. This indicator can also be specified in a text, if a parameter with hex feature is used. LPP, lines per page, and VMI, vertical motion index, may not be changed. e.g: ^^:^^FE^^13^^0A^^ sets the left margin to the 10th column
X'FF' =	printer adjustment parameters can be passed in this data record. These values are converted by HOB COM to the printer specific control characters. They are also used as HOB COM internal counters. A data record consists of individual parameters which in turn consist of a parameter character (one byte) and a parameter value. The following parameter indicators are in use:
X'02' =	feature code, specified in 2 bytes. 2000 = No Graphic mode. This entry is valid for HOB printers with graphic capabilities, e.g. the HOB 8 LP and the HOB 150 IP. This entry is necessary, if no graphic characters are to be printed and if values which indicate the size of the print (for example, horizontal spacing, vertical motion index) are set differently for HOB COM and for the printer.
4000 =	blank page suppression, this means that the printer issues no page feed, if it is already in the first line
8000 =	Hex Feature, means that the two characters following X'5H' are interpreted as hexadecimal values. In order to specify several features, values are added. For example, C000 = 4000 (empty page suppression) + 8000 (Hex-Feature)
X'10' =	copy count, the number of copies the user wants (including the original) is specified in one byte. The default value is 1.
X'11' =	LPP (lines per page). The number of lines per page are specified as a binary number in a half word (0 to 32,000). This value is not passed to the printer, instead it is used as an internal program counter. The default value is 72. If LPP=0 is specified, the program sends a page feed without the logic. If LPP=1 is specified, the program does not send its own page feed.
X'12' =	ZES, is the line number of the first line of each new page. The line number follows as a binary number in a half word. The program sends several line feeds when it encounters a page feed. The default value is 0.
X'13' =	PP (Print Position), is the number of blanks inserted before each line is printed. The default value is 0.
X'14' =	VMI, vertical motion index. Indicates the length of a line feed in multiples of 1/48th of an inch. The parameter is specified as a binary value in one byte (0 to 255).
X'15' =	SPA (Spacing), width of a printed character. The number of characters which are to be printed in one inch are specified in one byte. The default value is 12.
X'16' =	LEN, maximum length of a printed line. The number of characters which are to be printed in one line is specified in one byte as a binary number. Characters above this are truncated. Special case: LEN=0, this indicates that the maximum length is not tested.

A list of some of the feed bytes

00 bis 7F =	data record, number of line feeds
80	= data record with line feed
81	= attribute
83	= data with variable feed
8D	= extra feed
8E	= advance to end of page
8F	= print buffer

90 = printer character without translation
 E0 = accoustic alarm
 FE = change parameter
 FF = reset parameter

Examples:

1) A form with 80 characters per line, 36 lines per page and a line at the end of the form:

```
XPRPDEF NAME=FORM2, LABEND=PPFORM2E, LPP=36, SPACING=10
      DC      AL1(81)          Length of nearest print_record
      DC      X'06'            Feed
      DC      80C'-'          Separation line
      DC      AL1(2)           Length of next print_record
      DC      X'0140'          Feed
PPFORM2E EQU      *
```

2) Hex values can be passed to the printer, in order to be able to use special functions. 80 characters per line are to be output:

```
XPRPDEF NAME=FSP10H, FEATURE=HEX, SPACING=10
```

or

```
XCFOR ABB=FSP10H, PAR=FF028000150A
```

3) 80 is to be the maximum line length and 24 lines per page are to be printed:

```
XCFOR ABB=LEN80, PAR=FF1650110018
```

6.9. TABLE WITH BATCH TASK COMMANDS - XCUSBT -

The batch task commands for automatically starting and stopping tasks are entered after the label XCUSBT. This allows to start a task automatically as soon as a screen is switched on or off respectively a connection of a end device to HOB COM. Beyond it is the starting of tasks not possible when you start HOB COM.

The commands are entered by using the macro XCUBT:

XCUBT TERM=terminalname ,	X
TASK=taskname ,	X
SYSTEM=YES/NO ,	X
CO=YES/NO ,	X
COM= ' command '	

or

XCUBT TERM=terminalname ,	X
TASK=taskname ,	X
TERMSTA=YES/NO ,	X
TASKSTA=YES/NO ,	X
CO=YES/NO ,	X
COM= ' command '	

or

XCUBT TASK=taskname ,	X
PERSNO=personalnumber ,	X
BTPRI=YES/NO ,	X
COM= ' command '	

TERM= terminalname

Name of the real terminal as entered after the label XCTERMA. This name with the maximum length of eight characters is simultaneously the name of the task if no other name is entered with the parameter TASK=.

TASK= taskname

Any name with a maximum length of 8 characters can be entered as task name. If you do not enter a name here, HOB COM uses the name that is specified under TERM= as taskname. You only have to define this parameter when several tasks from one screen should be started.

CO= YES/NO
CO=YES

When this parameter is set you are allowed to feed exclusive HOB COM commands by COM= respectively BAT-ON, OPEN (see below). The input of batch task commands aren't possible.

The parameter TASK= can't be used if CO= is set YES.
CO=NO

This is the default value.

If CO= is set NO you can declare a batch task command which starts a task by COM=.

Examples: EXEC, SHUTDOWN, CANCEL, LOGON, SET PARAM.

COM=	<p>'command'</p> <p>Declare a HOB COM command or a batch task command. Note, that the parameter CO= appropriate.</p> <p>You can order the starting or ending of a batch programm with the commands EXEC or SHUTDOWN. The command must always be enclosed in apostrophes.</p> <p>HOB COM operator commands can't be specified!</p>
SYSTEM=	<p>YES/NO</p> <p>SYSTEM=YES</p> <p>With this parameter, the batch task can be immediately started when the HOB COM is activated on. This excludes the parameter TERMSTA= and TASKSTA=!</p> <p>SYSTEM=NO</p> <p>This is the default value. The stated task won't be started by activating HOB COM.</p>
TERMSTA=	<p>YES/NO</p> <p>This parameter defines when the command stated by the parameter COM= will be executed</p> <p>TERMSTA=YES</p> <p>This is the default value. The command is executed if the screen is switched on respectively by connecting the end device to HOB COM</p> <p>TERMSTA=NO</p> <p>The command is executed if the screen is switched of respectively by the input of the command "LOGOFF" in the HOB COM basic mask.</p> <p>The parameter TERMSTA= shouldn't be used simultaneously with the parameter SYSTEM=!</p>
TASKSTA=	<p>YES/NO</p> <p>This parameter indicates if a task is to be started, if it does not yet exist.</p> <p>TASKSTA=YES</p> <p>The command is also executed if no task is existing. In this case the task is started. This is the default value.</p> <p>TASKSTA=NO</p> <p>The command will only be executed, if the task already exists.</p> <p>The parameter TASKSTA= shouldn't be used simultaneously with the parameter SYSTEM=!</p>
BTPRI=	<p>YES/NO</p> <p>BTPRI=YES</p> <p>results that the terminal name is saved which the task has started. That can be a name respectively created from HOB COM. If respectively HOBLINK 3270 or HOBLINK J-Term are started without a resource name, TN\$nnnn is created as terminal name ;nnnn is a continuous number with the maximum length of four characters.</p> <p>BTPRI=NO</p> <p>is the default value.</p> <p>If NO is set HOB COM „forgets" immediately after starting the task which terminal caused the starting of the task.</p>

Example:

predetermined which terminal name in HOB COM is created for that)
it can be started with the personal number.

XCPERS NO=00000055 ,TYPE=P ,	X
NAME=MUELLER ,PW=PASSWORD ,	X
ENKEY=Key ,ENFULL=YES ,	X
COMASK=(TEXT ,CP ,SHU ,CAN ,DISC ,FILE ,TCTL ,STTE)	
.	
.	
.	
XCUBT TASK=HUGO ,PERSNO=00000055 ,	X
COM=' EXEC PR3287..... '	X

The task HUGO is started when a person MUELLER logs on HOB COM.

Example:

XCUSBT A DS 0F	
XCUBT TERM=N01 ,TASK=PRINT1 ,	X
COM=' EXEC PR3287 PA=CICS ,SA=N01P ,PRINTER=N01 ,PARAM=FSX P17 '	
XCUBT TERM=N01 ,TASK=PRINT1 ,	X
TERMSTA=NO ,	X
TASKSTA=NO ,	X
COM=' SHUTDOWN '	

Please note that there may be no blanks between the parameters at command invoke. This danger exists especially with continuous lines (write through to X).

Besides, certain parameters can be set or changed with the help of the COBA program even after starting the task, i.e. through the command „SET PARAM=fsp10h“, „LOGON PAPPL=...“ or „SET PARAM=...PAPPL...“. More information for this you'll find in the paragraphs of the corresponding batch programs in the HOB COM manual.

Command invokes can also be divided. This is a special advantage when batch tasks have to be newly started with the help of „BAT ON ALL“ (see HOB COM operator commands) because of a CICS

Example:

XCUBT TERM=N01,TASK=PRINT1,	X
COM='EXEC PR3287 SA=N01P,PRINTER=N01P,PRINTER=N01,PARX	
AM=FSP10H	
XCUBT TERM=N01,TASK=PRINT1,TASKSTA=NO	X
COM='LOGON PA=CICS'	
XCUBT TERM=N01,TASK=PRINT1,	X
TERMSTA=NO,	X
TASKSTA=NO,	X
COM='SHUTDOWN'	

The 3287 program invoke and logging onto CICS happen automatically when the terminal is turned on, and the SHUTDOWN command becomes effective when the terminal is turned off.

6.10. PERSONAL ENTRIES - XCPERSTA -

These entries are only necessary when HOBTEXT, HOBLIST or STTE is used.

XCPERS	NO=number,TYPE=type,NAME=name,PW=password,	X
	ENKEY=key,ENFULL=value	X
	GROUP=groupno,PROFD1=mainfolder name,	X
	PROFD2=ordnername,PROFD5=textname,	X
	MAILID1=mainfoldername,MAILID2=foldername,	X
	MAILOD1=mainfoldername,MAILOD2=foldername,	X
	COMASK=(commands)	

- NO= the personnel number of the user you wish to enter. This can be any 8 digit number of your choice.
- TYPE= the type of user entry is indicated here. Person and group entries are possible:
P=person, g=group.
- NAME= enter the name of the user here; the entry may be up to 16 characters long.
- PW= the user's password must be entered here. The password may be up to 8 alphanumeric characters in length. getragen werden.

The following entries have a meaning only for HOBTEXT and HOBLIST:

- GROUP= the name of the group to which the user belongs can be entered here. The group name may be up to 8 characters in length.
- PROFD1= specifies the cabinet name of the user's profile
- PROFD2= specifies the binder name of the user's profile
- PROFD3= specifies the text name of the user's profile

The following entries have a meaning only for HOBTEXT:

- MAILID1= specifies the cabinet name of the user's mail entry.
- MAILID2= specifies the binder name of the user's mail outlet.
- MAILOD1= specifies the cabinet name of the user's mail entry.
- MAILOD2= specifies the binder name of the user's mail outlet.
- COMASK= gives the authorization for certain HOB COM Operator Commands; possible commands are: SHU, CAN, DISC, FILE, TCTL, TEXT, CP

Please note that every group in HOBTEXT and HOBLIST also has to be registered. The necessary statements are NO=group_number, TYPE=G and NAME=group_name!

6.11. LOGON MASK BY S- AND X-SCREENS- XCSYSCTL -

In the table XCSYSCTL you define how the announcement on HOB COM happens when user logon with a X- or S-Screen (repectively emulation) on HOB COM.

In the table XCSYSCTL the macro XCSYSCTL is called:

XCSYSCTL	DS	0F
XCSYSCTL	PERSEXA=	YES/NO

PERSEXA=

YES/NO

With the parameter PERSEXA= you define how user of terminals or terminal emulations logon on HOB COM when the communication happens over the S- or X-Protocol.

YES

When the user logon they receive a logon mask where they have to state user-id and password. If RACF is in use it checks the input before the connection with HOB COM takes place.

NO

The user don't have to identify and authorize by logon. This is the default value.

S- and X-Sessions can be allocated to a group over a personal entry. This assignment happens personal not related to the ressource -id. (terminalname).

When a person logs on a LU (e.g. a terminal with S- or X-Protocol or a HOBLINK 3270/J-Term with Y-Protocol) that belongs to a group so the **LU** is allocated to this group.

i

When this person logs off and afterwards an other person **without a membership of a group** logs on at the same LU so the (second) person is allocated to the same group the first person belongs to.

Exceptions:

1. S-terminals respectively emulations that communicate with HOB COM through S-Protocol. In this case the second person belongs to the default-group (XCUSOUT; XCUSCOM).
2. Belongs the second person (independent of the protocol) to a group so the person gets the own group.

More information about the assignment of persons or LU's to groups you'll find in the paragraph „group

6.12. JCL-ENTRIES - XCJCLTAB -

Data can be designated Job-Cards in this table, that will be worked over later. They are used by different driver routines.

From the XCJCLTAB label on, three macros can be used that determine the name of the JCL and eventual necessary additional information: XCJCL1, XCJCL2 and XCJCL3.

Using the macro XCJCL1 first the name of the JCL (NAME=), a target machine (USER=) and a class (CLASS=) or a Tag (TAG=) are entered.

```
XCJCLTAB DS      0F
          XCJCL1 NAME=name,USER=targetmachine,CLASS=class
```

NNAME= Here you enter a freely chosen name. This name may be up to 8 characters long. This entry will be shown connected with a driver program (as part of the name) when invoked. Example: OUTFILE=\$PUN.PRINT.name

USER= enter the name of the virtual machine, to which the data which has been read is to be spooled.

CLASS= enter the class under which the read data is to be spooled Afterwards, starting- and end-control cards for the data will be entered with help of the XCJCL1A and XCJCL1E macros that, i.e. should be transmitted from a HOBCOM driver program and must yet be worked on according to these control cards. These macros can occur several times per JCL entry and are also allowed with the XCJCL2 macro.

Use the macro XCJCL1A to define the control cards that are to be placed at the beginning of the read data. You can define several XCJCL1A macros.

```
XCJCL1A LINE='text'
```

LINE= enter a JCL card enclosed in apostrophes which is to be placed at the beginning of the data which is to be read.

Use the macro XCJCL1E to define the control card that is to be placed at the end of the data which is to be read. Several XCJCL1E macros may be defined.

```
XCJCL1E LINE='text'
```

LINE= enter a JCL card enclosed in apostrophes which is to be placed at the end of the data to be read.

Use the macro XCJCL1E without parameters to close a JCL definition.

Example:

```

XCJCLTAB DS      0F
          XCJCL1 NAME=TESTJCL,USER=VSE1,CLASS=A
          XCJCL1LA LINE=' * $$ JOB JN=JOB1,DISP=D,CLASS=A '
          XCJCL1LA LINE=' * $$ LST DISP=D,CLASS=C,DEST=(,USER) '
          XCJCL1LA LINE=' * $$ PUN DISP=I,CLASS=A,PRI=6
          XCJCL1LE LINE=' / * '
          XCJCL1LE LINE=' // EXEC LNKEDT '
          XCJCL1LE LINE=' / & '
          XCJCL1LE LINE=' / * '
          XCJCL1E
*
          DC      AL2 (0)

```

This way, the job JOB1 is set into the POWER of the VSE machine HOBTT14 and starts according to the powerclass A. This JCL is spoken to with the name TESTJCL.

The Macro XCJCL2 determines the name of the JCL (NAME=). Afterwards different macros can be used: XCJCL2, XCJCL2J, XCJCL2E, XCJCL1LA and XCJCL1LE.

DC X'...' optional entry: text blocks for Dynaloc. These blocks are defined according to the manual 'OS/VS2 MVS System Programming Library: Job Management'. After the XCJCL2 macro, several text blocks may be given. If the HOB COM program, that this JCL speaks to doesn't need text blocks, these will be ignored.

XCJCL2J This macro ends text blocks. It must always be given, even when no text blocks have been defined.

XCJCL1A LINE= '...' The lines given with this macro will be given at the start of the output. Lines with XCJCL1A must not be present.

XCJCL1E LINE= '...' Lines given with this macro will be given at the end of the output. A macro XCJCL1E also ends the output at the start, no other macros may follow XCJCL1A after the first macro XCJCL1E. Lines with XCJCL1E must not be present. blocksatz aus

XCJCL2E A JCL entry is ended with this macro. The macro XCJCL2E must be defined at the end of every JCL entry.

Examples:

1. The data output should result to SYSOUT=A. At the start of the output, i.e. before the actual data, a SYSOUT-A-START line and at the end, i.e. after the actual data, the SYSOUT-A-END line should be put out.

```

XCJCL2 NAME=SYS0-A
DC      X'001800010001C1' ;SYSOUT=A
XCJCL2J
XCJCL1LA LINE=' SYSOUT-A-BEGINNING '
XCJCL1LE LINE=' SYSOUT-A-END '
XCJCL2E

```

2. A HOB COM program reads data, that shall be processed by LKED (or another program). The needed JCL is stored under the name RDR-JCL1.

```
XCJCL2 NAME=RDR-JCL1
```

```

XCJCL2J
XCJCL1LA LINE='//LKED JOB 1,MD,CLASS=A'
XCJCL1LA LINE='//LKED EXEC LKED'
XCJCL1LA LINE='//LKED.SYSLMOD DD DSN=... '
XCJCL1LA LINE='//LKED.SYSIN DD *'
XCJCL1LE LINE=' NAME=TEST(R) '
XCJCL1LE LINE='// '
XCJCL2E

```

The macro XCJCL3 can be used to send print output on disk. Please note, that we do not offer a program yet, that sends the stored print output from disk to printer!

```

XCJCLTAB DS      0F
XCJCL3 NAME=name,DISP=H,CLASS=F,PRI=7,SPFIL3=TSP#

```

- NAME= As name enter a freely choosen, maximal 8 digit string; we suggest \$SPOOL!
- DISP= The disposition is not evaluated at the moment. This entry becomes meaningful when a program is available, that sends a file from disk to the printer.
- CLASS= The class is not evaluated at the moment. This entry becomes meaningful when a program is available, that sends a file from disk to the printer.
- PRI= The printer is not evaluated at the moment. This entry becomes meaningful when a program is available, that sends a file from disk to the printer.
- SPFIL1 name of the cabinet, in which the file is stored
- SPFIL3 specifies the name under which the file will be stored in the archives (in the above example TSP plus a sequential number).

To end the JCL table the last two bytes must contain zeros (DC AL2(0)).

6.13. PASSWORD FOR LAPTOPS - LTKEY -

If you wish to prevent that unauthorized machines make contact with your Host while using a laptop, you can enter a maximally 8 digit password after LTKEY=. If you wish to relinquish the password protection, enter zero. The password must be entered into the PADSETUP of the Laptop in the HOST PASSWORD field.

XCTCTANF	XTCTGEN	ACBNAM=HOB COM,	X
		TERMA=XCTERMA,	X
		PRTAB=XCPRTAB,	X
		USSOUT=XCUSSOUT,	X
		USSCOM=XCUSSCOM,	X
		PRPAR=XCPRPAR,	X
		USSBTA=XCUSSBTA,	X
		PERSTA=XCPERSTA,	X
		DIANAM=XCDIANAM	X
		COMASK=XCCOMASK,	X
		LTKEY=ABCD5678,	X
		PASSW=XCPASSW	

*	ENTRIES OF TERMINALS		
	.		
	.		

If someone should receive a personal laptop password, you may enter the parameter LTKEYP in the terminal table (XCTERMA). This parameter inverts the third Byte and replaces the fourth Byte of LTKEY.

You will find examples in chapter 3.3.

6.14. EXIT ROUTINE - XCUPNAM -

UPNAM is an EXIT-routine to enter individual routines in HOBCOM, i.e. to generate the LU-names or to reserve programs for certain users or terminals. You can, for example, also achieve that your own SAPPL-name is used at invoking the COVTC program.



This interface should only be used by practiced system programmers, since HOBCOM and its own data could be destroyed through unauthorized useage with this exit.

This interface should only be used by practiced system programmers, since HOBCOM and its own data could be destroyed through unauthorized useage with this exit.

At jumping into a subprogram and back into HOBCOM the conventions used by IBM must be followed! The most important condition is the saving and later on the reloading of the registers!

After invoking your program Register 15 points to your program! On displacement 0 you find the length of your program in a halfword, displacement 2 shows the beginning of your program.

Register 1 points on the parameters:

Displacement 0:

00 = Enter

FF = Exit

Displacement 1:

20 = print program

40 = remote program

80 = VTAM program

REVM AND COAPPCVT use 40

COVTC AND COVTOP use 80

PR3770 AND PR3287 use A0 (80+20)

Displacement 4:

address TS\$USER (in TS\$BLOCK*+) of the running task in a full word

Displacement 8:

at entering: entered SAPPL (length 8) at exit: delivered SAPPL

Displacement 16:

output generated by the system due to the terminal name (SAPPL, length 8, only at entering)

Displacement 24:

output target given by the user (PAPPL)

Register 13 points to the HOBCOM SA\$BLOCK . This owns a save area in the first 72 bytes in which you can save the registers. The programm will be stored in SA\$UPNAM; the program lenght stands in the first half word.

SA\$UPNAT may be used freely, i.e. to enter the address of an ordered storage.

These two HOBCOM system blockshare described in the macro XCTDEF.

Register 14 contains the address for jump back.

Register 0 and register 2 to register 12 are unpredictable and therefore their contents cannot be used. But they must be secured so that they are available to HOB COM for backjumping.

In register 15 the return code from your program is transferred at backjumping; is it unequal zero the register points to your own error message, that is then put out by HOB COM (i.e. in program CO-APPCVT: ERROR COAVT005 EXIT-R here follows the message).

Storage-Request

When you need storage, you must jump into a routine whose beginning address is in field SA\$STGET, SA\$STGP or SA\$STGHP (Storage Get).

SA\$STGET = normal storage, i.e. storage will be soon accessible again SA\$STGP = permanent storage, i.e. storage will be accessible at a much later time

SA\$STGHP = high priority storage, i.e. only short pieces of storage should be asked for that are always needed by the system

The registers are used as follows:

R13 addresses the SA\$BLOCK

R12 contains the length of the desired storage at jump-in. The length must be divisible by 4 (full words). The address of the reserved storage will be reported back.

R14 contains the jump-back address

R15 contains the jump-in address (SA\$STGET or SA\$STGP, SA\$STGHP)

The registers R00 and R01 may be changed, all other registers remain unchanged.

Should this storage be freed again, you must jump into a routine whose beginning address is stored in the field SA\$STFRE (Storage Free). It makes no difference with which routine the storage has been requested.

The registers are used as follows:

R13 addresses the SA\$BLOCK

R12 contains the storage address that should be freed at jump-in. Exactly this address must first have been transferred at getting storage (SA\$STGET).

R14 contains the jump-back address

R15 contains the jump-in address (SA\$STFRE)

The registers R00 and R01 may be changed, all other registers remain unchanged.

Transfer of Date and Time

If date or time should be asked for, a routine will be jumped to whose beginning address is stored in field SA\$RDATE.

The registers are used as follows:

R13 addresses SA\$BLOCK

R12 contains the date at jump-back

R11 contains the time at jump-back

R14 contains the jump-back address

R15 contains the jump-in address (SA\$WAITE)

Date and time will be given in european format, packed with an additional zero in front of the prefix = constant OC.

The registers R00 and R01 can be changed, all other registers remain unchanged.

Example: The call is performed on 05.11.86 at 18.06.20.

the first system parameter (RSP1) contains hexa: 0511860C

the second system parameter (RSP2) contains hexa: 1806200C

Output of a Message on the System Console

If a message should be output on the system console, first the routine is jumped to whose address is stored in field SA\$DISP1. With this invoke the address of a display storage is transmitted in which a maximal 64 byte long output message can be set up.

After that another invoke is done with BALR R14,R15, whereby the message is given out.

When Zero is given as address at the first invoke, the first output of messages is not wanted and the second invoke must not be performed.

When a valid address is given at the first invoke, then this 64 bytes large storage is pre-initialized with blanks.

The registers are used as follows:

R13 addresses the SA\$BLOCK

R12 contains the address of the 64 Byte long display field or zero at jump-back

R14 contains the jump-back address

R15 contains the jump-in address (SA\$DISP1) or after the first invoke the address of the second invoke.

The registers R00 and R01 can be changed, all other registers remain unchanged.

Example (output of a message):

L	R15,SA\$DISP1;ADDRESS DISPLAY ROUTINE 1
BALR	R14,R15 ;GET DISPLAY FIELD
LTR	RSP1,RSP1 ;SOMETHING TO PUT OUT ?
BZ	PDENDE ; NO
MVC	0(20,RSP1),=C'THIS IS THE MESSAGE' ;TEXT
BALR	R14,R15 ;DISPLAY MESSAGE
PDENDE	DS 0H ;GO ON

The following operations are strictly prohibited



- usage of relative address constants
- overwriting the HOBCOM storage
- time dependent operations (i.e. disk access, setting the timer)

- change the program and then reloading the TCT while HOB COM is operating

An example for the use of the UPNAM macro is contained in your TCT. It appoints LU address out of a pool. A printout of these routine is in the appendix of this manual.

6.15. AUTHORIZATION FOR HOB COM OPERATOR COMMANDS -XCCOMASK -

Beginning at the label XCCOMASK you can define authorizations for the use of HOB COM operator commands (consult the HOB COM User's Manual for a more detailed description of the operator commands). To do this the macro XCOP must be invoked twice.

The first time XCOP is invoked, the commands which can be entered from the console are determined; the second invocation determines the commands which can be entered from any HOB E terminal.

Structure of the macro:

XCOP	DIS= (YES / NO) , SHU= (YES / NO) , CP= (YES / NO) ,	X
	CAN= (YES / NO) , DISC= (YES / NO) ,	X
	FILE= (YES / NO) , TCTLOAD= (YES / NO)	

Each parameter determines the authorization for a certain command:

DIS = DISPLAY commands are allowed

SHU = the SHUTDOWN command to end HOB COM is allowed

CP = CP commands may be entered

CAN = the CANCEL command to end any HOB COM task is allowed

DISC = the command to disconnect a HOB COM task is allowed

FILE = the operator commands for word processing, OPEN, CLOSE and ACT-DIR, and the general operator commands BAT-ON TERM=xyz or BAT-OFF TERM=xyz are allowed

TCTLOAD = the command to reload a VCTCT is allowed

The default value for each command is YES. This means that if you invoke XCOP without specifying parameters, all commands will be allowed. The commands which are suppressed here can, however, be authorized for individual terminal groups (see Chapter 5.5, parameter COMASK= in the macro XCTE-GRO).

Consult the HOB publication "HOB COM USER'S MANUAL" for the meaning of the commands.

6.16. HOB COM SCREENMASK

With the function „Screen Mask“ it is possible in HOB COM to prepare input like LOGON procedures. This function is especially useful for logon over RACF through PASSTICKET.

With the help of Screen Mask you can query certain screen contents (or parts of it) in the TCT and corresponding to the picture you can order certain input.

Not only characters in the screen display can be checked but also attributes. As further criteria a special register is available for certain automatically input.

Every Screen Mask has a name length of eight byte in the HOBCOM TCT. Inside a Screen Mask entry several screen contents can be described that means you can switch through several masks. If the description fits on a present screen the fields can be filled and an application can be sent.

Tip:

For a better using of RACF passticket the application HOBCOM has to be particularly authorized that means it has to be catalogized with SETCOD AC(1) in an authorized library.

Besides the RACF interface in HOBCOM has to be activated per ZAP.

The person who wants to logon has to be defined in the HOBCOM-TCT with XCPERS. Instead of the parameter PW= the parameter USER= is stated.

6.16.1. Installation of Screen Mask

- a) SMD\$BLOK is tendered for one's resignation in the XCTCT:

```
COPY SMD$BLOK
```

- b) the macro XCTCTANF has a new parameter:

```
XCTCTANF SCRMA=XCSRMA
```

- c) the new table XCSRMA is inserted at the right place in the XCTCTt: between the end marking of a existing table and the beginning of the next table.

```
XCSRMA    DS 0F

.

.

.

DC  AL2(0)    ; end-marking
```

- d) Between you can query individual screen contents with the following macros and programming corresponding input.:

XCSRMH (Header)
XCSRMS (Sub-Entry)
XCSRMC (Compare)

e) The announcement on the first application happens with the parameter SCRMA= by the program COVTC:

```
EXEC COVTC PA=CICS,SA=... ,SCRMA=headername
```

6.16.2. The macros XCSCRMH, XCSCRMS, XCSCRMC

a) the macros XCSCRMH

With it a screen mask is programmed. This contains a name and it has to be specified at the end of the table XCSCRMA with ELABEL (End-Label).

The table XCSCRMA can contain several Screen Masks.

XCSCRMH NAME=...,ELABEL=...

Format:

Disp 0	Length 2	Length over the whole Screen Mask Entry
Disp 2	Length 8	Name of the Screen Mask Entry
Disp 10	Length 1	Typ of Entry: 00

b) the macro XCSCRMS

With it a subentry is determined. You can define several subentries inside of a header. If the parameter ELABEL is specified you can determine the respective end.

```
XCSCRMS ELABEL=.....
```

Comparing operations are defined with the help of XCSCRMC inside of a subentry. If they are fulfilled the operations are executed that were programmed inside of this subentry.

The subentries can be interlaced. By the first subentry you specify for example the action - by the interlaced subentry you specify the single compares.

Format:

Disp 0	Length 2	Length of Sub Entry
Disp 2	Length 2	Length of values to compare

c) the macro XCSCRMC

With it the compare criterias are defined on this basis the actions should happen which are programmed in the subentry.

You can create several XCSCRMC inside of a subentry. All COMPARE'S have to be succesful that the programmed actions can follow (AND condition of all XCSCRMC).

```
XCSCRM POS=....,HEXVAL=....
CHARVAL=....
```

By POS= you specify the position inside of a screen on which the compare should happen. For example the characters which are queried are situated in line1, column 1. Then you state the position as X'0000'. With HEXVAL or CHARVAL you can specify the wanted characters. By CHARVAL single quotes aren't possible. Blanks aren't allowed in the string who has to be compared

The strings with that are compared stand at the Displacement 0000 to 3FFF. The attributes with that are compared stand at the Displacement 4000 to 7FFF and the SMD\$BLOK begins at the Displacement 8000.

A certain field in the SMD\$BLOK can be defined as position e.g the special register SMD\$SPRE.

This register can be queried on a specials contents with HEXVAL or CHARVAL.

This register is set 0 by calling from COVTC.


It can be filled for example with 1 by the first action and in the second subentry the register can be queried for 1.

Therefore the second action block is only executed when the first was succesful.

Format:

```
Disp 0 Length 1    Length of comparing string minus 1
Disp 1 Length 1    Condition Code 08 = EQUAL
Disp 2 Length 2    Position of Comparing field
0000 - 3FFF      = Screen contents
4000 - 7FFF      = Attributes
8000 - FFFF      = special fields (SMD$BLOK)
Disp 4 Length n    area of constants for Compares
```

6.16.3. Structure of the table SCDCRMA



XCSCRM C	compare 3
XCSCRM C	compare 4
SUBENT002 EQU *	
Action	
Action	
Action	
SUBENTRY2E EQU *	
PSCRM1E EQU *	
DC AL2(0)	

6.16.4. The SMD\$BLOK

*	SCREEN MASK DEFINITION
SMD\$BLOK	DSECT
SMD\$SPRE DS	H ;SPECIAL REGISTER
SMD\$PART DS	H ;PARTITION-ID (ZERO)
SMD\$TERM DS	CL8 ;TERMINAL NAME
SMD\$SUBT DS	H ;SUB-TERMINAL NUMBER (ZERO / 1-4)
SMD\$SCRS DS	H ;SCREEN SIZE (ROWS / COLUMNS)
SMD\$CURA DS	H ;CURSOR ADDRESS (FROM ZERO)
SMD\$AKEY DS	H ;KEY
SMD\$PERS DS	F ;PERSON NUMBER
SMD\$PNET DS	CL8 ;PRIMARY APPLICATION NETID
SMD\$PAPP DS	CL8 ;PRIMARY APPLICATION ID
SMD\$SAPP DS	CL8 ;SECONDARY APPLICATION ID
SMD\$END EQU	*

6.16.5. Commands for the actions:

X'01'	special key
X'10'	cursor position follows in 2 byte (Format big endian)
X'11'	set special register of SMD\$BLOK (2 bytes follow)
X'20'	request for RACF-UserID
	Disp 1 Length 2 position in the screen of UserID
X'21	request for RACF pass ticket
	Disp 1 Length 2 position in the screen of UserID
	contents is -1 (X'FFFF) if not set
	Disp 3 Length 2 Position in the screen for passticket
	Disp 5 Length 1 Length of application names
	Disp 6 Length n application name

6.16.6. Keycodes for the actions

For the keycodes actions are needed. The following keycodes are possible:

Code	Meaning
0101	Enter
0104	Clear (= Delete)
0115	PA1
0116	PA2
0117	PA3
0129	PF01
022A	PF02
022B	PF03
.	
.	
.	
0240	PF24

The keycodes are programmed like the commands as DC statements in the order they should be executed.

6.16.7. Example 1

Loggon in TSO without RACF

```

*****
XCSCRMA DS 0F ;SCREEN MASK TABLE BEGINNING
*
XCSCRMH NAME=SCREEN1,ELABEL=SCR1E ;Header 1
XCSCRMS ELABEL=SSCR1E ;first subentry
XCSCRMS ELABEL=SSCR1 ;interlaced subentry
* COMPARE IF PERSON 55
XCSCRM POS=(SMD$PERS-SMD$BLOK+X'8000'),HEXVAL=00000055
* SPECIAL REGISTER = 0 ?
XCSCRM POS=(SMD$SPRE-SMD$BLOK+X'8000'),HEXVAL=0000

```

SSCR1	XCSCRM	POS=X'0001',CHARVAL=IKJ56700A	
	EQU *		
	DC	C'USERID'	
	DC	X'0101'	;ENTER
	DC	X'110001'	;SET SPECIAL REG ON 1
	SSCR1E	EQU *	
	*		
	XCSCRM	ELABEL=SSCR2E	;second subentry
	XCSCRM	ELABEL=SSCR2	;interlaced subentry
	*	SPECIAL REGISTER = 1 ?	
	XCSCRM	POS=(SMD\$SPRE-SMD\$BLOK+X'8000'),HEXVAL=0001	
	XCSCRM	POS=X'0234',CHARVAL=Password	;(8-1)*80+(5-1)=564
	*	XCSCRM	POS=X'0234',HEXVAL=D781A2A2A6969984
	SSCR2	EQU *	
	DC	X'10'	;SET CURSOR ADDRESS
	DC	AL2((8-1)*80+(20-1))	;CURSOR ADDRESS OF PASSWORD
	DC	C'PASSWORD'	
	DC	X'0101'	;ENTER
	DC	X'110002'	;SET SPECIAL REG ON 2
SSCR2E	EQU *		
	SCR1E	EQU *	; End Header 1

6.16.8. Example 2

Loggon in TSO over RACF with the help of passticket

	XCSCRMH	NAME=SCREEN2,ELABEL=SCR2E	;Header 2
	XCSCRM	ELABEL=S2CR1E	;first subentry
	XCSCRM	ELABEL=S2CR1	;interlaced subentry
	*	COMPARE IF PERSON 56	
	XCSCRM	POS=(SMD\$PERS-SMD\$BLOK+X'8000'),HEXVAL=00000056	
	*	SPECIAL REGISTER = 0 ?	
	XCSCRM	POS=(SMD\$SPRE-SMD\$BLOK+X'8000'),HEXVAL=0000	
	XCSCRM	POS=X'0001',CHARVAL=IKJ56700A	
S2CR1	EQU *		
	DC	x'20001A'	;RACF USERID
	DC	X'0101'	;ENTER
	DC	X'110001'	;SET SPECIAL REG ON 1
S2CR1E	EQU *		

```

        XCSCRMS ELABEL=S2CR2E           ;second subentry
        XCSCRMS ELABEL=S2CR2           ;interlaced subentry

*      SPECIAL REGISTER = 1 ?

        XCSCRM POS=(SMD$SPRE-SMD$BLOK+X'8000'),HEXVAL=0001
        XCSCRM POS=X'0234',HEXVAL=D781A2A2A6969984

S2CR2   EQU *

        DC      X'21'                   ;FETCH RACF PASSTICKET
        DC      X'FFFF'                 ;NO USERID  (-1)
        DC      AL2((8-1)*80+(20-1))    ;CURSORADDRESS OF PASSWORD
        DC      AL1(7)                   ;LENGTH OF APPLIKATION
        DC      C'TSOP390'              ;NAME OF APP. FROM CLASS

*                                           ;PTKTDATA

        DC      X'0101'                 ;ENTER
        DC      X'110002'               ;SET SPECIAL REG ON 2

S2CR2E   EQU *

SCR2E    EQU *                          ; End Header 2

*

        DC      AL2(0)                   ;END OF TABLE

*****

```

6.17. HOB COM PASSWORD - XCPASSW -

The macro call happens at the end of the TCT (after entering the XCOMASK label):

```
*****  
XCPASSW DC      X'nnnnnnnnnnnnnnnnnnnnnnnnnnnnnnnnnnnnnn'  
*****
```

The delivered 34-character password is to be entered at this point (17 Bytes)!

This password checks among other things the ACB name of HOB COM and makes additional options possible like STTE. It is limited in time and is yearly renewed. If you shouldn't receive a new password before expiration of the time limit please inform the HOB-Software-Support.

7. DEFINING PCS WITH HOBLINK 3270 - Y-PROTOCOL -

7.1. GENERAL REMARKS CONCERNING THE INSTALLATION

The communication between HOBLINK 3270 (version 2.1 or higher) and HOB COM is performed with a HOB owned protocol, the so-called Y protocol. This protocol makes it possible to encrypt and compress the data stream. In order to allow PCs that have HOBLINK 3270 installed, to communicate with HOB COM, the following definitions are required on the host.

7.2. PASSWORD IN THE HOB COM TCT

In the HOB COM TCT you have to enter a password, which contains information about the number of Y sessions that are to communicate with HOB COM. This password you can obtain from the HOB support.

If two different HOB COM communicate with each other, the password has to be entered in the TCT of the HOB COM, that manages the real terminals resp. on which the emulation logs on.

7.3. PERSONAL ENTRY IN THE HOB COM TCT

In the HOB COM-TCT one personal entry is required at least. This entry contains the encryption key. You can choose freely a different encryption key for every user. The encryption key can have a length up to 32 byte.

The default value that HOBLINK 3270 uses, is "GUEST". That means that normally one person „GUEST“ has to be entered in the HOB COM TCT. The personal entry „GUEST“ is not necessary, if no PC uses the default value, i.e. if any HOB COM user has its own personal entry.

Examples:

```

XCPERSTA DS      0F          For VSE, MVS and GCS
*
XCPERS NO=111111,TYPE=P,NAME=GUEST,PW=GUEST,          X
ENKEY=GUEST,ENFULL=NO
*
XCPERS NO=nnnnnn,TYPE=P,NAME=name,PW=password,        X
ENKEY=key,ENFULL=NO/YES
*
*****
*  INSTEAD OF ENKEY OPTIONALLY ENKEYH CAN BE USED      *
*  THE KEY HAS TO BE ENTERED HEXADECIMALLY THEN (EBCDIC) *
*  EXAMPLE: ENKEYH=C7E4C5E2E3                          *
*                G U E S T                             *
*****

```

nnnnnn= personal number
The number 000000 is reserved and may not be used.

password = the HOB COM user password

name= HOB COM user ID

key= The encryption key, it may be chosen freely.

ENFULL= NO = only the passwords will be encrypted.
YES = all data will be encrypted.

```

XCPERSTA DS      0F
* without RACF
XCPERS NO=nnnnnn,TYPE=P,NAME=name,PW=password,          X
PROFD1=HOB,PROFD2=PROFILE,PROFD3=name,                  X
MAILID1=POSTEIN,MAILID2=name,                            X
MAILOD1=POSTAUS,MAILOD2=name,                            X
ENKEY=key,ENFULL=NO
* with RACF
XCPERS NO=nnnnnn,TYPE=P,NAME=name,USERID=userid,        X
PROFD1=HOB,PROFD2=PROFILE,PROFD3=name,                  X
MAILID1=POSTEIN,MAILID2=name,                            X
MAILOD1=POSTAUS,MAILOD2=name,                            X
ENKEY=schlüssel,ENFULL=YES

```

The personal entries in HOB COM have to correspond with the entries in the configuration files (*.hik) of HOBLINK 3270. One of the hik-values, Name, HobcomUserId or PersNo (see default value of the hik file) will be sent by HOBLINK 3270 to HOB COM for identification.

HobcomUserId= will only be sent to HOB COM if RACF is used.

PersNo= will only be sent to HOB COM, if the entry Name= is missing.

The hik values Password and HobcomKey will always be sent to HOB COM. HOB COM checks the correspondance of the sent values with the entries in the HOB COM TCT. If the entries don't correspond or if the maximum numbers of allowed Y sessions is exceeded, the user is refused by HOB COM.

Default values in the HOBLINK 3270 configuration file (*.hik)

```

Hobcom=Yes
HobcomKey=C7E4C5E2E3          .....is always exploited by HOBCOM
PassEncryption=Off
HobcomBigBuffer=On
Name=GUEST
Password=GUEST                ..... is always exploited by HOBCOM
HobcomUserId=                  ..... only required for RACF
PersNo=111111                  ..... only required if Name= is missing

```

If RACF is used:

If RACF is used in the HOBCOM TCT the parameter USERID= has to be used instead of PW=.

If HOBLINK 3270 uses RACF when connecting an application, the hik entry "HobcomUserId=" has to correspond with the entry "PW=" in the HOBCOM TCT.

As RACF-Userid then the HOBCOM TCT entry "USERID=" will be sent to RACF, as RACF password the hik entry "Password="

If two different HOBCOM communicate with each other, the personal entry has to be entered in the TCT of the HOBCOM, that manages the real terminals resp. on which the emulation logs on.

7.4. LOGMODE

For the LOGON of HOBLINK 3270 a special logmode „CODLOG11“ is required. This logmode is contained in the MODTABCX on the installation tape.

Please add this logmode in your current modetab or reload the new modetab and enter your name together with the name of the logmode at any LU definition that HOBLINK 3270 uses.

Example:

```

MODETAB=MODTABHS
DLOGMOD=CODLOG11

```

7.5. USSTAB

If the LOGON is not performed when starting the USSTAB command COD91Y can be used. This command is contained in the USSTABHS on the installation tape.

This command uses the logmode CODLOG11, i.e. the MODTABHS has to be loaded before and the HOBLINK LUs get the entry

```

USSTAB=USSTABHS
MODETAB=MODTABHS

```

Entry from USSTABHS:

```

COD91Y  USSCMD  CMD=COD91Y,REP=LOGON,FORMAT=PL1
        USSPARM  PARM=APPLID,DEFAULT=HOBCOM

```


8. PRINTING WITH HOB COM

8.1. PRINTING FROM CICS ON STANDARD 3270 TERMINAL

8.1.1. DFT terminal

Necesseary printer definitions:

- in VTAM

CONSE10	LBUILD	
SP01	LOCAL CUADDR=111,	X
	TERM=3277,	X
	ISTATUS=ACTIVE	

- in CICS

SPRI	DFHTCT TYPE=TERMINAL,	X
	ACCMETH=VTAM,	X
	TRMTYPE=LUTYPE3,	X
	COMPAT=NO,	X
	ERRATT=NO,	X
	PGESIZE=(24,80),	X
	PGESTAT=AUTOPAGE,	X
	TCTUAL=255,	X
	TIOAL=160,	X
	TRMSTAT=TRANSCEIVE,	X
	TRMIDNT=SPRI,	X
	NETNAME= SP01 ,	X
	TRMPRTY=0	

- in the HOB COM major node

Virtual terminals and printers which are to be allowed to print from CICS are to be entered in the major node of HOB COM.

CODIS0E	VBUILD TYPE=APPL
SP01P	APPL AUTH=(ACQ,NOPASS),EAS=4,MODETAB=MODTABPR,VPACING=2

- in the HOB COM TCT

XCTERMA	DS	OF
XCTSTE	TERM=HT0E110,FLAG=OPT	
XCTPRI	TERM= SP01 ,PRINT=0100	

For printing from CICS the programm PR3287 has to be started as batch a task:

```
EXEC PR3287 PA=CICS,SA=SP01P,PRI=SP01,PARAM=parameter
```

The definitions above enable the print on a control unit printer.

If the printer is connected to a DFT terminal, the real printer in VTAM has to be defined as LU.

8.1.2. Printing on a 3270 printer connected to a CUT Terminal

Printing (other than the local hard copy) from a CUT terminal is only possible when a printer session is allowed by the terminal software! Such terminals are e.g the HOB 470 Series terminals and the IBM Info Window terminals. For any other terminals please check the set-up to see if a printer session is allowed!

The printer address of a CUT terminal must be the second entry in the control unit. The other definitions and the printer invocation are analog to those given in chapter 7.2.1.

8.1.3. Printing Using Form Parameters

When printing from CICS, form parameters can also be used which are passed by program PR3287. When printing from a standard 3270 terminal some restrictions must be observed:

1. It must be possible to enter a bypass character in the terminal set-up or the terminal software must recognize a bypass character.
2. In the printer parameter no 'FF' lines may appear in the printer parameter. If parameters are to be passed which normally appear in a 'FF' line, then this line should be converted to a '90 line'. See the following example:

The following example shows a form parameter which allows landscape format:

```
PPFOR11 EQU * ;PARAMETER FOR HOB 8LP
          DC AL2(PPFOR11Z-PPFOR11) ;LENGTH FORM
          DC CL8'X3' ;NAME FORM
          DC AL1(L'PPFOR11A) ;LENGTH
PPFOR11A DC X'905FF1C25093F1D7'
PPFOR11Z EQU *
```

The meanings of the codes in the 90 line are as follows:

5F corresponds to the bypass characters ^

F1C2 corresponds to the ASCII escape sequence 1B which marks the beginning of a control character

5093F1D7 are EBCDIC codes which are to be translated to ASCII; in this case &110

If more than one initialization sequence is to be passed in a 90 line, then each ASCII escape sequence (1B) and each character with a hexadecimal value less than X'40' must be coded with a bypass character!

Please observe that this sample parameter is not complete. Initialization sequences for page length, line spacing, number of lines per page, the left and right margins as well as the suppression of blank lines are missing.

8.2. PRINTING FROM CICS ON E-TERMINAL PRINTER

The program PR3287 allows you to print CICS data direct on a terminal printer. To do this the following definitions are necessary:

- in VTAM

Define the printers in the VTAM major node:

Example:

N01P	APPL	ACBNAME=N01P,	X
		AUTH=(ACQ,NOPASS),	X
		VPACING=1,	X
		EAS=2	

- in CICS

Define the printers in CICS as either LUTYPE 1 or LUTYPE 3.

Example for LUTYPE 1

N01P	DFHTCT	TYPE=TERMINAL,	X
		ACCMETH=VTAM,	X
		TRMTYPE=SCSPRT,	X
		TRMMODL=2,	X
		COMPAT=NO,	X
		ERRATT=NO,	X
		PAGESIZE=(24,80),	X
		PGESTAT=AUTOPAGE,	X
		TCTUAL=255,	X
		TIOAL=160,	X
		TRMSTAT=RECEIVE,	X
		TRMIDNT=N01P,	X
		NETNAME=N01P,	X
		TRMPRTY=0	

Example for LUTYPE 3

N01P	DFHTCT	TYPE=TERMINAL,	X
		ACCMETH=VTAM,	X
		TRMTYPE=LUTYPE3,	X
		COMPAT=NO,	X
		ERRATT=NO,	X
		PAGESIZE=(24,80),	X
		PGESTAT=AUTOPAGE,	X
		TCTUAL=255,	X
		TIOAL=160,	X
		TRMSTAT=TRANSCIEVE,	X
		TRMIDNT=N01P,	X
		NETNAME=N01P,	X
		TRMPRTY=0	

- Invoking in HOB COM

The program PR3287 has to be invoked in the HOB COM background. Example:

```
EXEC PR3287 PA=CICS,SA=N01P,PRI=N01,PARAM=FSP17,LLM,AGO
```

SA=N01P this is the SAPPL name

You will find a more detailed description of the programs PR3287 in the HOB COM User's Manual.

8.3. PRINTING FROM JES ON E-TERMINAL PRINTER

Program PR3770 allows you to print directly from your spool system on a HOB COM printer. The HOB COM printers emulate RJE stations and must be defined as such.

- in JES

In order to be able to address an HOB printer as a RJE station, it is necessary to make an entry in JES under MVS.

The following is an example of an entry in JES2:

```
LOGON1 APPLID=JES2
&MAXSESS=nnnn
&NUMLINES=nnnn
&NUMLOGS=1
&NUMRJE=nnnn
&NUMTPBF=(nnnn,mmmm)
&TPIDCT=31
*
LINE1 UNIT=SNA
RMTnnnn DEVTYPE=LUTYPE1,BUFSIZE=512,NUMPRT=1,NUMRDR=0,NUMPU=0,
LUNAME=CBP1,COMPRESS=NO,COMPACT=NO,SETUP=PDIR,CONS=YES
$TRMTnnnn,A=Y
Rnnnn.PR1 PRWIDTH=132,COMP=NO,CMPCT=NO,CCTL=YES
```

Enter the name of the VTAM application as APPLID. MAXSESS defines the maximum number of VTAM sessions; NUMLINES is the number of lines; NUMLOGS is the number of JSE2/VTAM interfaces; NUMRJE is the number of the RJE stations; NUMTPBF is the number of the JSE2 TP buffers.

The following is an example of an entry in JES3:

In JES3 you define the HOB COM printer as 3776-RJE stations.

```
COMMDEFN,APPLID=JES3,LU=5
CONSOLE,JNAME=RMT01,TYPE=RJP,DEST=NONE,LEVEL=15
DEVICE,DTYPE=RMTPRINT,JNAME=RMT01PR1,XLATE=NO
RJPWS,N=RMT01,RD=0,PR=1,G=RMT01,AUTO=N,COMPACT=NO,C=R
```

The VTAM ACB name and the maximum number of LUs are to be entered in the first line.

Example of an invocation:

```
EXEC PR3770 PA=.....,SA=N01P,PRINTER=N01,PARAM=FSP17,MSG='RMT01'
```

You will find the complete description of the program PR3770 in the HOB COM User's Guide.

8.4. Printing over HOB COM on the system printer

The driver routine \$PRINT makes the print output on a system printer possible. For example an HOB-TEXT text is transferred in the IBM format and the output on printer that doesn't support the HOBTEXT format is possible. Especially there happens no transfer in the ASCII format!

1. Part filename (fix): \$PRINT

With DYNALLOC (= SVC 99) a resource is allocated.

2. Part filename: Class of the system printer in JES

3. Part filename: any string with the maximum length of eight characters;

When U is registered the text is translated in capitals

Please note that the output on Remote or NJE isn't possible respectively the way over

```
/*ROUTE PRINT x.y
```

is expected.

Example:

```
EXEC PR3287 PA=CICS,SA=N01P,OUTFILE=$PRINT.H.XXX-U,PARAM=FSP17
```

8.5. PRINTING A HARDCOPY ON E-TERMINAL PRINTER

The advantage of hardcopy printing over HOBCOM is, control unit overlapping hardcopies are possible.

Please note: If you are working on standard 3270 terminal, the program NOTE cannot be started as a batch task, because the terminal software does not allow it!

However, a hardcopy can be routed from an E-terminal to a standard 3270 terminal with an attached printer.

8.5.1. Pressing the Hardcopy Key for Output

To activate your hardcopy key, the program NOTE as Batch-task must be started over the COBA program or through entering the XCTCT (table XCUSBTAT):

```
EXEC NOTE TERM=terminal_name,PRI=printer_name
```

terminal_name Name of the terminal, from which the hardcopy will be sent

printer_name Name of the terminals, onto which the printer is
connected, on which the hardcopy will be put out

The NOTE program can either be started automatically through an entry in the HOBCOM-TCT (XCUBT-Macro) or individually with help of the COBA program.

8.5.2. Output over the HOBCOM-Notebook

The NOTE program can also be invoked as ONLINE-task with the help of the command EXEC NOTE order or a corresponding command abbreviation.

You can choose between 5 options in a terminal mask. One of these options allows the storing (and later printing) of up to 8 terminal contents.

For further information, see the HOBCOM User's Manual.

8.6. PRINTING A LOCAL HARDCOPY ON E-TERMINAL PRINTERS

The advantage of hardcopy printing over HOBCOM is, control unit overlapping hardcopies are possible.

INFORMATION : When you work on a standard 3270 - terminal, the PROGRAM NOTE can't be started as batch task, because the terminalsoftware forbids it.

From an E - Terminal the hardcopy can be transferred to standard 3270 - terminal with printer.

In the terminal setup, the hardcopy - control has to be set to HOBCOM.

8.6.1. Output by pushing the hardcopy key

To activate your hardcopy key, the program NOTE as Batch-task must be started over the COBA program or through entering the XCTCT (tabel XCUSSBTA):

```
EXEC NOTE TERM=terminal_name,PRI=printer_name
```

terminal_name	Name of the terminal, from which the hardcopy will be sent printer_name Name of the terminals, onto which the printer is connected, on which the hardcopy will be put out
---------------	---

The NOTE program can either be started automatically through an entry in the HOB COM-TCT (XCUBT-Macro) or individually with help of the COBA program.

8.6.2. Output over the HOB COM-Notebook

The NOTE program can also be invoked as ONLINE-task with the help of the command EXEC NOTE order or a corresponding command abbreviation.

You can choose between 5 options in a terminal mask. One of these options allows the storing (and later printing) of up to 8 terminal contents.

For further information, see the HOB COM User's Manual.

8.7. PRINTING FROM HOB COM OVER TCP/IP

For Information about printing from HOB COM over TCP/IP please refer to chapter 9. HOB COM AND TCP/IP on page 92 .

9. HOB COM AND TCP/IP

HOB COM supports the following three TCP/IP applications:

- Connecting PCs with HOB COM over TN3270 or TN3270E
- Printing on LPD
- Printing on NCs

In HOB COM a Lineprinter-Requester is integrated which allows you to print on LPD.

If a PC is connected to HOB COM over TN3270 the PC can only open a display session. If a PC is connected over TN3270E a display session or a printer session can be opened. If the PC is connected with HOBLINK 3270 or HOBLINK J-Term the PC performs with one session display session and printer session concurrently. In this case TN3270E is used always; print data and screen data are sent to the same resource name.

If you are using TN3270E (screen or printer) or TN3270 (only screen) the S protocol is used. If you are using TN3270E and HOBLINK 3270 (display and printer) the Y protocol will be used.

Requirements for TN3270/TN3270E to MVS-HOB COM:

- TCP/IP for MVS
- TN3270/TN3270E-capable application on the PC
- TCP/IP on the PC

Requirements for LPD printing with MVS-HOB COM:

- TCP/IP for MVS
- LPD

Requirements for printing on NC from MVS-HOB COM

- TCP/IP for MVS
- NC with TCP/IP connection

9.1. HOB COM DEFINITIONS FOR THE TCP/IP CONNECTION

9.1.1. Open and Close TCP/IP Port

In order to make the TCP/IP connection to HOB COM possible, it is necessary to open a TCP/IP port before.

On the console of the MVS HOB COM a TCP/IP port has to be opened. You can choose any free port number.

```
F jobname,OPEN TCPIP TELNET PORT=5025
```

Example for an open that will be performed automatically when HOB COM is started.

```
XCUBT  SYSTEM=YES,CO=YES,COM='OPEN TCPIP TELNET PORT=5025'
```

Thus HOB COM becomes a TCP/IP application.

You can open as many ports for HOB COM as you want. You should use ports that are not reserved. Ports that are already used by other programs, e.g. port 23 cannot be opened by HOB COM.

The port entry on the client side (3270 emulation) has to correspond with the port opened in HOB COM.

When the OPEN is made TCP/IP has to be active already on the host.

If you close and reopen TCP/IP it is not sufficient to perform a second OPEN. A CLOSE has to be made before.

To do this enter on the console of MVS HOB COM:

```
F jobname,CLOSE TCPIP TELNET PORT=5025
```

9.1.2. Entries for TCP/IP in the XCTCT

An additional entry in the XCTCTGEN macro is required: TCP/IP=XCTCPIP. After making this entry you have to load the new macro library XCTCPIP and to assemble the XCTCT with this library.

Example:

```
XCTCTANF XTCTGEN TERMA=XCTERMA, X
      PRTAB=XCPRTAB, X
      USSOUT=XCUSSOUT, X
      USSCOM=XCUSSCOM, X
      PRPAR=XCPRPAR, X
      USSBTA=XCUSSBTA, X
      APPLTA=VCAPPLTA, X
      PERSTA=VCPERSTA, X
      TCPIP=XCTCPIP, X
      COMASK=XCCOMASK, X
      PASSW=XCPASSW
```

The new table XCTCPIP is entered after an existing table (e.g. after the endmark of VCPERSTA):

```
XCTCPIP DS 0F
      XCTCPIP NSERVER=aaa.bb.ccc.d, X
      VMTCPIP=jobname X
      DOMAIN=domainname, X
      HOST=hostname, X
      TIMEOUT=15
      DC AL2(0) ;end mark of the table
```

aaa.bb.ccc.d TCP/IP-address of the name-server over which the destination addresses are called.

jobname name of the job in which the TCP/IP-socket is started. It's an optional parameter, but has to be entered, when it's different to the default TCP/IP jobname.

hostname the TCP/IP-name of the HOST in which HOB COM runs.

domainname the name of the TCP/IP-domain in which the HOST "hostname" is located.

Example:

XCTCPIP NSERVER=123.45.123.1,	X
VMTCPIP=TCPIP,	X
DOMAIN=HOB.DE,	X
HOST=HOST9221,	X
TIMEOUT=15	

9.1.3. PASSWORD FOR S- AND Y-SESSIONS IN THE HOB COM TCT

In order to build a TN3270E/TN3270 session to HOB COM an authorization for S sessions or Y sessions is required. This authorization is granted by the HOB COM password, an additional feature (entailed with separate costs).

In the HOB COM TCT you have to enter a password, which contains information about the number of Y- or S- sessions that are to communicate with HOB COM. This password you can obtain from the HOB support.

S sessions are used for emulations with TN3270 (display session) or emulations with TN3270E (screen or printer session). HOBLINK 3270 without HOB COM support uses TN3270E and needs one S sessions per connection. HOBLINK J-Term with TN3270E uses up one S session, too.

Y sessions are required for HOBLINK 3270 with HOB COM support and for HOBLINK J-Term with „HOBY“ connection.

9.2. TN3270 CONNECTIONS TO HOB COM**9.2.1. TN3270 Display-Session to HOB COM (S-Session)**

If the clients are connected over TN3270 only display sessions are possible, no printer sessions.

Sample configuration in HOBLINK 3270:

Configure Connections [X]

LU Type : Display Use Session : Next Available

Screen Size : 80 x 24 No. of Connections : 1

Connection 1

Connection Type : TN 3270 [Configure...]

☐ Enable Data Compression

☐ HOB COM Support [Configure...]

☐ Host Graphics Support

Acknowledge Timeout (secs.) : 10 Auto-connect time : 0

Disconnect after (mins. idle) : 0

OK
Cancel
Help

HOB

TN 3270 [X]

Host Alias / IP Address : 123.45.123.123

Terminal / Device Type : 3279

Remote Port : 5025

☐ Auto-Reconnect

Local Port

☒ Automatic Port Assignment

Port Number : 256

☐ Use TN3270 Extended Protocol

Resource / Device Name :

OK
Cancel
Help

HOB

9.3. TN3270E CONNECTIONS TO HOB COM

If the clients are connected over TN3270E both, display sessions and printer sessions are possible.

9.3.1. TN3270E Display Session to HOB COM (S-Session)

Sample configuration in HOBLink 3270:

Configure Connections

LU Type : Display Use Session : Next Available

Screen Size : 80 x 24 No. of Connections : 1

OK
Cancel
Help

Connection 1

Connection Type : TN 3270 Configure...

☐ Enable Data Compression Configure...

☐ HOB COM Support

☐ Host Graphics Support

Acknowledge Timeout (secs.) : 10 Auto-connect time : 0

Disconnect after (mins. idle) : 0

HOB

TN 3270

Host Alias / IP Address : 123.45.123.123

Terminal / Device Type : 3279

Remote Port : 5025

☐ Auto-Reconnect

Local Port

☒ Automatic Port Assignment

Port Number : 256

☒ Use TN3270 Extended Protocol

Resource / Device Name : TERM123

OK

Cancel

Help

HOB

9.3.2. TN3270E Printer Session to HOB COM (S-Session)

If you are connected to HOB COM with a TN3270E printer session, the emulation can be interpreted by MVS HOB COM as „S printer“. HOB COM supports then both, DSC print and SCS print. That means, that it is possible to address an S-printer out of HOB COM with 3270 data stream. Therefore in VM HOB COM the driver \$COP0100 has been linked.

An entry with the macro XCTPRI is not mandatory for the TN3270E.

The TN3270E connection requires the authorization for S-sessions through a HOB COM password.

After the session to HOB COM was built up, the session gets inside HOB COM the name, that was entered in the TN3270E application as device name or resource name. This name was sent inside the data stream. If no device or resource name was entered, a session name will be assigned automatically. This name is "TEL\$nnnn" . nnn is a number consecutive from 0001 up.

You cannot influence this number, HOB COM assigns it automatically. If no device or resource name was entered, the startup of printer tasks cannot be made automatically, because the name of the TN3270E printer session is not fixed before.

The name of the TN3270E printer session can be displayed by the 'CO D TERM' command in the HOB COM main mask or console.

The name of the printer session then can be specified in all print programs (in the parameter PRI= or OUTFILE=) as the destination of the print.

Examples:

```
EXEC PR3287 SA=01P,PA=CICS,PRI=TN$0001
EXEC PR3287 SA=01P,PA=CICS,OUTFILE=$NET.$name.TEL$0005
```

All print programs available in HOB COM under MVS can be used. That means, that you can print out of CICS with PR3287, from JES with PR3770, over NOTE etc.

Sample configuration in HOBLink 3270:

Configure Connections

LU Type : Use Session :

Screen Size : No. of Connections :

Connection 1

Connection Type :

☐ Enable Data Compression

☐ HOB COM Support

☐ Host Graphics Support

Acknowledge Timeout (secs.) : Auto-connect time

Disconnect after (mins. idle) :

HOB

TN 3270

Host Alias / IP Address :

Terminal / Device Type :

Remote Port :

☐ Auto-Reconnect

Local Port

☒ Automatic Port Assignment

Port Number :

☒ Use TN3270 Extended Protocol

Resource / Device Name :

HOB

The XCTPRI Macro

With the help of this macro the printer driver 100 is assigned to a 3270 printer (S protocol) that is managed by HOB COM, and the LU type is determined.

Now you can print on a S printer from HOB COM under MVS, if it is connected over TCP/IP. If a TN3270E printer session is built to MVS-HOB COM this printer can be made known to HOB COM by the macro XCTPRI. As it can be used in VTAM-HOB COM to define an SNA printer.

Note: If the macro is not entered in the TCT, HOB COM recognizes the type (TN3270 or SNA) automatically, when the printer is connected.

The macro is required only, if you wish to use the non-default values.

Sample entry:

XCTPRI	TERM=nameabc ,TYPE=TN3270 ,PRINT=100 ,LUTYPE=1 ,DISCON=NO
XCTPRI	TERM=namexyz ,TYPE=SNA ,PRINT=20 ,LOGM=DSC2K ,DISCON=NO ,LASTTE=NO

TERM=	This parameter is mandatory. It corresponds to the resource/device name used in TN3270E or the name of the VTAM LU in SNA. With the help of this name the printer is addressed inside HOB COM.	
TYPE=	SNA	SNA is the default value. This parameter is not required if the default value is used.
	TN3270	This parameter specifies if the printer is connected to HOB COM over TN3270E or SNA.
PRINT=	This parameter always should be specified. Enter the driver reference number of the printer. If you use a TN3270E printer (S protocol) only 100 can be used. (For SNA all drivers can be used). If TYPE=TN3270 the driver 100 will be used by default, if this parameter is not entered.	
	ATTENTION! If you enter TYPE=TN3270 and not the value 100 for PRINT= HOB COM can crash. If the parameter is not entered, the first driver of the TCT that has a three digit reference code is used.	
LOGM=	This parameter is only effective if TYPE=SNA is used.	
	This entry overwrites the logmode that was entered in VTAM for the printer LU. Possible values are SCS, DSC2K, DSC4K etc. If the parameter is entered when TYPE=TN3270 is used, it will be ignored.	
LUTYPE=	1	This parameter is only effective if TYPE=TN3270 is used.
	3	This entry determines, if the data is sent to the printer as SCS data (LUTYPE=1) or as DSC data (LUTYPE=3). The default value is LUTYPE=3. If the parameter is entered when TYPE=SNA is used, it will be ignored.
DISCON=	NO	NO is the default value.
	YES	
LASTTE=	NO	NO is the default value
	YES	This parameter has to be entered in the definition of the last terminal/printer in the VCTCT.

The Driver 100

Under VM the driver 100 can be used only for TN3270E printers. If the TN3270E printer session is built up to HOB COM and no XCTPRI entry was made, HOB COM recognizes automatically the printer type and assigns the driver 100 to the printer. No different driver can be used for this printer type.

9.3.3. TN3270E Display and Printer Session to HOB COM (Y-Session)

Requirement on the client side is HOBLINK 3270 or HOBLINK J-Term and a password that allows you to use Y-sessions.

Enable the "HOB COM support" check box in the HOBLINK 3270 configuration dialog box. If you use HOBLINK J-Term choose the „HOBY“ protocol.


The session is represented for HOB COM as a terminal, that can process both, display and printer data, as the HOB terminals can do it. Analogous to the terminal in HOB COM a printer task is created in the background, e.g. PRVM.

The output of the printer data is made to this „terminal“, i.e. with the parameter PRI= or OUTFILE= as printer name the device/resource name is specified. If no device/resource name was specified, the terminal will obtain a HOB COM name. This name is "TEL\$nnnn". nnn is a number consecutive from 0001 up.

HOBLINK 3270 can also establish a printer session to HOB COM, but this session will be executed like an S-session. If in the HOBLINK 3270 printer session the "HOB COM support" check box is enabled this device will be refused by HOB COM as a 3270 printer cannot understand the Y protocol.

```
XCTERMT1: RECV_TCP SB 3270_REGIME: TERMINAL NOT SUPPORTED
```

Sample configuration in HOBLINK 3270:



9.4. PRINTING OVER LPD

9.4.1. Printing from HOB COM to an LPD

In order to print over TCP/IP out of MVS-HOB COM to an LPD some additional entries are required.

Entry in the XCTCT

In the XCTCT an additional entry in the XTCTGEN macro is required. See section „9.1. HOB COM DEFINITIONS FOR THE TCP/IP CONNECTION“ on page 92.

Therefore it is necessary that you load the macro library XCTCTM that comes with HOB COM and assemble the XCTCT with this library.

In the table XCTCPIP for LPD an entry can be made. This makes it easier to address the printer on the target host. This can be done with the XCHOST and XCPRT macros. These macros are optional, i.e. not required for printing on LPD.

```
XCTCPIP  DS  0F
          XCHOST NAME=$name1,IPADDR=eee.ff.ggg.hhh
          XCHOST NAME=$name2,IPADDR=eee.ff.ggg.iii
          XCPRT  NAME=$printeralias,PRT=printername
          DC      AL2(0)                                ;End mark of the table
```

The **XCHOST** macro makes it possible to give the target host an alias name.

\$name1

\$name2 Name, that can be used at the parameter OUTFILE= instead of the hex-coded target address. If you prefer the work with names instead of TCP/IP addresses, you can enter several names with its IP addresses under the XCHOST macro.

eee.ff.ggg.hhh

eee.ff.ggg.iii TCP/IP addresses of the target host.

The **XCPRT** macro makes it possible, to give the printer on the target host an alias name.

printername Name of the printer on the target host.

Under circumstances the target host expects that this name is in lowercase. Then here the name has to be entered in lowercase, too. In this case in HOB COM only the alias name can be used, because HOB COM command entries are automatically changed to uppercase.

\$printeralias HOB COM name of the target printer.

Starting the LPD print:

The following HOB COM programs can be used to print on LPD:

NOTE, PR3770 and PR3287

If the TCP/IP print is to be started the parameters HOST= and PRI= are required when this print programs are used, or the parameter OUTFILE= alternatively.

Examples:

```
EXEC PR3287 HOST=targethostname.targetdomainname,PRI=printername,AGO
EXEC PR3287 HOST= targethost,PRI=printername
EXEC PR3287 HOST=$name1,PRI=printername
```

targethostname	Name of the target host as it is entered in the name server.
targetdomainname	Name of the target domain as it is entered in the name server. This name is divided by a dot. Example: HOST=qqq.rrr.ss Hostname : qqq Domainname: rrr.ss
targethost	the TCP/IP address of the target host. Example: HOST=222.33.444.5
printername	Name of the printer in the target environment (Host/PC) As Name the <i>\$printeralias</i> or the <i>printername</i> from the macro Macro XCPRT can be entered.
\$name1	the HOB COM alias name of the target host.

Instead of HOST= and PRI= the OUTFILE= parameter can be used:

```
EXEC PR3287 OUTFILE=$NET.$name1.printername,AGO
EXEC PR3287 OUTFILE=$NET.vvwwxxyy.printername,AGO
```

\$NET	HOB COM driver program for printing on LPD.
\$name1	HOB COM name of the target host. This second part of the name has to be entered together with the TCP/IP address in the XCTCT under the XCHOST macro. The TCP/IP address is token from the macro.
printername	the third part of the name is the name of the printer on the target host.
vvwwxxyy	Instead of a name which is entered in the VCTCT the target address in OUTFILE= can be entered as four hex values. These 4 bytes are the TCP/IP target address:

Example:

Address: 195.46.235.68
Hex : C3 2E EB 44

That's the way you enter the target host in the NOTE program, too as default value, when NOTE is called with the OUTFILE= parameter.

Example:

```
EXEC NOTE OUTFILE=$NET.$name1.$printeralias
```

It appears:

```
ENTER NUMBER OF PICTURE (Px) 1
OUTFILE: $NET.C32EEB44.printername
```

Printing on LPD over driver

In order to print on LPD out of HOB COM the XCPRT macro can be used optionally.

To send init sequences from HOB COM to a printer HOB COM has to know which printers are connected. This information is entered in HOB COM over the driver number (e.g. '10' for HP Laser). LPD can be controlled by a HOB COM driver, too. This makes it possible to avoid problems with special characters, face types, line space, etc.

To do this, in the XCPRT macro the PRINT= parameter is used.

Example:

```
XCPRT NAME=$printer alias ,PRT=printer name ,PRINT=driver number
```

driver number is the driver number as entered in you TCT for a certain driver program, e.g. 20 for \$COP0020 or 98 for \$COP0098

If the entry XCPRT is missing, no driver will be used.

If the PRINT= parameter is missing, the default value driver 98 will be used.

Note:

Please note that in this case an entry for the driver 98 in your XCTCT in the table XCPRTAB is necessary.

Some LPDs or applications don't send a form feed at the end of the print. With the XCPRT macro this form feed will be added and thus the last side of the print is output. To do this, the parameter FFONEND has to be added.

The default value for this parameter is NO. Enter FFONEND=YES if the form feed is to be sent.

Example:

```
XCPRT NAME=$ALIAS ,PRT=LPD1 ,PRINT=20 ,FFONEND=YES
```

In some LPDs on PCs the names of the windows printers are assigned to a TCP/IP printer name. Use this name in the PRT= parameter.

Example:

The name of the Windows printer is 'HP Laser Jet III'

The LPD sends the print data to this printer, if the TCP/IP printer LPD1 is addressed.

In XCPRT you enter the name LPD1 in the PRT= parameter. Inside HOB COM the alias name is used.

```
EXEC PR3287 HOST=195.46.235.73 ,PRINTER=$ALIAS
```

If the name you entered in PRI= is not found in the XCTCT (i.e. no XCPRT entry exists for this printer) the name entered with PRI= will be sent as TCP/IP name.

Example:

```
EXEC PR3287 HOST=195.46.235.73 ,PRINTER=LPD1
```

If your LPD doesn't allow you to rename the Windows name the XCPRT macro can be used to enter the Windows name as a string.

Example:

```
XCPRT NAME=$ALIAS,PRT='HL Laser Jet III',PRINT=20,FFONEND=YES
```

Note, that blanks, special characters and uppercase are allowed (max. 99 characters).

Example:

The following example shows, how to print with the NOTE program on a LPD. You can test if this printing works properly. If not an error message appears in the status line of NOTE.

To invoke NOTE enter:

```
EXEC NOTE PRINTER=$ALIAS,HOST=1.1.1.1
```

The NOTE program window will appear. Select function 4 to print the current screen.

```
ENTER PICTURE NR. (Px) 1
OUTFILE: SNET.01010101.$ALIAS
```

If no error message appears the printer works properly. Error messages you will find in section „11.9. MESSAGES OF THE XCTCPIP2 PROGRAM“.

9.4.2. Printing from PC over LPD on the host to HOB COM

To print over LPD on the host to HOB COM both, TCP/IP and an LPD have to be installed on the host. In the LPD a printer has to be configured in the LPD.

```
Lpr -s eee.ff.ggg.hhh -p printername filename
```

9.5. Printing on NC

To print on a NC (network client) the programs NOTE, PR3287, PR3770 can be used, i.e. all programs that use the OUTFILE= parameter.

The print is initialized from the host, i.e. the NC is called over its IP number.

The NC can (as LPD) be called with or without driver.

1. Printing without driver:

For LPD:

```
EXEC programname ...,HOST=ip-address,PRI=name
```

For NC:

```
EXEC programname ...,HOST=ip-address,PORT=portnumber
```

name is the name of the printer on the remote system (PC).

portnumber is the port number the printer has on the remote system.

When you print on an NC you have to specify the port number.

In the XCTCT no entry is required if you want to print without driver.

2. Printing with driver:

LPD:

```
EXEC programname ...,HOST=ip-address,PRI=name
```

NC:

```
EXEC programname ...,HOST=ip-address,PRI=name
```

ip-address is the TCP/IP address (decimally or the IP name of the host).

name is the name of the printer as specified in the NAME= parameter in the XCPRT macro.

If a HOB COM driver is used, the NC print and LPD print don't differ in their program invoke. The printer „name“ has to be specified in the XCTCT in this case. For the NC print the port number is required.

The definition of the NC printer in the XCTCPIP table:

LPD:

```
XCTCPIP DS 0F
XCPRT NAME=name,PRT=printername,PRINT=drivernumber,FFONEND...
```

NC:

```
XCTCPIP DS 0F
XCPRT NAME=name,PORT=portnumber,PRINT=drivernumber,FFONEND...
```

NAME=	<i>name</i> is the name of the printer as specified inside HOB COM (printer alias). You can choose any name you want. When you invoke a HOB COM program this name can be referred.
PRT=	<i>printername</i> is the name of the printer on the remote system. (PC)
PORT=	<i>portnumber</i> is the number of the port on the remote system, that was opened for the printer there.
PRINT=	<i>drivernumber</i> is the number of the driver program as entered in the XCPRTAB for the driver program.
FFONEND	The FFONEND (FormFeed on End) parameter is optional.

9.6. PRINTING ON A USER NAME

It is possible to enter a printer batch task in the TCT, that doesn't contain the name of the printer performing the output.

HOBLINK J-Term can create a connection to HOB COM without specifying a device or resource ID. Normally HOB COM can start only one batch task per terminal. If HOBLINK J-Term send no resource ID, the terminal name for this HOBLINK J-Term is generated by HOB COM. On this name the print can be output. As the name is not known before the connection, the definition of a printer task is not possible.

The XCUBT macro has two parameters, BTPRI and PERSNO, that allow you to start batch tasks depending on the user name instead of the terminal name.

The BTPRI parameter allows you to store the information, which terminal name has been started by this task. The terminal name can be generated by HOB COM.

If the parameter PRI= is not set when invoking the print program the storage position will be read that was filled by BTPRI=YES.

If you use the PRI= parameter instead of the OUTFILE= outfile parameter when you invoke the print program, the three part names of the OUTFILE= parameter will be provided. That means, that the terminal name on which the print will be made has to be known before. Thus with the OUTFILE= parameter a resource name has to be sent, but not with the PRI= parameter.

The PERSNO parameter in the XCUBT macro causes that a batch task will be started that depends on the user ID.

Example for starting a batch task depending on a User ID

It is possible to start a batch task, that performs the print on the terminal on which the concerning person logged on.

Example:

```

XCPERS NO=00000055,TYPE=P, X
      NAME=MILLER,PW=PASSWORD, X
      ENKEY=KEY,ENFULL=YES, X
      COMASK=(TEXT,CP,SHU,CAN,DISC,FILE,TCTL,STTE)
.
.
.

XCUBT TASK=HUGO,PERSNO=00000055,BTPRI=YES, X
      COM='EXEC PR3287 SA=sapplname'

```

If the person 'Miller' logs on via HOBLINK J-Term without specifying a resource ID for his PC a name, e.g. TN\$0109 is assigned. HOB COM saves the generated name and starts the task. If the PRVM program will be started by this user the name TN0109 will be entered for the PRI=parameter, as if the following EXEC command would be entered.

```
'EXEC PR3287 SA=sapplname,PRI=TN$0109'
```

If a user sends to HOB COM data with the class A, this data will be output on the PC TN\$0109.

When BTPRI=NO is set, the task name will be used as printer name. In the example above, the task would be started, but HOB COM would try to output the print on a device with the name 'HUGO'. The print will be sent to the PC that specified as resource ID 'HUGO'.

If no terminal exists that has this name, PR3287 will not be started.

Another Example:

```

XCUBT TASK=HUGO,PERSNO=00000055,BTPRI=NO, X
      COM='EXEC PR3287 SA=sapplname,PRI=TN$0001'

```

The task will be started, if the person 'Miller' logs on. The output will be performed on the PC that logged on first without device or resource ID (since HOB COM was started).

9.7. PRINTING OVER SMB

It is possible to print the SMB (Server Message Block) protocol on a PC with HOB COM. The 3270 emulation has not to be installed at the PC.

SMB is a protocol which is used in Microsoft networks. The support for SMB over Netbios and over TCP/IP is contained in Windows and OS/2. HOB COM supports by printing over SMB TCP and UDP on IP corresponding the recommendation RCF 1001/1002, but not TOP/NetBIOS.

In every Windows-Domain exists a Primary Domain Controller (PDC). Further is a WINS server responsible for the arrangement of the TCP/IP addresses to the Windows namen inside of the domain. HOB COM communicates with the WINS server and this one with the PC. It forwards the print data (also over TOP/NetBios) to the printer.

Necessary definitions on the PC:

The PC that will be used for printing should be connected with a local printer and Windows has to be defined. The PC must know the printer.

You have three possibilities:

- a) You need no authorization to address the printer- no password is given.
- b) You need a password to address the printer. All users knowing this password are able to print on it.
- c) (only under NT) only certain users of the domain are able to address this printer with userid and password.

The user who wants to address this printer has to be registered on PDC as user in this case. HOB COM represents to the PDC as user. The corresponding userid and the password will be entered in the HOB COM-TCT at the macro XCSMBDD.

The PC has to be announced at a WINS server The WINS server HOB COM is calling has to know this PC with printer.

Necessary definitions in the HOB COM-TCT:

HOB COM announces oneself in the Windows domain with a own ID (Parameter HCNAMED by XCSMBDD). You can choose it – and it has not to be defined in the Windos domain. A domain name is sent (Parameter DOMAIN by XCSMBDD) which you can also choose. The following definitions are necessary in HOB COM-TCT:

- a) The domain is named where the destination printer is located. The domain is written with the macro XCSMBDD. Several XCSMBDD descriptions are possible. These are located in a new table which you have to create. To create this table you have to the parameter SMBDOM by the macro XTCTGEN:

```
XTCTGEN SMBDOM=XCSMBDOM
```

The table will be inserted in the TCT, but a end marking is necessary:

```
XCSMBDOM    DS 0F
XCSMBDD ...
XCSMBDD ...
DC AL2(0)    ;end marking
```

- b) The printer is described with the macro XCTPRSMB. This macro is called in the table XCTERMA .

```
XCTERMA      DS 0F
XCTPRSMB NAME=test
XCTPRSMB .....
...
XCTPRSMB LASTTE=YES ; end marking of the table
```

The name of the printer is given when you call the printing program (e.g. PR3287) with the parameter PRI= or OUTFILE=.

Example:

```
EXEC PR3287 SA=..,PA=...,PRI=test10
```

The Macro XCTPRSMB

The following parameters are possible:

- TERM=** is the name of the printer inside of HOB COM. You can choose this name and it is given at the program appael with the parameter PRI= or OUTFILE=.
- PRINT=** Here, you specify the treiber code number (e.g 20) of the treiber with that HOB COM should adress the printer.
- SMBDOM=** is the name of the definition who was created with the macro XCSMBDD. This name refers to the domain description (macro XCSMBDD) which is used by the printer.
- NOSESS=** is the number of the session over that you can print. This parameter is optional. The value 0 means that the number of sessions is unlimited. A value unequal 0 signs how many PR3287 tasks at the same PRI= can be printed simultaneously . With Value 1 it is possible to start several printing programs at the same PRI=, but they can only print one after one. If you print simultaneously, the PC will control over the print number – so that the lists are not printed mixed.
- TYPE=** at the moment ist only the entry LPT1 possible
- PCNAM=** Is the name of the PC inside of the Windows domain where the printer is connected. The WINS server receives this name and passes the print datas on the corresponding TCP/IP address.

Attention: The WINS server receives this name in capitals.

- PCPRINAM=** Is the name of the used printer. This name is always known with capitals in the Windows network.
- PW=** If a password for the used printer is entered at the PC it has to be announced to HOB COM. So HOB COM is authorized to print on that printer.
- PROT=** Here the SMB dialect is adjusted which HOB COM should propose by the communication.

Possible values from 0 to 6
 0 = PC Network Program 1.0
 1 = Microsoft Networks 1.03

Attention! By the dialects 0 and 1 no Userid can be sent only a password. The password is used in this case from the macro XCPRTSMB (parameter PW=). Userid is the entry by the parameter HCNAMED in the macro XCSMBDD from the WINS server. If a userid and a password are given in the macro XCSMBDD they will be ignored.

2 = Microsoft Networks 3.0
 3 = LANMAN 1.0
 4 = LM1.2X002

The parameter PROT is optional. The default value is 4.
 Actually, the smallest common value both interlocutors are able is used for the communication.

- LASTTE=** YES or NO (NO is default)
 YES is given if it is the last entry in the table XCTERMA.

Das Makro XCSMBDD

The following parameters are possible:

- NAME=** HOB COM internal name of the domain description. In the table XCSMBDOM are several of this entries possible. Which of that entries the respective printer (defined through XCTPRSMB) uses is defined through the parameter SMBDOM in the macro XCTPRSMB.
- DOMAIN=** this parameter declares the name of the Windows domain.
- HCNAMED=** You can choose this name. HOB COM identifies oneself together with the parameter DOMAIN= in the Windows domain.
- IPADDRP=** The IP address of the WINS server is declared which is called from HOB COM.
- IPADDRS=** this parameter is optional. Here you declare the IP adress of a substitute WINS server if the first is not available at the moment.
- USERID=** this parameter is optional.
- It is necessary if a user authorization and a password from PDC is expected from HOB COM to print on the printer.
- PW=** this parameter is optional.
- It is necessary if a password is expected from PDC and only user should print who know the password.

Example:

```

XCTERMA  DS      0F                      ;ADDRESSES OF THE TERMINALS
          XCTPRSMB  TERM=TEST10,                      X
              TYPE=LPT1:,PROT=0,NOSESS=0,PRINT=20,      X
              SMBDOM=HCDOM,PW=test,                    X
              PCNAM=WRKST,                              X
              PCPRINAM=wrk_stpr
          XCTPRSMB  TERM=TEST20,                      X
              TYPE=LPT1:,PROT=2,NOSESS=0,PRINT=10,      X
              SMBDOM=HCDOM,                              X
              PCNAM=wrkst2,                              X
              PCPRINAM=wrk_st2pr
          XCTPRSMB  TERM=TEST30,                      X
              TYPE=LPT1:,PROT=4,NOSESS=0,PRINT=0100,    X
              SMBDOM=HCDOM,                              X
              PCNAM=WRKST3,                              X
              PCPRINAM=WRKST3PR,                        X
          LASTTE=YES                      ;Endekennung
XCSMBDOM  DS      0F                      ;DOMAIN BEGINNING SMB-DRUCK
          XCSMBDD  NAME=HCDOM,DOMAIN=DOM100,HCNAMED=HOB COM,      X
              IPADDRP=123.45.678.121,IPADDRS=194.45.234.121,      X
              USERID=Test,PW=test
          DC      AL2(0)                      ;END MARKING

```


10. HOB COM DRIVER ROUTINES

HOB COM driver routines build interfaces between your system environment and HOB COM uses.

They consist principally of three parts, that are separated from each other through a point: the first part is always fixed and contains the driver name. The two following parts differenciate with the different drivers and depend partly on the uses.

10.1. \$SPOOL

The driver routine \$SPOOL is necessary for printing; the output results either on a terminal printer or it will be temporarily stored on a disk (the last is only possible using HOBTEXT or HOBLIST). Please note that at the moment we have no program that passes on files that are on disks to a printer!

The FAX output will also be stored onto disks (only with FAX option!).

\$SPOOL puts the list onto disks in HOBLIST format, looking at it with EDLI is possible (HOBTEXT modul HOBLIST).

1. part filename (fix): \$SPOOL

The second part-filename will give the name of the terminal, onto which the chosen printer will be connected. If the printing should be done on disk, the terminal name is still to be entered (this name then serves as binder name for the archives).

The third part-filename can be chosen out of the following options:

\$NORMAL	ormal printing; when the printer is occupied the user must wait until the printer is either free and the output is ended
\$DIRECT	directly onto terminal printer; when the printer is occupied, an error report will be given and the printing is interrupted
\$PERM	terminal printer, permanently appointed
\$IMM	immediate print; when the printer is occupied the print output is detoured onto disk

Eintrag aus XCJCLTAB print onto disk

Notice to printing on disks:

In the HOB COM-TCT, the Macro XCJCL3 in the XCJCLTAB can be used to steer the output onto disk:

```
XCJCLTAB DS      0F
XCJCL3  NAME=name , DISP=H , CLASS=F , PRI=7 , SPFIL3=TSP#
```

You enter a random, maximally 8 digit string as a name; we suggest \$SPOOL!

Disposition (DISP=), class (CLASS=) and Printer (PRI=) are not evaluated at the moment. These entries become meaningful when a program is available, that sends a file from the disk to the printer. SPFIL3 specifies the name under which the file will be stored in the archives (in the above example TSP plus a sequentual number).

The output on disk results in EDLI format, i.e. the file will be stored in the cabinet SPOOL in the archives. The binder name results out of the second part file name of the driver.

10.2. \$PUN

The driver routine \$PUN can send data into the punch system. There is no translation into ASCII format.

1. part filename (fix): \$PUN

The second part-filename defines the output format:

PUN	punch format; makes unchanged output of the record contents possible when the lines are not longer then 80 digits.
PRINT	print format; causes the HOB feedbyte to be split into two characters aufgeteilt wird und records, that do not fit onto a hole card (column 3 to 71), to be set up.

The third part filename will be entered in the XCTCT as a name out of the XCJCLTAB (NAME=...), that is responsible for the necessary job control.

10.3. \$PRINT

The driver routine \$PRINT makes print output on a system printer possible.

It transferres i.e. a HOBTEXT text into IBM format and makes output possible on printers that tolerate no HOBTEXT format. There is especially no transfer into ASCII format.

1. part filename (fix): \$PRINT

2. part filename: name entered in the XCJCL4 macro for NAME= in the XCTCT

3. part filename: name of the print output in the power list queue

Example:

In the XCJCLTAB exists a JCL entry with name TEST-UP. Then the driver routine is called as follows:

\$PRINT.TEST-UP.TEST

, whereas TEST is the name of the printout in the power list.

You will find information about the pertaining entries in the XCJCLTAB of the TCT.

10.4. \$SCREEN

The contents of a virtual terminal of the real terminal, on which one is just working on can be read with help of the driver routine \$SCREEN.

1. part filename (fix): \$SCREEN

The second Part-filename determines the number of the virtual terminal, from which will be read:

Pn instead of n enter the number of the virtual terminal (1, 2, 3 or
4)

xxxxxx the third part filename is not being evaluated at the moment

This driver routine is used by HOBTEXT to read the contents of a second virtual terminal. Example invoke:

```
$SCREEN.P3.xxxxxx.
```

10.5. \$TCT

The driver routine \$TCT reads entries of the printer parameter from the VCTCT.

1. part filename (fix): \$TCT
2. part filename (fix): PARAM

Enter as third part filename the name of the chosen parameter from the VCTCT (table XCPRPAR).

Example invoke:

```
$TCT.PARAM.FSP10H
```

10.6. \$DIALOG

The driver routine \$DIALOG opens a virtual terminal, which makes communication (reading and writing) with any optional sub-system possible.

1. part filename (fix): \$DIALOG

The second part filename is the name of the dialog as it is defined in the VCTCT.

The third part filename depends on, if data will be read or written:

- for reading, give the system name of the file from which will be read
- for writing enter the name of the VM user on whose console the data shall be written.

If you want further information about the dialog driver routine, please contact the HOB-software-support.

10.7. \$VSAM

With \$VSAM you have access to a VSAM file. The access via index (key is supported). Every task, that opens an access with \$VSAM creates its own ACB. Several ACBs can be opened per file. It is not possible to write data.

1. part filename (fix): \$VSAM

The second part filename marks the type of the file: ESDS (without key) or KSDS (with key).

The third part of the filename gives the name of the file. This name is entered in the XCTCT using the XCJCL2 macro.

Example:

In HOBTEXT data of a VSAM file can be transferred into the text processing system. In the file description the desired file is announced to the system:

```
cDATA EXTERN $VSAM.KSDS.FILE01
```

(Please note that c stands for the context command character 'c in the box'). Like this a file with key field is defined, the name of the file is entered in the XCTCT as follows:

```
XCJCLTAB DS      0F
          XCJCL2 NAME=DATEI1
          CODD    DSN=SDATEI.VSAMT1,DISP=SHR
          XCJCL2J
          XCJCL2E
          DC      AL2(0)
```

Instead of SFILE.VSAMT1 you have to write the name, under which the file is stored in the system, while for FILE01 the name that is to be valid in HOBTEXT has to be entered.

```
// DLBL FILE01,'SFILE1',,VSAM,CAT=CATx
// EXTENT ,DISK
```

In the DLBL-Statement the system name of the file (SFILE1) and the file name that will be used in HOBTEXT (FILE01) are given. Instead of CATx the name of the VSAM catalogue must stand, in which the file is listed, instead of DISK, the name of the disk on which the file is stored.

10.8. \$PDS

With the driver routine \$SPDS information can be read into HOBTEXT out of partitioned-data-sets.

1. part filename (fix): \$PDS

The second part filename marks the data set name in the XCTCT (NAME=..).

The third part filename contains the actual member name. Since this name is not given in the XCTCT, any chosen member of a library can be read, as long as it is defined as partitioned data set in the XCTCT.

Example: the member MODTABCX in the partitioned-data-set CODIS.LIB1 should be read.

In the XCTCT is defined:

```
XCJCLTAB DS      0F                      ;JCL-EINTRÄGE
          XCJCL2 NAME=CODL
          CODD    DSN=HOB COM.LIB1,DISP=SHR,VOL=SER=DISK01
          XCJCL2J
          XCJCL2E
          DC      AL2(0)                  ;ENDE DER TABELLE
```

The contents can now be read with the file names \$PDS.CODL.MODTABCX.

An enlargement that enables writing is possible when necessary. Up to now write access to PDS members is only possible with \$PUN.

11. MESSAGES

11.1. GENERAL REMARKS

This manual contains two basic kinds of error messages: those which appear only at the HOB COM console, and those which appear at user terminals.

Console messages can be found in the following chapters:

HOB COM Direct Error Messages at the Terminal Console Messages (XCM, XCT) All other error messages belong to the group of messages which appear at the user terminal.

The first four characters in the error message indicate the name of the program from which the message originated. For example, ERROR NOTE0003, indicates that the program NOTE issued the message.

11.2. HOB COM CONSOLE MESSAGES ON THE HOB COM TERMINAL

PARTITION/PROGRAM NOT SPECIFIED

P1, P2, P3 or P4 has not been specified to indicate the partition or program. Insert P1 or P2, etc. in front of the command.

NO TASK GENERATED

The user has attempted to enter "UNLOAD" or "UNBATCH" although no task has been generated on the corresponding virtual terminal. Enter "UNLOAD" and "UNBATCH" only for virtual terminals in which tasks have been generated.

PROGRAM RUNNING IN SPECIFIED PARTITION/TASK

A program has been invoked in a partition or task in which a program is already running.

NO PROGRAM LOADED IN SPECIFIED PARTITION

The user has attempted to terminate a program in a given partition using the UNLOAD command, although no program had been loaded by LOAD in the partition concerned. Check whether a program is running at all in the specified partition. If there is, check how the program is to be terminated.

PROGRAM UNLOAD ALREADY ACTIVE

An UNLOAD command has been entered although UNLOAD is already active. Wait until the UNLOAD command has been executed.

WRONG TEXT AFTER COMMAND

A text has been entered after one of the following commands UNBATCH, UNLOAD, CANCEL or LOGOFF. The command must be entered without subsequent text.

NO PROGRAM RUNNING IN SPECIFIED PARTITION

The user has attempted to terminate the program in the given partition, although no program is running in the partition concerned. Check which partition is to be terminated. Correct the partition number if necessary.

SPECIFIED PROGRAM HAS NO CANCEL EXIT

The user has attempted to terminate a program that does not have a cancel exit. The program must be terminated in the usual manner.

NO COMMAND ENTERED

The "ENTER" key has been pressed without entering a command. Enter a command.

INVALID COMMAND

An invalid command has been entered. Enter a valid command. NO PROGRAM NAME ENTERED The ENTER key has been pressed after the command EXEC without entering the program name. Enter a valid program name after "EXEC".

NO PROGRAM NAME GIVEN

'Enter' or 'DatFreig' - key typed, without typing a program name after the „EXEC“ - command.

PROGRAM NAME TOO LONG

Either a program name with more than eight characters has been entered, or no space has been left between the program name and subsequent parameters. Enter a valid program name with up to eight characters.

PROGRAM DOES NOT EXIST

The user has attempted to invoke a program that does not exist. Enter a valid program.

PARTITIONS/PROGRAMS STILL ACTIVE

The user has attempted to enter LOGOFF in the HOB COM console, although applications are still running in other virtual terminals. Applications in progress must be terminated before entering LOGOFF.

NO COMMAND STORED

Function key F5 or F6 has been pressed after switching on the terminal, although no command has been entered and stored. The first command (and commands in general) is stored after being entered and can then be repeated using the function keys F5 and F6.

NO STORAGE SPACE AVAILABLE

The main storage space managed by HOB COM is full. Increase the value of the SIZE statement for the partition or class in which HOB COM is running. (Refer also to the installation description, Section 5).

PROGRAM CANNOT BE INVOKED BY EXEC

The user has attempted to load program XC\$DA with the EXEC command. The command "LOAD XC\$DA" must be entered to load program XC\$DA.

PROGRAM CANNOT BE INVOKED BY LOAD

The user has entered LOAD to invoke a program that can only be invoked by a different command. Enter the corresponding program name after LOAD.

WRONG TEXT AFTER USSTAB COMMAND

Text has been entered after the command abbreviation. Enter only the command abbreviation.

INCORRECT USSTAB GENERATION

An incorrect command has been generated for USSTAB generation. Ask your system programmer for assistance.

PROGRAM/PARTITION NOT AVAILABLE

A connection to another HOB COM has been established using REVM. In the process the virtual terminal number Pn in the command line has been written over; this is invalid because REVM makes only one virtual terminal available.

11.3. HOB COM CONSOLE MESSAGES UNDER MVS (XCM, XCT)

HOB COM Main Task Messages

*XCM00001 START HOB COM 1.2 E * D xx.xx.xx*

The HOB COM program, version 1.2, has been started.

XCM00002 SUBPOOL SIZE FOR THIS START-UP IS xxx K

HOB COM has been allocated xxx K main storage space which will be managed dynamically. This message appears only in the DOS version of HOB COM; in the MVS version the necessary storage space is provided by the operating system.

XCM00003 NOT ENOUGH MAIN-STORAGE

HOB COM has not been allocated enough main memory space; HOB COM is terminated immediately. This message is used only in the DOS version of HOB COM and does not appear in the MVS version of HOB COM.

XCM00004 NO STORAGE AVAILABLE - ABEND

HOB COM is terminated because no more storage space is available. This situation should not occur, since HOB COM usually reserves sufficient storage space. Should this message appear, inform the HOB Software Service and allocate more storage space.

XCM00006 SHORT-ON-STORAGE

The virtual storage managed by HOB COM is insufficient.

XCM00007 PHASE xxxxxxxx NOT LOADED - GETVIS RC=

The XCTCT phase xxxxxxxx could not be loaded. The GETVIS of this partition is probably too small.

XCM00008 DUMP

HOB COM has created a dump. Please contact your system manager or the HOB Software Support.

XCM00009 END PROG HOB COM

The program HOB COM has been ended.

XCM00011 STOP-ROUTINE ENTERED

This message appears in MVS when STOP xxx is entered (xxx is the name of HOB COM job).

XCM00012 USER TASK STILL ACTIVE

If HOB COM could not be terminated because users are still active, this message appears in MVS after the message XCM00011 has been displayed. Terminal Control Task Messages

XCTM0001 ID=xxxxxxx LOGON

Terminal xxxxxxxx has logged on to HOB COM.

XCTE0002 ID=xxxxxxx POWER ON

The power ON code of a non-SNA terminal has been received.

XCTE0003 ID=xxxxxxx POWER ON

The power ON code of an SNA terminal has been received.

XCT00004 ID=xxxxxxx POWER OFF

The power OFF code of an SNA terminal has been received.

XCT00005 ID=xxxxxxx LUSTAT SENSE=xxxxxxx

The logical unit status of an SNA terminal has been received. The meaning of the codes can be found in the IBM publication, "VTAM Reference Summary: SNA Reference Data".

XCTE0006 ID=xxxxxxx RECOVERY

Terminal xxxxxxxx was switched off or disabled as a result of an error and is now being resynchronized.

XCTM0007 ID=xxxxxxx DISCONNECT

The session between HOB COM and the terminal has been ended.

XCTM0010 ID=xxxxxxx LU=xxxxxxx LOGON-ERR - DUPLICATE TERMINAL

With an E- or S - Terminal you tried to connect to HOB COM, although the name in the HOB COM TCT with the macro XCTLTS, is registered for Laptop slave

XCTM0011 ID=xxxxxxx LOGON-ERROR - ALREADY OPENED

You have tried to logon a terminal whose name already exists in HOB COM.

XCTM0012 ID=xxxxxxx LOGON-ERROR - INVALID LOGON-MESSAGE

While LOGON to a S-Screen to HOB COM over the parameter DATA a LOGON message was sent

XCTM0013 ID=xxxxxxx LOGON-PARAMETER FROM LOGON-MESSAGE S-xx

While LOGON of an S-Screen to HOB COM the LOGON message S-xx was sent.

XCTM0014 ID=xxxxxxx ERROR S-TERMINAL BIND-PARAMETER

While connecting HOB COM to an S - Terminal, from VTAM it became a wrong Bind,e.g VTAM sends the Bind for model 1. These can't be processed by HOB COM

XCTM0015 ID=xxxxxxx S-TERMINAL NUMBER OF SESSION EXCEEDED

The number of S - Sessions, declared in the HOB COM Password was crossed.

XCTM0016 ID=xxxxxxx LAPTOP NOT ALLOWED (PASSWORD)

In your HOB COM Password,the LOGON of a PC or Laptop over HOB COM Asynchron is denied.

XCTM0017 ID=xxxxxxx LOGON-MESSAGE IGNORED

Because of that the you are already logged in with your screen, e.g. as E - Screen, your message was ignored.

XCTM0020 LU=xxxxxxx CLSDST-ERROR RTNCD=xx FDBK2=xx SE=xxxxxxx

VTAM registers an error. Consult the IBM manual, VTAM Messages, in particular the chapter on Return Codes/Sense Fields and Return Code Posting.

XCTM0021 LU=xxxxxxx ERR R=xx RTNCD=xx FDBK2=xx SENSE=xxxxxxx

VTAM registers an error. Consult the IBM manual, VTAM Messages, in particular the chapter on Return Codes/Sense Fields and Return Code Posting.

XCTM0022 ID=xxxxxxx ERR R=xx RTNCD=xx FDBK2=xx SENSE=xxxxxxx

VTAM registers an error. Consult the IBM manual, VTAM Messages, in particular the chapter on Return Codes/Sense Fields and Return Code Posting.

XCTM0023 ID=xxxxxxx NSEXIT NSH=xxxxxx CLEANUP

The session between HOB COM and the terminal has been ended.

XCTE0030 ID=xxxxxxx TERMINAL ERROR

Terminal xxxxxxxx has sent an error message to HOB COM. Contact the HOB Software Service.

The following is a list of possible errors:

TERMINAL-ERROR A : incorrect switch off instruction.

TERMINAL-ERROR B : wrong IDT-Byte.

TERMINAL-ERROR C : the entry field defined does not begin on the terminal screen. This means that the displacement of the entry field is not between 0 and 780H.

TERMINAL-ERROR D : wrong end address (entry field is longer than the terminal screen.)

TERMINAL-ERROR E,F: Wrong character type.

TERMINAL-ERROR H : entry length incorrect.

TERMINAL-ERROR I : the cursor is not in a defined data entry field.

TERMINAL-ERROR J : 2 windows sent.

XCTE0031 ID=xxxxxxx TERMINAL DATA ILLOGIC

Terminal xxxxxxxx has sent illogical data to HOB COM. Contact HOB software Service.

XCTM0040 ID=xxxxxxx ERROR (OUTPUT FORMAT)

Internal HOB COM error, the output format of a virtual screen is ncorrect. Contact HOB Software Service.

XCTE0041 ID=xxxxxxx NO SCREEN TO OUTPUT

HOB COM has made several unsuccessful attempts to process a irtual screen for output. This may be due to the fact that HOB COM is running with a very low priority; or it may be due to an internal HOB COM error. Contact HOB Software Service.

XCTE0042 ID=xxxxxxx SCREEN HAS ERROR

Internal HOB COM error: the output of a virtual screen is incorrect. Contact HOB Software Service.

XCTE0043 ID=xxxxxxx OUTPUT HAS INVALID SCREEN FORMAT

Internal HOB COM error: the output of a virtual screen in HOB mode is incorrect. Contact HOB Software Service.

XCTE0044 ID=xxx OUTPUT HOB-MODUS HAS ERROR

The program you invoked, uses a screen format which is not supported by your machine. Choose a suitable screen format.

XCTM0050 ID=xxxxxxx LOG-ERR RTNCD=xx FDKB2=xx SENSE=xxxxxxx

An error was indicated while logging on a real terminal xxxxxxxx. Refer to the VTAM manual, VTAM Programming, in particular the chapter on Return Codes/Sense Fields and Return Code Posting:

Return Code Combination.

XCTM0051 ID=xxxxxxx LOSTERM RC=xx (HEXA)

A terminal has been logged off; refer to VTAM Manual, VTAM Programming, in particular the chapter on Using Exit Routines, Lost-Term. The connection to the real terminal xxxxxxxx has been severed, due either to the operator command V NET,TERM,ID=, or a data transmission line failure.

XCTE0052 ID=xxxxxxx REC-ERR RTNCD=xx FDBK2=xx SENSE=xxxxxxx

HOB COM has received an error message from terminal xxxxxxxx. A receive error has been registered. For more information refer to the VTAM manual, VTAM Messages, in particular the chapter on Return Codes/Sense Fields and Return Code Posting: Return Code Combination.

XCTE0053 ID=xxxxxxx SEND-ERR RTNCD=xx FDBK2=xx SENSE=xxxxxxx

HOB COM has received an error message while sending a record to terminal xxxxxxxx. Refer to the VTAM manual, "VTAM Messages"; in particular the chapter on Return Codes/Sense Fields and Return Code.

*XCTE0054 ID=xxxxxxx SEND ERROR * POWER OFF*

HOB COM has determined, while sending a record to terminal xxxxxxxx, that the terminal is turned off. The terminal was not switched off properly using LOGOFF.

XCTE0055 ID=xxxxxxx ERR R=xx RTNCD=xx FDBK2=xx SENSE=xxxxxxx

An error was indicated while executing the VTAM request R=XX. Refer to the VTAM manual, "VTAM Messages", in particular the chapter Return Codes/Sense Fields and Return Code Posting: Return Code Combination.

XCTE0056 ID=xxxxxxx WRONG SNA-COMMAND RECEIVED

Terminal xxxxxxxx has received invalid commands from the controller.

*XCTE0057 ID=xxxxxxx SEND ERROR * POWER OFF*

HOB COM has received the response that the send line is switched off. The terminal was not switched off correctly via LOGOFF.

XCTE0058 ID=xxxxxxx WRONG CID RECEIVED

HOB COM has determined while checking the CID=SESSION-ID that it is incorrect. Either the terminal control unit or VTAM has sent an incorrect CID.

*XCTM0059 RECEIVE-ERROR R115=xx RTNCD=xx FDBK2=xx * WAIT*

While processing a receive command, VTAM indicates an error, e.g. VTAM has no more storage space available. HOB COM waits 16 seconds and then prepares another receive command.

XCT00060 ID=xxH LOGON-ERR - TERMINAL ALREADY EXISTS

You have tried to log on a terminal whose name already exists in HOB COM.

XCT00061 LU= ERR R= RTNCD=xxH FDBK2=xxH

VTAM registers an error. Consult the IBM manual, VTAM Messages, in particular the chapter on Return Codes/Sense Fields and Return Code Posting.

XCTM0091 ID=xxxxxxx LOGON - GETMAIN / GETVIS ERROR

Terminal xxxxxxxx has logged on to HOB COM, but due to insufficient storage the logon cannot be carried out.

XCTM0092 ID=xxxxxxx LOSTERM - GETMAIN / GETVIS ERROR

Terminal xxxxxxxx is to be logged off from HOB COM, but there is no storage space free.

XCTM0093 ID=xxxxxxx RELREQ - GETMAIN / GETVIS ERROR

Not enough memory to call the EXIT Routine RELREQ.

XCTM0094 ID=xxxxxxx NSEXIT - GETMAIN / GETVIS ERROR

Not enough memory to call the EXIT Routine NSEXIT.

XCTM0101 TPEND - HALT NET NORMAL

VTAM has been ended using the command Z NET. HOB COM is also ended, if no users are active.

XCT00102 TPEND - HALT NET QUICK

VTAM has been ended using the command Z NET,QUICK. HOB COM is also ended, if no users are active.

XCTM0111 ACB OPEN ERROR xxH ID=xxxxxxx

An OPEN-ERROR is indicated while opening the VTAM-ACB of the terminal control task (normally ID=CODIS). The error code is displayed in hexadecimal form (xxH = hexadecimal). Refer to the VTAM Programming manual, in particular the chapter on Description of the VTAM Macro Instructions.

*XCTM0111 ACB OPEN ERROR XXH ID=xxxxxxx * NOT DEFINED*

This is a special form of the error message XCT0111: An OPEN-ERROR is indicated while opening the VTAM-ACB of the terminal control task (normally ID=CODIS). The error code indicates that the VTAM node has either not been defined or has been inactivated. The corresponding VTAM node must be activated. Consult the VTAM Programming Manual, in particular the chapter on the Description of the VTAM Macro Instructions.

*XCTM0111 ACB OPEN ERROR XXH ID=xxxxxxx * ALREADY IN USED*

Special form of error message XCT0111: An OPEN-ERROR is indicated while opening the VTAM-ACB of the terminal control task (normally ID=CODIS). The error code indicates that the VTAM node is already being used by another job. Check whether HOB COM is already active (in another partition or another task). For further information consult the VTAM Programming Manual, in particular the chapter entitled Description of the VTAM Macro Instructions.

XCTM0112 ACB CLOSE-ERROR xxH

An error is indicated while closing the VTAM-ACB of the terminal control task. The error code is displayed in hexadecimal form (xxH = hexadecimal). Refer to the VTAM Programming Manual in particular the chapter covering the Description of VTAM Macro Instructions.

*XCTE0300 ID=xxxxxxx LAPTOP START * LU=xxxxxxx*

The connection between a PC with HOB COM asynchron and HOB COM was built. As ID Name, the VTAM Name of the PC was used, LU is the HOB COM intern name of the PC. This name was saved in the PSETUP on the PC under PSEUDO-LU NAME.

*XCTE0301 ID=xxxxxxx LAPTOP LU OCCUPIED * xxxxxxx*

Another PC with the same PSEUDO LU NAME is already logged in.

*XCTE0302 ID=xxxxxxx LAPTOP LU MISSING * xxxxxxx*

The name, which is registered as PSEUDO LU NAME in the PSETUP on the PC, could not be found in the HOB COM TCT. Please register this terminal with the makro XCTLTS.

*XCTE0303 ID=xxxxxxx LAPTOP LU NOT LT * xxxxxx*

The name, which is registered in the PSETUP on the PC under PSEUDO LU NAME, is defined in the HOB COM - TCT with a wrong Macro. Please register the Terminal with the macro XCTLTS.

XCTE0304 ID=xxxxxxx INVALID LTKEY LT= xxxxxx KEY=xxxxxxx

The in the HOB COM - TCT declared LTKey is different to the LTKEY in the PSETUP on the PC.

XCTE0305 ID=xxxxxxx INVALID PU-TYPE LT= xxxxxx PU-TYPE=xx

11.4. COBA MESSAGES

FUNCTION NOT DEFINED

The function number entered is not listed in the menu.

NO STORAGE AVAILABLE

The main storage managed by HOB COM is full. Increase the value of the SIZE statement for the partition or class in which HOB COM is running. (Refer to the Installation Guide) SYNTAX OF TASK-NAME NOT CORRECT The task name entered does not start with a letter. Task names must start with a letter and can have a maximum length of eight characters.

TASK-NAME ALREADY IN USE

The task name selected is already in use.

TASK NOT FOUND

The user has attempted to establish a connection to a nonexistent task via function 2 (CONNECT TASK).

TASK IS ALREADY CONNECTED

The task entered is already running on another virtual terminal.

A PROGRAM IS ALREADY ACTIV

The user has attempted to invoke a program in a task in which a program is already running.

WRONG TEXT AFTER THE COMMAND

Text has been entered after the command CANCEL. The command must be entered without any text.

IN THIS PART. NO PROGRAM LOADED

You entered the command CANCEL although no batch program was started.

THIS PROGRAM HAS NO CANCEL EXIT

The user has attempted to terminate a program which does not have a cancel exit.

NO COMMAND SPECIFIED

You pushed the data release key without entering a command.

NO COMMAND IN BUFFER

No command has been entered in the batch console which can be stored.

NO STORAGE AVAILABLE

The main storage managed by HOB COM is full. Increase the value of the SIZE statement for the partition or class in which HOB COM is running. (Refer to the Installation Guide)

COMMAND NOT FOUND

An invalid command has been entered.

NO PROGRAM-NAME SPECIFIED

The user has pressed the 'ENTER' key after the word "EXEC" without entering a program name.

SPECIFIED PROGRAM-NAME TOO LONG

The program name entered is longer than eight characters or no spaces have been left between the program name and the subsequent parameters.

SPECIFIED PROGRAM NOT FOUND

The user has attempted to invoke a program that does not exist.

PROGRAM IS NOT EXEC -UTABLE

You wanted to start a program with EXEC that has to be called with LOAD.

PROGRAM MUST BE CALLED FROM TERMINAL

The user has attempted to invoke a program from the batch console, this program, however, can only be invoked from the HOB COM console of a virtual terminal.

PARAMETER-STRING HAS MORE THAN 64 CHARACTERS

The parameter string must not be longer than 64 characters. Use an abbreviated form for each parameter.

WRONG TEXT AFTER USSTAB-COMMAND

You entered a text after the abbreviated command. Enter only the abbreviated command.

USSTAB-COMMAND WRONG GENERATED

The command abbreviation is wrongly defined in your HOB COM TCT. Please check your entry and if necessary contact your system programmer.

11.5. COVTC/COVTOP MESSAGES*ERROR 10000001 COMMAND IS INVALID*

The command entry was incomplete or incorrect.

ERROR COVT0001 NO PAPPL=... IN COMMAND

The parameter string was not entered when invoking the program COVT.

ERROR COVT0002 NO SAPPL=... IN COMMAND

The parameter string was not entered when invoking the program COVT. Since a table of SAPPL entries was not generated in the HOB COM system, a SAPPL must be entered.

ERROR COVT0003 EXIT-R

You can build your own Exit Routines into your XCTCT that give back error codes. These are put out under these error numbers.

ERROR COVT0004 SAPPL=xxxxxxx NOT DEFINED

The virtual terminal name entered has not been defined.

ERROR COVT0005 SAPPL=xxxxxxx ALREADY ACTIVE

The virtual terminal (VTAM node) ... is already being used for a different purpose. Recall COVT and enter a new SAPPL.

ERROR COVT0006 SAPPL=xxxxxxx OPEN ERROR xxH

Program COVT or COVTOP found an error while opening the VTAM ACB. Consult the VTAM Manual to find the cause of the error or notify the HOB Customer Service.

ERROR COVT0007 PAPPL=xxxxxxx NOT DEFINED (x)

The primary application entered (e.g. CICS, TSO, IMS) has not been defined.

ERROR COVT0008 PAPPL=xxxxxxx NOT ACTIVE (x)

The required primary application (application program, e.g. CICS, TSO, IMS) is not active and therefore cannot be selected.

ERROR COVT0009 LOGMODE NOT DEFINED

The LOGMODE entered is not defined in your MODTAB. Ask the system programmer for a valid LOGMODE.

ERROR COVT0010 LOGON REJECTED RC=xx SENSE=xxxxxxx

A logon to the primary application has been rejected. The RC and SENSE values indicate the cause. Consult your VTAM Manual, "VTAM Messages", the Chapter on Return Codes/Sense Fields and Return Code Posting: Return Code Combination.

ERROR COVT0011 NO BIND (OUT OF SERVICE)

The selected application does not send a Bind, no connection is established. This may be because the virtual terminal (SAPPL) has been set OUT OF SERVICE.

ERROR COVT0012 NO SDT (NON-SNA INSTALLATION)

The requested application does not send a SDT command (SDT = set data traffic). The BIND parameters registers that the connection has already been made. A possible cause is that the virtual screen (SAPPL) has been incorrectly installed in the application program (e.g. in CICS), for example as a non-SNA terminal.

ERROR COVT0013 NO UNBIND - TIME LIMIT

The session with the requested VTAM application has been terminated but the VTAM application has not sent an UNBIND; for this reason, the session is terminated by COVT. This may be because the VTAM application has been terminated abnormally.

ERROR COVT0014 REQ:xxH RTN xxH FTM xxH

An error has been reported to the program COVT, COVTC or COVTOP. The request code for the current access is xx. Refer to the VTAM Manual to find the cause of the error or inform HOB Customer Service.

ERROR COVT0015 SAPPL=... CLOSE-ERROR xxH

An error was reported to program COVT while closing the VTAM-ACB. Refer to the VTAM Manual, "VTAM Programming", chapter, "Description of the VTAM Macro Instructions", to find the cause of the error or inform the HOB Customer Service.

ERROR COVT0016 xxxxxxxx R15=xxH R00=xxH

The VTAM access xxxxxxxx (e.g. GENCB) has been incorrectly terminated with the return code xx. Refer to the VTAM Manual, "VTAM Messages", chapter, "Return Codes/Sense Fields and Return Code Posting: Return Code Combination", to find the cause of the error or inform the HOB Customer Service.

11.6. NOTE MESSAGES

Error Messages When Invoking Note:

ERROR 10000001 COMMAND IS INVALID

The command entered was either incomplete or incorrect.

ERROR NOTE0002 OUTFILE AND PRINTER NAME ENTERED

You may use only one of the two parameters for calling.

ERROR NOTE0003 OUTFILE AND SFN3 ENTERED

You may use only one of the two parameters for calling.

ERROR NOTE0004 INVALID OUTFILE FILE NAME

The name given at parameter OUTFILE is wrong. Compare the build-up of the parameter in chapter 'parameter at calling'

ERROR NOTE0005 PRINTER NAME IS INVALID

The printer name entered cannot be found or no printer has been generated for the terminal specified. A second possibility is that the REVP has not been started.

ERROR NOTE0006 PRINTER PARAMETER NAME INVALID

The printer parameter name entered could not be found in the table. Check the XCTCT or the VCTCT to see if the parameter has been entered correctly.

ERROR NOTE0007 PARAMETER TERMINAL ONLY IN BATCH

TERMINAL=... was entered when invoking NOTE as a dialog program. This parameter is only valid for batch tasks.

ERROR NOTE0008 TERMINAL NOT FOUND

The terminal entered after TERMINAL= is not listed in the XCTCT or VCTCT.

ERROR NOTE0009 TERMINAL NOT ACTIV

The terminal entered with TERMINAL= is not active.

ERROR NOTE0010 HARDCOPY ALREADY DEFINED

The hardcopy key can only be assigned to one program. In this case, the hardcopy key was already defined by a preceding call.

ERROR NOTE0011 TASK DISCONNECTED BY TERMINAL

A hardcopy is to be entered for a disconnected task. First execute the command GETTASK for this task.

ERROR NOTE0012 IN BATCH SOFTCOPY NOT ALLOWED

Parameter SOFTCOPY was entered when invoking program NOTE for a batch task. This parameter cannot be executed.

Program Error Messages

ERROR FUNCTION NOT DEFINED

You have entered a function number which is not defined in the menu.

ERROR ENTER PROGRAM-NUMBER 1 TILL 4

A terminal number between 1 and 4 corresponding to P1 to P4 must be entered.

ERROR NO SCREEN THAT CAN BE STORED

The screen content of the corresponding virtual terminal cannot be saved or printed.

ERROR ENTER ADDRESS 1 TILL 8 IN STORE

A memory location number between 1 and 8 must be entered because you have saved more than one screen.

ERROR THERE IS NO SCREEN IN STORE

No screen has been stored.

ERROR ONLY ONE SCREEN IN STORE

Only one screen has been stored.

ERROR BACKGROUND PRINT IS ACTIV

Your print output can not follow immediately because a background print is activ.

ERROR TERMINAL-NAME IS INVALID

The first character of the printer name may have been entered as a space. The first character may not be a space.

ERROR TERMINAL-NAME IS NOT GENERATED

You gave the name of a not generated terminal as a printer name.

11.7. PR3287 MESSAGES

ERROR 1000001 COMMAND IS INVALID

The command entered is either incomplete or incorrect.

ERROR PR010001 PROGRAM IS BATCH-P

The selected program can only be invoked from the HOB COM console.

ERROR PR010002 EITHER OUTFILE OR PRINTER-NAME

You may use only one of the two parameters for invoking.

ERROR PR010003 EITHER OUTFILE OR SFN3

You may use only one of the two parameters for invoking.

ERROR PR010004 INVALID OUTFILE FILE-NAME

The name entered at the parameter OUTFILE is wrong. Compare the build-up of the parameter in chapter 'Parameter at invoking'

ERROR PR010005 PRINTER PARAMETER NAME INVALID

The parameter entered for the printer form is incorrect.

ERROR PR010006 SESSION ACTIVE - LOGON NOT POSSIBLE

A LOGON to a VTAM application has already been executed.

ERROR PR010007 NO SESSION ACTIVE - NO LOGOFF

The session with the VTAM application was not activated or has already been ended.

ERROR PR010008 WRONG TEXT AFTER COMMAND

Text has been entered following the command LOGOFF, SHUTDOWN, GO or HALT. These commands must be entered without subsequent text.

ERROR PR010009 P-E

HOB COM has received an error message from the printer (hardware error). Consult the following list for the meaning of the error messages:

01010001 Terminal non-existent

A print task must be started for this terminal. Use EXEC COBA.

01010002 no printer generated

There is no driver entered in the TCT for this printer

01010003 Terminal is turned off

Turn the terminal on and enter "GO" in the COBA.

01010004 Printer is turned off

Turn the printer on and enter "GO" in the COBA.

01010005 Driver program not available

The selected driver has not been entered in the TCT.

01010006 Printer is busy

01010101 unknown Printer

either entry in JCL Table missing or wrong print - command

01050001 The terminal has been switched off while printing

Turn the terminal on and enter "GO" in the COBA.

01050002 The printer has been turned off while printing

Turn the printer on and enter "GO" in the COBA.

01050003 Wrong Load parameters

The print parameters entered in the TCT are incorrect.

01050004 Attribute record duplicate

Restart the print operation. If this message appears again, notify HOB Software Support.

01050005 After the attribute record, no normal record

Restart the print operation. If this message is displayed again, notify HOB Software Support.

00000011 HOBTEXT is using the printer

Wait a while and then reenter the print command

ERROR PR010010 NO PAPPL=xxxxxxx IN COMMAND

The parameter string was entered incorrectly when invoking program PR3287.

ERROR PR010011 NO SAPPL=xxxxxxx IN COMMAND

The parameter string was entered incorrectly when invoking program PR3287. A SAPPL entry must be made, because a table of SAPPL entries was not generated by HOB COM.

ERROR PR010012 SAPPL=xxxxxxx NOT DEFINED

The virtual terminal name entered has not been defined.

ERROR PR010013 SAPPL=xxxxxxx ALREADY ACTIVE

The virtual printer (VTAM node) entered under SAPPL is already in use. Re-invoke PR3287 and enter a different SAPPL.

ERROR PR010014 SAPPL=xxxxxxx OPEN-ERROR xxH

During the OPEN of the VTAM ACB an error message was passed to PR3287. Consult the VTAM Manual (Chapter: "Description of the VTAM Macros Instructions") to find the cause of the error or inform the HOB Customer Service.

ERROR PR010015 PAPPL=xxxxxxx NOT DEFINED

The primary application entered (e.g. CICS, IMS, TSO) has not been defined.

ERROR PR010016 PAPPL=xxxxxxx NOT ACTIVE

The requested primary application (application program, e.g. CICS, TSO, IMS) is not active and as a result cannot be reached.

ERROR PR010017 LOGMODE NOT DEFINED

The LOGMODE entered is not listed in your MODETAB. Ask the system programmer for a valid LOGMODE.

ERROR PR010018 REQSESS RTN xxH FTN xxH SENSE xxxxxxxxH

Request Session was rejected. The meaning of the codes can be found in the VTAM Manual (VTAM programing appendix B).

ERROR PR010019 PAPPL=xxxxxxx LOGON REJECTED RC=xx SENSE=xxxxxxx

The Logon on the Primary Application was rejected. You will find the meaning of the code in the VTAM Manual (VTAM programing, appendix B).

ERROR PR010020 PAPPL=.... INVALID BIND-PARAM

The primary application (CICS or DSPRINT) has sent the wrong BIND parameters for LOGON. This may be due to an incorrect LOGMODE (LOGON with LOGMODE=).

ERROR PR010021 NO BIND (OUT OF SERVICE)

The selected application does not send a Bind, no connection is established. This may be because the virtual terminal (SAPPL) has been set OUT OF SERVICE.

ERROR PR010022 PAPPL=xxxxxxx NO SDT (NON-SNA INSTALLATION)

The selected application does not send an SDT command (SDT = start data traffic), although BIND registers that the connection has already been established. This may be because the virtual terminal (SAPPL) has been incorrectly installed in the application program (e.g. CICS), for instance as a NON-SNA terminal.

ERROR PR010023 PAPPL=xxxxxxx NO UNBIND - TIME LIMIT

The session with the selected VTAM application has been terminated, but the VTAM application has not sent an UNBIND; for this reason, the session is terminated by PR3287. This may be because the VTAM application was terminated abnormally.

ERROR PR010024 PAPPL=xxxxxxx REQ:xxH RTN xxH FTN xxH

An error has been reported to program PR3287. The request code for the current access is xx. Refer to the VTAM Manual, (VTAM Messages, Chapter "Return Code/Sense Fields and Return Code Posting: Return Code Combination) to find the cause of the error or inform the HOB Customer Service.

ERROR PR010025 SAPPL xxxxxxxx CLOSE-ERROR xxH

An error was reported to program PR3287 while closing the VTAM-ACB. Consult the VTAM Manual (VTAM Messages, Chapter "Return Code/Sense Fields and Return Code Posting: Return Code Combination) to find the cause of the error or inform the HOB Customer Service.

ERROR PR010026 xxxxxxxx R15=xxH

The VTAM access xxxxxxxx (e.g. GENCB) was incorrectly terminated with the Return Code xx. Refer to the VTAM Manual (VTAM Messages, Chapter "Return Code/Sense Fields and Return Code Posting: Return Code Combination) to find the cause of the error or inform the HOB Customer Service.

ERROR PR010027 INVALID CHARACTER IN PAGE

The value entered after parameter PAGE= is incorrect. Refer to the Print Manual for a list of valid entries.

ERROR PR010028 VALUE OF PAGE OUT OF RANGE

The value entered after parameter PAGE= is too large. It must not exceed 999.

ERROR PR010029 PARAMETER FREETIME IS INVALID

The value specified after the FREETIME= parameter is incorrect. Valid entries range from 1 to 9999.

ERROR PR010030 PARAMETER FREETIME=ZERO IS INVALID

The value for FREETIME= may not be null (zero).

ERROR PR010031 EXIT-R

You can build your own Exit Routines into your XCTCT that give back error codes. These are put out under these error numbers.

ERROR PR010032 PAPPL=xxxxxxx NOT IN SESSION

LOGOFF can only be performed when a session is established.

ERROR PR010033 NO SESSION EXISTS

You can enter this command only when a session is established.

ERROR PR010034 LOGOFF ALREADY ISSUED

You entered LOGOFF, although the LOGOFF was already ended.

ERROR PR010035 SESSION IN SHUTDOWN STATE

The Shutdown is not yet ended. Wait a moment and try it again. If the message is shown again, please contact your system programmer.

ERROR PR010036 INVALID QUERY COMMAND

You made a typing/spelling error while entering your command. Please note that the command must be entered without further additions (only 'QUERY PARAM').

11.8. PR3770 MESSAGES*ERROR 10000001 COMMAND IS INVALID*

The command entered is either incomplete or incorrect.

ERROR PR020001 PROGRAM IS BATCH-P

The selected program can only be invoked from the HOB COM console. You tried to start it from the HOB COM console. Use EXEC COBA to start a background task and then invoke program PR3770.

ERROR PR020002 EITHER OUTFILE OR PRINTER-NAME

You may use only one of the two parameters for invoking.

ERROR PR020003 EITHER OUTFILE OR SFN3

You may use only one of the two parameters for invoking.

ERROR PR020004 INVALID OUTFILE FILE-NAME

The name entered at the parameter OUTFILE is wrong. Compare the build-up of the parameter in chapter 'Parameter at invoking'

ERROR PR020005 PRINTER PARAMETER NAME INVALID

The parameter entered for the printer form is incorrect.

ERROR PR020006 FREETIME UND PERM NOT ALLOWED

Both the PERM and the FREETIME parameters were specified when invoking the program PR3770. These parameters are contradictory and may not be specified together.

ERROR PR020007 PARAMETER FREETIME IS INVALID

The value specified after the FREETIME= parameter is incorrect. Valid entries range from 1 to 9999.

ERROR PR020008 PARAMETER FREETIME=ZERO INVALID

The value for FREETIME= may not be null (zero).

ERROR PR020009 EXIT-R

You can build your own Exit Routines into your XCTCT that give back error codes. These are put out under these error numbers.

ERROR PR020010 SESSION ACTIVE - LOGON NOT POSSIBLE

A LOGON to a VTAM application has already been executed.

ERROR PR020011 NO SESSION ACTIVE - NO LOGOFF

The session with the VTAM application was not activated or has already been ended.

ERROR PR020012 TEXT AFTER COMMAND IS INVALID

Text has been entered following the command LOGOFF, SHUTDOWN, GO or HALT. These commands must be entered without any text.

ERROR PR020013 P-E

HOB COM has received an error message from the printer (hardware fault). Consult the following list for the meaning of the error messages:

01010001 Terminal non-existent

A print task must be started for this terminal. Use EXEC COBA.

01010002 no printer generated

There is no driver entered in the TCT for this printer

01010003 Terminal is turned off

Turn the terminal on and enter "GO" in the COBA.

01010004 Printer is turned off

Turn the printer on and enter "GO" in the COBA.

01010005 Driver program not available

The selected driver is not entered in the TCT.

01010006 Printer is busy

Wait a while and then restart the print

01010101 Unknown printer

Either an entry in the JCL - table is missing or there is a mistake in the printer command

01050001 The terminal has been switched off while printing

Turn the terminal on and enter "GO" in the COBA.

01050002 The printer has been turned off while printing

Turn the printer on and enter "GO" in the COBA.

01050003 Wrong Load parameters

The print parameters entered in the TCT are incorrect.

01050004 Attribute record duplicate

Restart the print operation. If this message appears again, notify HOB Software Support.

01050005 After the attribute record, no normal record

Restart the print operation. If this message is displayed again, notify HOB Software Support.

00000011 HOBTEXT is using the printer

Wait a while and then reenter the print command

ERROR PR020014 NO PAPPL=... IN COMMAND

The parameter string for the LOGON command was incorrectly specified.

ERROR PR020015 NO SAPPL=xxxxxxx IN COMMAND

The parameter string was entered incorrectly when invoking program PR33770. Because no table with SAPPL entries was generated by the HOB COM System, a SAPPL entry must be made.

ERROR PR020016 SAPPL=xxxxxxx NOT DEFINED

A virtual printer name has been entered, which has not been defined in VTAM.

ERROR PR020017 SAPPL=xxxxxxx ALREADY ACTIVE

The virtual printer (VTAM node) entered under SAPPL is already in use. Re-invoke PR3770 and enter a different SAPPL.

ERROR PR020018 SAPPL=xxxxxxx OPEN-ERROR xxH

During the OPEN of the VTAM ACB an error message was passed to PR3770. Consult the VTAM Manual (Chapter: "Description of the VTAM Macros Instructions") to find the cause of the error or inform the HOB Customer Service.

ERROR PR020019 PAPPL=xxxxxxx NOT DEFINED (X)

The primary application entered (e.g. POWER,JES) has not been defined.

ERROR PR020020 PAPPL=xxxxxxx NOT ACTIVE

The requested primary application (application program, e.g. POWER, JES) is not active and as a result cannot be reached.

ERROR PR020021 LOGMODE NOT DEFINED

The LOGMODE entered is not listed in your MODETAB. Ask the system programmer for a valid LOGMODE.

ERROR PR020022 REQSESS RTN xxH FTH xxH SENSE =xxxxxxx

Request Session has been rejected. For the meaning of the codes refer to the VTAM Manual (VTAM-Programming, Appendix B).

ERROR PR020023 PAPPL=.... BIND-PARAM INVALID

The primary application (POWER or JES) has sent the wrong BIND parameters for LOGON. This may be due to an incorrect LOGMODE (LOGON with LOGMODE=). Enter appropriate session parameters for LOGMODE.

ERROR PR020024 LOGON REJECTED RC=xx SENSE=xxxxxxx

LOGON to the Primary Application has been rejected. For the meaning of the codes refer to the VTAM Manual (VTAM-Programming, Appendix B).

ERROR PR020025 NO BIND (OUT OF SERVICE)

The selected application does not send a Bind, no connection is established. This may be because the virtual printer is not entered in the appropriate table (POWER, JES).

ERROR PR020026 NO SDT (NON-SNA INSTALLATION)

The selected application does not send an SDT command (SDT = start data traffic), although BIND registers that the connection has already been established. N.B. the application must always be entered as an SNA application, regardless if the real terminal is an SNA terminal or not. Check your applications.

ERROR PR020027 NO UNBIND - TIME LIMIT

The session with the selected VTAM application has been terminated, but the VTAM application has not sent an UNBIND; for this reason, the session is terminated by PR3770. A possible cause is that the VTAM application was terminated abnormally.

ERROR PR020028 REQ:xxH RTN xxH FTH xxH

An error has been reported to program PR3770. The request code for the current access is xx. Refer to the VTAM Manual, (VTAM Messages, Chapter "Return Code/Sense Fields and Return Code Posting: Return Code Combination) to find the cause of the error or inform the HOB Customer Service.

ERROR PR020029 SAPPL xxxxxxxx CLOSE-ERROR xxH

An error was reported to program PR3770 while closing the VTAM-ACB. Consult the VTAM Manual (VTAM Messages, Chapter "Return Code/Sense Fields and Return Code Posting: Return Code Combination) to find the cause of the error or inform the HOB Customer Service.

ERROR PR020030 xxxxxxxx R15=xxH

The VTAM access xxxxxxxx (e.g. GENCB) was incorrectly terminated with the Return Code xx. Refer to the VTAM Manual (VTAM Messages, Chapter "Return Code/Sense Fields and Return Code Posting: Return Code Combination) to find the cause of the error or inform the HOB Customer Service.

ERROR PR020031 SET CONSOLE=(OFF/ON/ALL)

You have entered something other than OFF, ON or ALL after the SET CONSOLE= command.

ERROR PR020032 SEND INHIBITED - NO SESSION

The value entered after parameter PAGE= is too large. It must not exceed 999.

ERROR PR020033 SEND INHIBITED - NO ALLOWANCE

The RJE station is in the print or receive status and as a result cannot send commands to POWER or JES. To make entries you must first enter ATTN.

ERROR PR020034 ATTENTION INHIBITED - NO SESSION

You have entered ATTENTION although no session is active. An application must first be selected using the LOGON command.

ERROR PR020035 ATTENTION INHIBITED - NO ALLOWANCE

You have entered ATTENTION. This action is blocked because a send command is being executed.

11.9. MESSAGES OF THE XCTCPIP2 PROGRAM

These error messages appear either in the HOB COM basic mask (NOTE) or in the COBA (NOTE, PRVM, PRT2), dependent on the print program that was started.

Example:

DRUCKER-ERROR 01010**505**

or:

ABEN PROG PR3770 ERROR PR020013 P-E 01010**505**

Errors of the TCP/IP of MVS

x'501' Permission is denied. No owner exists.

x'502' The data set or directory was not found

x'503' The process was not found

x'504' A system call was interrupted

x'505' An I/O error occurred

x'506' The device or driver was not found

x'507' The argument list is too long

x'508' An EXEC format error occurred

x'509' Givesocket: The socket has already been given. The domain is not AF_INET Select: One of the specified descriptor sets is an incorrect socket descriptor

x'50A' There are no children

x'50B' There are no more processes

x'50C' There is not enough storage

x'50D' Takesocket: The other application (listener) did not give the to your application Socket: Access denied. The client's ID is not the OBEY file

x'50E' An incorrect storage address or length was specified

x'50F' A block device is required

x'510' Listen has already been called for this socket

x'511' The data set exists

x'512' This is a cross-device link

x'513' The specified device does not exist

x'514' The specified directory is not a directory

x'515' The specified directory is a directory

x'516' An incorrect argument was specified

x'517' Data set table overflow occurred

x'518' The socket descriptor table is full

x'519' An incorrect device call was specified

x'51A' A text data set is busy

x'51B' The specified data set is too large

x'51C' There is no space left on the device

x'51D' An incorrect seek was attempted

x'51E' The data set system is Read only

x'51F' There are too many links

x'520' The connection is broken

x'521' The specified argument is too large

x'522' The result is too large

x'523' The socket is in nonblocking mode and connection are not queued. This is not an error condition

x'524' The socket is marked nonblocking and the connection cannot be completed immediately. This is not an error condition

x'525' The socket is marked nonblocking an the previous connection has not been completed

x'526' A socket operation was requested on a nosocket connection

x'527' A destination address is required

x'528' The message is too long. The default is 8192 and the maximum is 32767

x'529' The specified protocol type is incorrect for this socket

x'52A' The socket option specified is incorrect or the level is not SOL_SOCKET

x'52B' The specified protocol is not supported

x'52C' The specified socket type is not supported

x'52D' Listen: The socket does not support the Listen call

x'52E' The specified protocol family is not supported

x'52F' The specified address family is not supported by this protocol family

x'530' The address is in a timed wait because a LINGER delay from a previous close or another process is using the address

x'531' Bind: The specified address is incorrect for this host Connect: The calling host cannot reach the specified destination

x'532' The network is down

x'533' The network cannot be reached

x'534' The network dropped a connection on a reset

x'535' The software caused a connection abend

x'536' The connection to the destination host is not available

x'537' Accept: Not enough buffer space is available to create the new socket Send: Not enough buffer space is available to send the new message

x'538' The socket is already connected

x'539' The socket is not connected

x'53A' A send cannot be processed after socket shutdown

x'53B' There are too many references. A splice cannot be completed

x'53C' The connection timed out before it was completed

x'53D' The requested connection was refused

x'53E' There are too many symbolic links levels

x'53F' The file name is too long

x'540' The host is down

x'541' There is no route to the host

x'542' The directory is not empty

x'543' There are too many processes in the system

x'544' There are too many users on the system

x'545' The disk quota has been exceeded

x'546' A STALE NFS data set handle was found

x'547' There are too many levels of remote in the path

x'548' The device is not a stream device

x'549' The timer has expired
 x'54A' There are no more stream resources
 x'54B' There is no more message of the desired type
 x'54C' The system cannot read the message
 x'54D' The identifier has been removed
 x'54E' A deadlock condition has occurred
 x'54F' No record locks are available
 x'550' The requested machine is not on the network
 x'551' The object is remote
 x'552' The link has been severed
 x'553' An ADVERTISE error has occurred
 x'554' An SRMOUNT error has occurred
 x'555' A communication error has occurred on a Send call
 x'556' A protocol error has occurred
 x'557' A multihop address link was attempted
 x'558' A cross-mount point was detected. This is not an error
 x'559' The remote address has changed
 x'55A' The connection was closed by a peer

HOB COM internal errors:

x'565' TCPIP eintrag in TCT nicht vorhanden
 x'566' Header ID in DNS response fehlerhaft
 x'567' DNS response ist nicht response
 x'56E'... DNS response Fehler Nr
 x'57F' keine ANSWER SECTIONS in DNS response
 x'580' 2. NamensTeil falsch (nur 1234567890ABCDEF erlaubt) oder nicht im TCT gefunden
 x'581' Kein Printer Name oder fehlerhaft
 x'582' Treiber für in TCT eingegebenen Drucker kann nicht geöffnet werden
 x'583' Printer am angegebenen Host nicht definiert
 x'584' recl = 0
 x'585' reca = 0
 x'586' -RSP auf RECEIVE DATA FILE empfangen

x'587' -RSP auf DATA FILE empfangen
x'588' -RSP auf RECEIVE CONTROL FILE empfangen
x'589' -RSP auf CONTROL FILE empfangen
x'58A' Treiber für in TCT eingetragenen Drucker nicht vorhanden
x'58B' printer name zu lang (max 80)
x'590' IUCV Send für SETSOCKOPT completed mit IPAUDIT != 0
x'591' IUCV Send für BIND fehlerhaft
x'592' IUCV Send für BIND completed mit IPAUDIT != 0
x'593' IUCV Send für LISTEN fehlerhaft
x'594' IUCV Send für LISTEN completed mit IPAUDIT != 0
x'595' GETSOCK routine liefert (für ACCEPT) keine SOCKET_NR
x'596' IUCV Send für ACCEPT fehlerhaft
x'597' IUCV Send für ACCEPT completed mit IPAUDIT != 0
x'598' IUCV Send für CONNECT fehlerhaft
x'599' IUCV Send für CONNECT completed mit IPAUDIT != 0
x'5A2' IUCV Send für CANCEL fehlerhaft
x'5A3' IUCV Send für CLOSE fehlerhaft
x'5A4' IUCV Send für CLOSE completed mit IPAUDIT != 0
x'5AA' IUCV Send für GETPEERNAME fehlerhaft
x'5AB' IUCV Send für GETPEERNAME completed mit IPAUDIT != 0
x'5B4' IUCV Send für WRITE fehlerhaft
x'5B5' IUCV Send für WRITE completed mit IPAUDIT != 0
x'5BE' IUCV Send für READ fehlerhaft
x'5BF' IUCV Send für READ completed mit IPAUDIT != 0
x'5C9' GETSOCK routine liefert (für SOCKET) keine SOCKET_NR
x'5CA' IUCV Send für SOCKET (UDP) fehlerhaft
x'5CB' IUCV Send für SOCKET (UDP) completed mit IPAUDIT != 0
x'5D2' IUCV Send für SENDTO fehlerhaft
x'5D3' IUCV Send für SENDTO completed mit IPAUDIT != 0
x'5DC' IUCV Send für RECVFROM fehlerhaft
x'5DD' IUCV Send für RECVFROM in 30 nicht completed
x'5DE' IUCV Send für RECVFROM completed mit IPAUDIT != 0

x'5E6' IUCV Send für CANCEL fehlerhaft
x'5F0' Länge feld mit Host Adresse falsch (DNS response
x'5F1' kein TCPIP OPEN da shutdown läuft
x'5F2' IUCV Connect mit TCPIP fehlerhaft
x'5F4' IUCV Send Initial Message fehlerhaft
x'5F5' IUCV Server empfangen
x'5F6' ACB Name zu lang
x'5FC' GETSOCK routine liefert (für SOCKET) keine SOCKET_NR
x'5FD' IUCV Send für SOCKET fehlerhaft
x'5FE' IUCV Send für SOCKET completed mit IPAUDIT != 0
x'5FF' IUCV Send für SETSOCKOPT fehlerhaft

A. APPENDIX

A.1. SAMPLE JOBS

A.1.1. Jobs to Load the HOB COM Program Phase and the Libraries

The program phase is loaded together with the libraries.

Sample job:

```
//TAPINHC JOB (ACCT), 'HOB COM-LESEN', MSGLEVEL=(1,1), MSGCLASS=X
//***** LOADS HOB COM FROM TAPE INTO THE LIBRARIES
//COPY EXEC PGM=IEBCOPY
//SYSPRINT DD SYSOUT=*
//TAPE1 DD DSN=HOB COM.LOADLIB, LABEL=(1,SL), DISP=SHR,
// UNIT=TAPE, VOL=SER=HOB COM
//TAPE2 DD DSN=HOB COM.MACLIB, LABEL=(2,SL), DISP=SHR,
// UNIT=TAPE, VOL=SER=HOB COM
//TAPE3 DD DSN=HOB COM.LIB1, LABEL=(3,SL), DISP=SHR,
// UNIT=TAPE, VOL=SER=HOB COM
//TARG1 DD DSN=HOB COM.TEST.LINKLIB, DISP=SHR
//TARG2 DD DSN=HOB COM.TEST.MACLIB, DISP=SHR
//TARG3 DD DSN=HOB COM.TEST.LIB1, DISP=SHR
//SYSIN DD *
COPY INDD=TAPE1, OUTDD=TARG1
COPY INDD=TAPE2, OUTDD=TARG2
COPY INDD=TAPE3, OUTDD=TARG3
/*
//
```

If you are using UCC1, enter the following label:

```
//LABEL=EXPDT=98000
```

It could be advantageous from a standpoint of performance, to copy the HOB COM module in an authorized library and to define it as non-swappable.

Our Tape Was Created Using the Following Job Steps

```
.
.
.
//*****
//STEP4 EXEC PGM=IEBCOPY
//SYSPRINT DD SYSOUT=*
//IN1 DD DSN=HOB COM.LINKLIB, DISP=SHR
//OUT1 DD DSN=HOB COM.TEMPLIB, VOL=SER=MVSDL2, UNIT=3380,
// DISP=(NEW,CATLG), SPACE=(CYL,(1,1,3)),
// DCB=(RECFM=U, BLKSIZE=23200)
```

```

//SYSIN      DD      *
              COPY I=IN1,O=OUT1
              SELECT MEMBER=XCHOB COM,XCHOB CST
/*

//*****    ALL HAS TO BE SAVED ON TAPE

//STEP5      EXEC PGM=IEBCOPY
//SYSPRINT   DD      SYSOUT=*
//IN1        DD      DSN=HOB COM.TEMPLIB,DISP=SHR
//IN2        DD      DSN=HOB COM.MACLIB,DISP=SHR
//IN3        DD      DSN=HOB COM.LIB1,DISP=SHR
//TAPE1      DD      DSNAME=HOB COM.LOADLIB,UNIT=TAPE,
//              VOL=SER=HOB COM,LABEL=( ,SL),DISP=(NEW,KEEP)
//TAPE2      DD      DSNAME=HOB COM.MACLIB,UNIT=TAPE,
//              VOL=SER=HOB COM,LABEL=( 2,SL),DISP=(NEW,KEEP)
//TAPE3      DD      DSNAME=HOB COM.LIB1,UNIT=TAPE,
//              VOL=SER=HOB COM,LABEL=( 3,SL),DISP=(NEW,KEEP)
//SYSIN      DD      *
              COPY I=IN1,O=TAPE1
              COPY I=IN2,O=TAPE2
              COPY I=IN3,O=TAPE3
/*

```

A.1.2. Job to Start HOB COM

HOB COM can be started using the following JOB:

```

//GOHOB COM JOB , 'GOHOB COM',CLASS=A,REGION=512K,TIME=1440
//JOB LIB DD DSN=HOB COM.LOADLIB,DISP=SHR
//LOAD EXEC PGM=XCHOB COM
//SYSPRINT DD SYSOUT=A
//SYSUDUMP DD SYSOUT=A
//CODIDUMP DD SYSOUT=A
//PARAM DD *
PHASE:XCTCT
//

```

If necessary the parameter UNIT should be specified for the JOBLIB assignment.

The XCTCT (see chapter 5) is read via the file assigned to the label PARAM. If no XCTCT is to be loaded, you can make the following entry:

```
//PARAM DD DUMMY
```

If HOB COM is to be started from a procedure, then DD * is not allowed.

Instead a file with content must be created.

```
PHASE:XCTCT
```

The name of the file must then be entered in the Start Job in place of the DD *.

A.2. Sample for Terminal Groups

When the XCTERMA table is created the assignment of terminals to groups is determined.

In our example (N.B.: this does not correspond to the TCT we delivered!) there are three terminals: N01, N02 and N08.

Terminal N01 does not belong to a terminal group. That means HOB COM sends the standard XCUS-SOUT mask to the terminal with this address. N02 belongs to Group 1; N08 to Group 3. The mask for all group 1 terminals is defined under the label G1USSOUT and the mask for the terminals in group 2 is defined under the label G2USSOUT. The commands for group 1 are defined under the label G1USSCOM and those for group 2 can be found under the label G2USSCOM.

Under the label XCTEGRO the masks and the commands to be used for the individual terminal groups are entered as well as any additional HOB COM Operator commands which are to be permitted in this group.

In our example the DISPLAY command has been entered for all terminals.

Additionally, terminals belonging to group 1 (G1LABEL) are authorized to use the commands CP as well as DISCTASK.

Entries for masks, command abbreviations and any additionally permitted Operator commands are optional. If they are missing, HOB COM uses the standard entries contained in XCUSOUT and XCUSCOM, respectively.

You can tell which group a terminal belongs to by the system message displayed in the part of the HOB COM base mask, that appears independent of the XCUSOUT/GxUSSOUT definitions.

Please be careful to make your entries in the proper order.

You can change the mask and commands for group 1 according to your wishes.

Groups and masks are not limited to 2; likewise you can also increase the number of terminals per group.

```

TITLE 'XCTCT * TERMINAL-CONTROL-TABLE HOBCOM'
*****
      XTCTDEF                                ;DEFINITION DATA FIELD
*****
*      PROGRAMM
*****
XCTCT  CSECT
*
XCTCTANF XTCTGEN TERMA=XCTERMA,                X
          PRTAB=XCPRTAB,                        X
          ACBNAM=HOBCOM,                        X
          TEGRO=XCTEGRO,                        X
          USSOUT=XCUSSOUT,                      X
          USSCOM=XCUSSCOM,                      X
          PRPAR=XCPRPAR,                        X
          USSBTA=XCUSSBTA,                      X
          PERSTA=VCPERSTA,                      X
          JCLTAB=XCJCLTAB,                      X
          COMASK=XCCOMASK,                      X
          LTKEY=ABCD1234,                       X
          PASSW=XCPASSW
*****
*
XCTERMA DS    0F                                ;ADRESSES OF TERMINALS
          XCTCT TERM=N01,PRINT=10
          XCTCT TERM=N02,PRINT=06,                X
          GROUP=G1LABEL-XCTEGRO
          XCTCT TERM=N08,PRINT=06,                X
          GROUP=G2LABEL-XCTEGRO,                X
          LASTTE=YES
*
.
*
XCTEGRO DS    0F
          DC    H'0'
          DC    Y(XCTEGROE-XCTEGRO)      ;LENGTH OF TABLE
          XCTEGRO LABEL=G1LABEL,NAME=GRUPPE1,USSOUT=G1USSOUT,    XI
          USSCOM=G1USSCOM
          XCTEGRO LABEL=G2LABEL,NAME=GRUPPE2,USSOUT=G2USSOUT,    XI
          USSCOM=G2USSCOM,COMASK=(DISC)
XCTEGROE EQU  *
*
G1USSOUT DS    0F                                ;OUTPUT
          DC    AL2(XXX)                    ;LENGTH OF OUTPUT
          DC    X'01'                        ;CORNER
          DC    5X'0B'                      ;HORIZONTAL LINE
          DC    CL7'GRUPPE1'
          DC    66X'0B'                      ;HORIZONTAL LINE
          DC    X'42'                        ;CORNER
          DC    X'46'                        ;VERTICAL LINE
          DC    2X'40'
          DC    CL76'The following commands can be entered:'
          DC    X'46'                        ; VERTICAL LINE
          DC    X'46'                        ; VERTICAL LINE
          DC    5X'40'
          DC    CL73'
          DC    X'46'                        ; VERTICAL LINE

```

```

DC      X'46'                ; VERTICAL LINE
DC      5X'40'
DC      CL73'
DC      X'46'                ; VERTICAL LINE
DC      X'46'                ; VERTICAL LINE
DC      5X'40'
DC      CL73'VM = CMS MASCHINE
DC      X'46'                ; VERTICAL LINE
DC      X'46'                ; VERTICAL LINE
DC      5X'40'
DC      CL73'AUS = SWITCH OFF TERMINAL
DC      X'46'                ; VERTICAL LINE
DC      X'02'                ;CORNER
DC      78X'0B'              ;HORIZONTAL LINE
DC      X'43'                ;CORNER
*
G2USSOUT DS      0F                ;OUTPUT
DC      AL2(XXX)              ;LENGTH OF OUTPUT
.
Mask for group 2
.
*
XCUSSOUT DS      0F
DC      AL2(XXX)              ;LENGTH OF OUTPUT
.
Standard mask for those terminals which have not been
assigned to a group in XCTERMA
.
*
XCUSSCOM EQU      *                ;COMMANDS
XCUSS ABB=..... X
.
abbreviations for terminals not assigned to a
group, displayed in the standard mask
.
DC      X'FF'                ;END OF TABLE
*
G1USSCOM EQU      *                ;COMMANDS
XCUSS ABB=PROD, X
COM='EXEC COVTOP PA=PRODCICS,KEYLOCK'
XCUSS ABB=AUS, X
COM='LOGOFF'
DC      X'FF'                ;END OF TABLE
*
G2USSCOM EQU      *                ;COMMANDS
XCUSS ABB=..... X
.
starting here you can define the abbreviations for
the commands to be used for group 2
make sure that explanations of the abbreviations
also appear on mask 2
.
DC      X'FF'                ;END OF TABLE
*
.
.
*
XCCOMASK DS      0F                ;HOB COM-OPERATOR MASK

```

```

      XCOPY                                ;COMM. F. CONSOLE, ALL ALLOWED
      XCOPY  DIS=YES,SHU=NO,                ;COMMANDS F. TERMINAL:
          CAN=NO,                            ;DISPLAY IS ALLOWED, ALL OTHER
          DISC=NO,TCTLOAD=NO                ;COMMANDS NOT
*
XCPASSW  DC      'XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX'
          .
          .
          LTORG
          END      XCTCTANF

```

A.3. CHANGING THE PRINTER DRIVERS

The extension of the EPSON standards has made a further differentiation of our EPSON drivers 09 and 12 necessary.

Whether or not you need a different printer driver can be recognized by checking the line spacing. If it is wrong, you need a new driver. If the only problem you encounter is printing the German umlauts, you can simply change the character set on the printer.

Generally speaking:

- driver 9 does not support graphic characters and normally makes use of the the italic character set
- driver 12 supports the HOBTEXT graphic characters and normally requires the extended EPSON character set.

If the bit is not set, 1/180th of an inch is used for the vertical feed.

If it is set, 1/216th of an inch is used for the vertical feed.

Required changes in the HOBCom-TCT

Example:

Bit is set	Bit is not set
for 1/180"	for 1/216"
PPRINT09 EQU *	PPRINT49 EQU *
DC X'0009'	DC X'0049'
DC X'0C'	DC X'0C'
DC X'00'	DC X'40'
DC C'\$COP0009'	DC C'\$COP0009'
PPRINT12 EQU *	PPRINT42 EQU *
DC X'0012'	DC X'0042'
DC X'0C'	DC X'0C'
DC X'00'	DC X'40'

DC C\$COP0012' DC C\$COP0012'

The following table shows the characteristics of the two drivers and gives examples of printers which run under them:

Driver	9		12	
Character Set	Basic/Italics Character Set./ CG1		extended Epson Character Set / CG2	
Bit	00	40	00	40
Feed	1/180"	1/216"	1/180"	1/216"
Printer Examples	SQ-2550	MT-90	MT-330 LQ 2550 SQ 2550	MT-905

A.4. EXAMPLE FOR AN EXIT-ROUTINE

This exit routine assigns LU addresses from a pool.

```
*****
XCUPNAM  DS      0F    ;EINSPRUNG
          DC      Y(PEXEND-*) ;LENGTH OF PROGRAM
*****
R E G I S T E R    D E F I N I T I O N S
*****
R00      EQU      0
R01      EQU      1
R02      EQU      2
R03      EQU      3
R04      EQU      4
R05      EQU      5
R06      EQU      6
R07      EQU      7
R08      EQU      8
R09      EQU      9
R10      EQU     10
R11      EQU     11
R12      EQU     12
R13      EQU     13
R14      EQU     14
R15      EQU     15
RPARA    EQU      2    ;PARAMETER PASS
RDAT      EQU      3    ;ADDRESSING DATA
RH0       EQU      4    ;HELP REGISTER 0 (EVEN)
RH1       EQU      5    ;HELP REGISTER 1
RH2       EQU      6    ;HELP REGISTER 2
RH3       EQU      7    ;HELP REGISTER 3
RH4       EQU      8    ;HELP REGISTER 4
RPROG     EQU      9    ;ADDRESSING WITHIN PROGRAM
RSP2      EQU     11    ;SYSTEM PARAMETER 2
RSP1      EQU     12    ;SYSTEM PARAMETER 1
RSYS      EQU     13    ;ADDRESS system area
*****
          USING    SA$BLOCK,RSYS          ;SYSTEM-ADDRESSES
          STM      R14,R12,12(R13)        ;SAVE REGISTER
          BALR     RPROG,0                 ;PICK ACTUAL ADDRESS
          USING    *,RPROG                ;PROGRAMM ADDRESSABLE
          LR       RPARA,R01              ;GET PASS
          TM       1(RPARA),X'80'         ;VTAM PROGRAM?
          BNO      PEXROK                 ; NO, JUMP BACK
          CLI      0(RPARA),0             ;ENTER?
          BNE      PEXOUT                 ; NO
          CLI      8(RPARA),C'*'         ;FROM POOL?
          BE       PEXP00                 ; YES
          CLI      8(RPARA),0             ;ANYTHING PASSED?
          BNE      PEXI02                 ; YES
          MVC      8(8,RPARA),16(RPARA) ;PICK CALCULATED
```

```

PEXI02  DS      0H      ;ENTER
        LA      RH4,PEXP00L1          ;BEGIN OF POOL
        LA      RH3,((PEXP00L2-PEXP00L1)/8) ;NUMBER
PEXI04  DS      0H      ;CHECK ENTRY
        CLC     0(8,RH4),8(RPARA)      ;THIS APPL?
        BE      PEXI10                ; YES
        LA      RH4,8(,RH4) ;NEXT ENTRY
        BCT     RH3,PEXI04 ;NEW CHECK
        B       PEXR0K                ;ALL READY
PEXI10  DS      0H      ;ENTRY FOUND
        ICM     RH0,15,SA$UPNAT        ;GET ADDRESS OF INTERIM STORAGE
        BZ      PEXP20                ; MISSING
        LA      RH2,4(,RH0) ;FROM HERE ENTRIES
        LH      RH3,2(,RH0) ;NUMBER OF ENTRIES
        XR      RH1,RH1                ;UNTIL YET NO FREE ENTRY
PEXI12  DS      0H      ;CHECK ENTRY
        CLC     0(8,RH2),8(RPARA)      ;THIS APPLID?
        BE      PEXI20                ; YES
        CLI     0(RH2),0                ;ENTRY FREE?
        BNE     PEXI14                ; NO
        LTR     RH1,RH1                ;REMEMBER FREE ENTRY?
        BNZ     PEXI14                ; YES
        LR      RH1,RH2                ;NOTE FREE ENTRY
PEXI14  DS      0H      ;NEXT ENTRY
        LA      RH2,8(,RH2) ;NEXT ENTRY
        BCT     RH3,PEXI12 ;CONTINUE SEARCHING
        LTR     RH1,RH1                ;FREE ENTRY FOUND?
        BZ      PEXP40                ; NO
        MVC     0(8,RH1),0(RH4)        ,NOTE ENTRY OCCUPIED
        B       PEXR0K                ;READY
PEXI20  DS      0H      ,ENTRY OCCUPIED
        LA      R15,PEXEA             ;ADDRESS ERROR MESSAGE
        B       PEXRERR                ;ERROR JUMP BACK
PEXP00  DS      0H      ;PICK FROM POOL
        LA      RH4,PEXP00L1          ;ADDRESS FIRST ENTRY
        ICM     RH0,15,SA$UPNAT        ;GET ADDRESS OF INTERIM STORAGE
        BZ      PEXP18                ; NOT FOUND
        XR      RH1,RH1                ;UNTIL YET NO EMPTY ENTRY FOUND
PEXP02  DS      0H      ;SEARCH TABLE
        LA      RH2,4(,RH0) ;FROM HERE ENTRIES
        LH      RH3,2(,RH0) ;NUMBER OF ENTRIES
PEXP04  DS      0H      ;LOOK WHETHER IN TABLE
        CLC     0(8,RH2),0(RH4)        ;THIS ENTRY?
        BE      PEXP10                ; YES
        LTR     RH1,RH1                ;SEARCH FREE ENTRY?
        BNZ     PEXP06                ; NO
        CLI     0(RH2),0                ;ENTRY FREE?
        BNE     PEXP06                ; NO
        LR      RH1,RH2                ;REMEMBER ENTRY
PEXP06  DS      0H      ;MEMBER PROCESSED
        LA      RH2,8(,RH2) ;NEXT ENTRY
        BCT     RH3,PEXP04 ;CONTINUE SEARCHING
        MVC     8(8,RPARA),0(RH4)      ;THIS NAME PASSED
        LTR     RH1,RH1                ;FREE ENTRY FOUND?
        BZ      PEXP40                ; NO
        MVC     0(8,RH1),0(RH4)        ;NOTE ENTRY OCCUPIED
        B       PEXR0K                ;READY

```

```

PEXP10  DS      0H      ;ENTRY OCCUPIED
        LA      RH4,8(,RH4) ;NEXT ENTRY
        LA      RH2,PEXP00L2      ;END OF POOL
        CLR     RH4,RH2      ;AT END OF POOL?
        BL      PEXP02      ; NO, GO ON SEARCHING
        TS      0(RH0)      ;SET DISPLAY-FLAG
        BNZ     PEXP12      ;ALREADY SET
        L       R15,SA$DISP1      ;ROUTINE DISPLAY
        BALR    R14,R15      ;PICK DISPLAY FIELD
        LTR     RSP1,RSP1      ;SOMETHING TO DISPLAY?
        BZ      PEXP12      ; NO
        MVC     0(34,RSP1),=C'XC USER-EXIT ALL ENTRIES USED'
        BALR    R14,R15      ;OUTPUT MESSAGE
PEXP12  DS      0H      ;BACK WITH ERROR MESSAGE
        LA      R15,PEXEF      ;ADDRESS ERROR MESSAGE
        B       PEXRERR      ;ERROR - JUMP BACK
PEXP18  DS      0H      ;ENTRY FROM RH4
        MVC     8(8,RPARA),0(RH4) ;APPL PASS
PEXP20  DS      0H      ;BUILD POOL
        LA      RH3,(PEXP00L2-PEXP00L1+4) ;LENGTH OF POOL
        LR      RSP1,RH3      ;LENGTH OF STORAGE
        L       R15,SA$STGP ;ROUTINE STORAGE PERMANENT
        BALR    R14,R15      ;GET STORAGE
        LR      RH2,RSP1      ;NEW ADDRESS
        XR      R15,R15      ;ERASE PAD BYTE
        MVCL    RH2,R14      ;DELETE STORAGE
        LA      RH3,((PEXP00L2-PEXP00L1)/8) ;NUMBER OF ENTRIES
        ST      RH3,0(,RSP1)      ;SET NUMBER
        MVC     4(8,RSP1),0(RH4) ;FIRST ENTRY
        ST      RSP1,SA$UPNAT      ;SET INTERIM STORAGE
        B       PEXROK      ;JUMP BACK
PEXP40  DS      0H      ;ENLARGE TABLE
        LH      RH3,2(,RH0) ;NUMBER OF ELEMENTS
        LA      RH1,8(,RH3) ;ENLARGE
        LR      RH2,RH1      ;TRANSFER NUMBER
        SLL     RH2,3      ;NUMBER TIMES 8
        LA      RSP1,4(,RH2)      ;GET LENGTH PLUS INTRODUCTION
        L       R15,SA$STGP ;ROUTINE STORAGE PERMANENT
        BALR    R14,R15      ;GET STORAGE
        LR      R01,RH2      ;NEW LENGTH (W/O INTRODUCTION)
        MVC     0(2,RSP1),0(RH0) ;DISPLAY FLAG
        STH     RH1,2(,RSP1)      ;SET NEW NUMBER
        LA      RH2,4(,RH0) ;ADDRESS OF OLD ENTRIES
        SLL     RH3,3      ;OLD NUMBER TIMES 8
        LA      R00,4(,RSP1)      ;NEW ENTRIES FROM HERE ON
        MVCL    R00,RH2      ;TRANSFER APPLS
        ST      RSP1,SA$UPNAT      ;SET INTERIM STORAGE
        LR      RSP1,RH0      ;GET OLD STORAGE
        L       R15,SA$STFRE      ;ROUTINE FREE STORAGE
        BALR    R14,R15      ;FREE STORAGE
        B       PEXROK      ;JUMP BACK
PEXOUT  DS      0H      ;REMOVE
        ICM     RH0,15,SA$UPNAT ;GET ADDRESS FROM INTERIM STORAGE
        BZ      PEXROK      ; NOT FOUND
        LA      RH2,4(,RH0) ;FROM HERE ENTRIES
        LH      RH3,2(,RH0) ;NUMBER OF ENTRIES
PEX002  DS      0H      ;CHECK ENTRY
        CLC     0(8,RH2),8(RPARA) ;THIS APPLID?

```

	BE	PEX004	; YES
	LA	RH2,8(,RH2)	;NEXT ENTRY
	BCT	RH3,PEX002	;CONTINUE CHECKING
	B	PEXROK	;READY
PEX004	DS	0H	;ENTRY FOUND
	MVI	0(RH2),0	;ERASE ENTRY
PEXROK	DS	0H	;JUMP BACK O.K.
	LM	R14,R12,12(R13)	;GET REGISTER
	XR	R15,R15	;DELETE RETURN CODE
	BR	R14	;JUMP BACK
PEXRERR	DS	0H	;JUMP BACK - ERROR
	L	R14,12(,R13)	;GET RETURN-JUMP REGISTERS
	LM	R00,R12,12+8(R13)	;GET REGISTER
	BR	R14	;JUMP BACK
	DROP	RPROG	;PROGRAM NO ADDR
	DROP	RSYS	;SYSTEM ADDRESSES NO ADR
	LTORG		
PEXEA	EQU	*	;ALREADY IN USE
	DC	AL1(L'PEXEAT)	;LENGTH
PEXEAT	DC	C'SAPPL AREADY IN USE'	
PEXEF	EQU	*	;FULL - ALL USED
	DC	AL1(L'PEXEFT)	;LENGTH
PEXEFT	DC	C'ALL SAPPLS IN USE'	
PEXPOOL1	DS	0F	
	DC	CL8'C909'	
	DC	CL8'C910'	
	DC	CL8'C911'	
	DC	CL8'C912'	
PEXPOOL2	EQU	*	
PEXEND	DS	0F	;END EXIT-ROUTINE

A.5. ERROR MESSAGES WHEN USING LAPTOPS

All of the following messages are displayed on the PC:

VTAM-Messages from the USSTAB:

- 1 WRONG FORMAT
- 2 UNKNOWN COMMAND
- 3 UNKNOWN PARAMETER
- 4 PARAMETER xxx INVALID (in place of xxx the erroneous
parameter is displayed)
- 5 FUNCTION NOT SUPPORTED
- 6 SEQUENCE ERROR
- 7 BIND REJECT FROM APL
- 8 NOT ENOUGH VTAM MAIN STORAGE
- C OPERAND MISSING
- D VTAM ECHO

Other Messages:

- 15 Pseudo-LU not found in TCT
- 19 no more logical channels available
- 17 invalid password in the HOB COM-TCT
- 21 LU not defined
- 22 erroneous LU
- 23 LTKEY erroneous
- 24 PU-TYPE erroneous
- 25 LU already in use

A.6. HOB COM OPERATOR COMMANDS

CO ACT-DIR NAME= ALIAS= LABEL=		HOBTEXT
CO BAT-OFF	MVS	
CO BAT-OFF ALL	MVS	
CO BAT-OFF TERMINAL=	MVS	
CO BAT-ON	MVS	
CO BAT-ON ALL	MVS	
CO BAT-ON ALL,IGNOFF	MVS	
CO BAT-ON TERMINAL=	MVS	
CO CANCEL TASK=	MVS	
CO CLOSE DISK=		HOBTEXT
CO DEFINE DCACHE1=		HOBTEXT
CO DISCTASK TASK=	MVS	
CO DISPLAY DIRECTORY		HOBTEXT
CO DISPLAY DISK		HOBTEXT
CO DISPLAY PROGRAMS	MVS	
CO DISPLAY STORAGE	MVS	
CO DISPLAY TASKS	MVS	
CO DISPLAY TASKS,FULL	MVS	
CO DISPLAY TASKS,BATCH	MVS	
CO DISPLAY TASKS,BATCH,FULL	MVS	
CO DISPLAY TASKS,DISCONN	MVS	
CO DISPLAY TASKS,HALT	MVS	
CO DISPLAY TASKS,TERMINAL=	MVS	
CO DISPLAY TASKS,PERS=		HOBTEXT
CO DISPLAY TERMINAL	MVS	
CO DISPLAY TERM=	MVS	
CO DISPLAY VERSION	MVS	
CO DYNALLOC ALLOC	MVS	
CO DYNALLOC UNALL	MVS	
Px GETTASK TASK=	MVS	
CO OPEN DISK=		HOBTEXT

CO OPEN TCPIP TELNET PORT=	MVS	
CO CLOSE TCPIP TELNET PORT=	MVS	
CO SHUTDOWN	MVS	
CO TCTLOAD PHASE=	MVS	
CO HELP COM	MVS	HOBTEXT
CO HELP COM,FULL	MVS	HOBTEXT

A.7. HOB COM PROGRAM PARAMETERS

AGO		PR3287	PR3770
ALARM	COVTC/COVTOP		
AUTOCONN		COBA	
AUTOEND		PR3287	PR3770
CECP	COVTC		
COT		COBA	
DELAY	COVTC		
EXTCHAR	COVTC	PR3287	
FREEPAGE		PR3287	
FREETIME		PR3287	PR3770
HARDCOPY		NOTE	
HIGHIN		NOTE	
INVERS	COVTC/COVTOP	NOTE	
INSSP	COVTC/COVTOP		
KEYLOCK	COVTC/COVTOP		
LLM			PR3287
LOGMODE=	COVTC/COVTOP	PR3287	PR3770
MOVSP	COVTC/COVTOP		PR3770
MSG=	COVTC/COVTOP		PR3770
NOATT		PR3287	
NORMAL		NOTE	
NOSTAT	COVTC/COVTOP		
NUMERIC	COVTC/COVTOP		
OPT	COVTC/COVTOP		
OUTFILE=		NOTE	PR3287 PR3770
PAGE=		PR3287	
PAPPL=	COVTC/COVTOP	PR3287	PR3770
PARAM=		NOTE	PR3287 PR3770
PERM		PR3287	PR3770
PF	COVTC/COVTOP		
PRINTER=		NOTE	PR3287 PR3770
SAPPL=	COVTC/COVTOP	PR3287	PR3770
SFN3=		NOTE	PR3287 PR3770
SOFTCOPY		NOTE	
TERMINAL=		NOTE	
UPC	COVTC/COVTOP		
UNDERLINE		NOTE	

A.8. HOB COM PRINT PROGRAM COMMANDS

ATTENT	PR3287	PR3770
CANCEL	PR3287	PR3770
GO	PR3287	PR3770
HALT	PR3287	PR3770
LOGON	PR3287	PR3770
LOGOFF	PR3287	PR3770
MESSAGE		PR3770
QUERYPARAM	PR3287	
SEND		PR3770
SETPAGE=	PR3287	PR3770
SETPARAM=	PR3287	
SETCONSOLE=		PR3770
SHUTDOWN	PR3287	PR3770

A.9. HOB COM MODE TABS

```

TITLE  'MODTABCX - MODETAB FOR HOB TERMINALS, X-PROTOCOL '
      PRINT NOGEN
MODTABCX MODETAB
HOBLME02 MODEENT LOGMODE=HOBLME02,
          FMPROF=X'03',TSPROF=X'03',
          PRIPROT=X'B1',SECPROT=X'90',
          COMPROT=X'3080',RUSIZES=X'8989',
          PSERVIC=X'028000000000185000007E00'
D4C32782 MODEENT LOGMODE=D4C32782,
          FMPROF=X'03',TSPROF=X'03',
          PRIPROT=X'B1',SECPROT=X'90',
          COMPROT=X'3080',RUSIZES=X'87F8',
          PSERVIC=X'028000000000185000007E00'
D6327802 MODEENT LOGMODE=D6327802,
          FMPROF=X'03',TSPROF=X'03',
          PRIPROT=X'B1',SECPROT=X'90',
          COMPROT=X'3080',RUSIZES=X'88F8',
          PSERVIC=X'028000000000185000007E00'
CODLOG10 MODEENT LOGMODE=CODLOG10,
          FMPROF=X'03',TSPROF=X'03',
          PRIPROT=X'B1',SECPROT=X'90',
          COMPROT=X'0000',RUSIZES=X'8888',
          PSERVIC=X'028000000000000000001000'
      MODEEND
      END

```

```

      TITLE 'MODTABCO - HOB COM-MODETAB FOR USING NCCF'
      PRINT NOGEN
USSTABCO MODETAB
ENTRYC  MODEENT LOGMODE=ENTRYC,FMPROF=X'03',TSPROF=X'03',
          PRIPROT=X'B1',SECPROT=X'90',COMPROT=X'3080',
          RUSIZES=X'87F8',PSERVIC=X'028000000000185000007E00'
D4C32782 MODEENT LOGMODE=D4C32782,FMPROF=X'03',TSPROF=X'03',
          PRIPROT=X'B1',SECPROT=X'90',COMPROT=X'3080',
          RUSIZES=X'87F8',PSERVIC=X'028000000000185000007E00'
DSILGMOD MODEENT LOGMODE=DSILGMOD,FMPROF=X'03',TSPROF=X'03',
          PRIPROT=X'B1',SECPROT=X'A0',COMPROT=X'3080',
          RUSIZES=X'8785',PSERVIC=X'02800000000000000000200'
      MODEEND
      END

```

```

      TITLE 'MODTABLT - HOB COM-MODETAB FOR LAPTOPS'
      PRINT NOGEN
MODTABLT MODETAB
ENTRYC  MODEENT LOGMODE=ENTRYC,FMPROF=X'03',TSPROF=X'03',
          PRIPROT=X'B1',SECPROT=X'90',COMPROT=X'3040',
      MODEEND
      END

```

A.10. HOB COM USSTABS

```

        TITLE 'USSTABN1 - HOB COM-USSTAB FOR NON-SNA-CONTROLLER'
        PRINT NOGEN
USSTABN1 USSTAB
LOGON    USSCMD  CMD=LOGON,FORMAT=PL1
        USSPARM  PARM=APPLID
        USSPARM  PARM=LOGMODE,DEFAULT=S3270
        USSPARM  PARM=DATA
IBMTEST  USSCMD  CMD=IBMTEST,FORMAT=BAL
        USSPARM  PARM=P1,DEFAULT=10
        USSPARM  PARM=P2,DEFAULT='0123456789ABCDEF'
MESSAGES USSMSG  MSG=10,BUFFER=PTEXTA
END      USSEND
*
PTEXTA   DC      AL2(PTEXTE-PTEXTA-2)  ;LENGTH
        DC      X'F5'                  ;ERASE WRITE
        DC      X'C3'                  ;WCC
        DC      X'114040C1'            ;BEGINNING OUTPUT
        DC      X'F06F4C6F6F'          ;KIND OF TERMINAL
        DC      X'F6F05BE0'            ;SWITCH OUT-CODE (ONCE)
        DC      X'00115D7F40'          ;BLANK AT THE END
PTEXTE   EQU      *                    ;END
END

```

```

                TITLE 'USSTABN2 - HOB COM-USSTAB FOR NON-SNA-CONTROLLER'
                PRINT NOGEN
USSTABN2  USSTAB
LOGON     USSCMD  CMD=LOGON,FORMAT=PL1
          USSPARM  PARM=APPLID
          USSPARM  PARM=LOGMODE,DEFAULT=S3270
          USSPARM  PARM=DATA
IBMTEST   USSCMD  CMD=IBMTEST,FORMAT=BAL
          USSPARM  PARM=P1,DEFAULT=10
          USSPARM  PARM=P2,DEFAULT='0123456789ABCDEF'
MESSAGES  USSMSG  MSG=10,BUFFER=PTEXTA
END        USSEND
*
PTEXTA    DC      AL2(PTEXTE-PTEXTA-2); LENGTH
          DC      X'F5'                      ;ERASE WRITE
          DC      X'C3'                      ;WCC
          DC      X'114040C1'                ;BEGINNING OUTPUT
          DC      X'F06F4C6F6F'              ;KIND OF TERMINAL
          DC      X'F16F6A506F6F6F4C7C5B6F' ;COMMAND SEND
          DC      C'-- HOB COM NICHT VERF'   ;TEXT
          DC      X'C07B'                    ;SIGN Ü
          DC      C'GBAR --'                 ;TEXT
          DC      X'F6F86F7B'                ;SWITCH OFF-CODE (DELAYED)
          DC      X'00115D7F40'              ;BLANK AT THE END
PTEXTE    EQU     *                          ;END
          END

```

```

      TITLE 'USSTABSA - HOBCOM-USSTAB FOR SNA AND VTAM VERSION 1'
      PRINT NOGEN
USSTABSA USSTAB
LOGON    USSCMD  CMD=LOGON,FORMAT=PL1
         USSPARM  PARM=APPLID
         USSPARM  PARM=LOGMODE
         USSPARM  PARM=DATA
IBMTTEST USSCMD  CMD=IBMTTEST,FORMAT=BAL
         USSPARM  PARM=P1,DEFAULT=10
         USSPARM  PARM=P2,DEFAULT='0123456789ABCDEF'
CODIS    USSCMD  CMD=CODIS,REP=LOGON,FORMAT=PL1
         USSPARM  PARM=APPLID,DEFAULT=CODIS
MESSAGES USSMSG  MSG=4,BUFFER=PTEXTA  ;HOBCOM NOT RUNNING
         USSMSG  MSG=10,BUFFER=PTEXTA  ;MESSAGE IF WITHOUT SESSION
END
*
PTEXTA  DC      AL2(PTEXTE-PTEXTA-2)  ;LENGTH
         DC      X'C1'                  ;BEGINN OF OUTPUT
         DC      X'F06F4C6F6F'          ;KIND OF TERMINAL
         DC      X'F16F6A506F6F6F4C7C5B6F' ;COMMAND SEND
         DC      C'-- HOBCOM NICHT VERF' ;TEXT
         DC      X'C07B'                  ;SIGN Ü
         DC      C'GBAR --'              ;TEXT
         DC      X'F6F86F7B'              ;SWITCH OFF-CODE (DELAYED)
         DC      23X'15'                  ;FIELD UNTIL THE 24. LINE
         DC      79X'00'                  ;BLANK IN 24. LINE
         DC      X'40'                    ;BLANK AT THE END
PTEXTE  EQU      *                        ;END
END

```

This USSTAB can also be used with VTAM Version 3.

```

      TITLE 'USSTABS1 - HOBCOM-USSTAB FOR SNA-CONTROLLER'
      PRINT NOGEN
USSTABS1 USSTAB
LOGON    USSCMD  CMD=LOGON,FORMAT=PL1
         USSPARM  PARM=APPLID
         USSPARM  PARM=LOGMODE
         USSPARM  PARM=DATA
IBMTTEST USSCMD  CMD=IBMTTEST,FORMAT=BAL
         USSPARM  PARM=P1,DEFAULT=10
         USSPARM  PARM=P2,DEFAULT='0123456789ABCDEF'
MESSAGES USSMSG  MSG=2,BUFFER=PTEXTA  ;MESSAGE NOT PROCESSED
         USSMSG  MSG=10,BUFFER=PTEXTA  ;MESSAGE IF NO SESSION
END
*
PTEXTA  DC      AL2(PTEXTE-PTEXTA-2)  ;LENGTH
         DC      X'C1'                  ;START OUTPUT
         DC      X'F06F4C6F6F'          ;KIND OF TERMINALS
         DC      X'F6F05BE0'            ;SWITCH OFF-CODE (ONCE)
         DC      23X'15'                  ;AREA UNTIL 24. LINE
         DC      79X'00'                  ;BLANK IN 24. LINE
         DC      X'40'                    ;BLANK AT THE END
PTEXTE  EQU      *                        ;END
END

```

```

        TITLE 'USSTABS2 - HOB COM-USSTAB FOR SNA-CONTROLLER'
        PRINT NOGEN
USSTABS2 USSTAB
LOGON    USSCMD  CMD=LOGON,FORMAT=PL1
        USSPARM  PARM=APPLID
        USSPARM  PARM=LOGMODE
        USSPARM  PARM=DATA
IBMTEST  USSCMD  CMD=IBMTEST,FORMAT=BAL
        USSPARM  PARM=P1,DEFAULT=10
        USSPARM  PARM=P2,DEFAULT='0123456789ABCDEF'
MESSAGES USSMSG  MSG=2,BUFFER=PTEXTA    ;MESSAGE NOT PROCESSED
        USSMSG  MSG=10,BUFFER=PTEXTA    ;MESSAGE IF NO SESSION
END      USSEND
*
PTEXTA   DC      AL2(PTEXTE-PTEXTA-2)    ;LENGTH
        DC      X'C1'                    ;BEGINNING OUTPUT
        DC      X'F06F4C6F6F'            ;KIND OF TERMINAL
        DC      X'F16F6A506F6F6F4C7C5B6F' ;COMMAND SEND
        DC      C'-- HOB COM NICHT VERF'  ;TEXT
        DC      X'C07B'                    ;SIGN Ü
        DC      C'GBAR --'                ;TEXT
        DC      X'F6F86F7B'                ;SWITCH OFF-CODE (DELAYED)
        DC      23X'15'                    ;AREA UNTIL 24. LINE
        DC      79X'00'                    ;LEERZEICHEN IN 24. LINE
        DC      X'40'                      ;BLANK AT THE END
PTEXTE   EQU      *                        ;END
        END

```

```

        TITLE 'USSTABX - HOB COM-USSTAB FOR HOB X-PROTOKOLL'
        PRINT NOGEN
USSTABX  USSTAB
LOGON    USSCMD  CMD=LOGON,FORMAT=PL1
         USSPARM  PARM=APPLID
         USSPARM  PARM=LOGMODE
         USSPARM  PARM=DATA
IBMTEST  USSCMD  CMD=IBMTEST,FORMAT=BAL
         USSPARM  PARM=P1,DEFAULT=10
         USSPARM  PARM=P2,DEFAULT='0123456789ABCDEF'
CODX1    USSCMD  CMD=CODX1,REP=LOGON,FORMAT=PL1
         USSPARM  PARM=APPLID,DEFAULT=CODIS
         USSPARM  PARM=LOGMODE,DEFAULT=CODLOG10
CODX2    USSCMD  CMD=CODX2,REP=LOGON,FORMAT=PL1
         USSPARM  PARM=APPLID,DEFAULT=CODIS2
         USSPARM  PARM=LOGMODE,DEFAULT=CODLOG10
CICS     USSCMD  CMD=CICS,REP=LOGON,FORMAT=PL1
         USSPARM  PARM=APPLID,DEFAULT=TESTCICS
CICS2    USSCMD  CMD=CICS2,REP=LOGON,FORMAT=PL1
         USSPARM  PARM=APPLID,DEFAULT=APCICS2
*
MESSAGES USSMSG MSG=1,TEXT='(VM1) WRONG FORMAT'
         USSMSG MSG=2,TEXT='(VM2) COMMAND % UNKNOWN'
         USSMSG MSG=3,TEXT='(VM3) PARAMETER % UNKNOWN'
         USSMSG MSG=4,TEXT='(VM4) PARAMETER % INVALID'
         USSMSG MSG=5,TEXT='(VM5) FUNCTION NOT SUPPORTED'
         USSMSG MSG=6,TEXT='(VM6) ORDER-MISTAKE'
         USSMSG MSG=7,TEXT='(VM7) BIND REJECTED'
         USSMSG MSG=8,TEXT='(VM8) VTAM MEMORY NARROW'
         USSMSG MSG=10,BUFFER=PTEXTA ;MESSAGE IF NO SESSION
END
*
PTEXTA   DC      AL2(PTEXTE-PTEXTA-2) ;LENGTH
         DC      C'--- VTAM --- HOB COM ---'
         DC      X'15' ;FEED
PTEXTE   EQU     * ;END
         END

```

Please note: you must change the ACB name (in the above example CODIS and CODIS2 for a second HOB COM), if you are going to use another ACB name in the XCTCT.

```

TITLE 'USSTABLT - HOB COM-USSTAB FOR LAPTOPS (HOB COM ASY)'
      PRINT NOGEN
USSTABLT USSTAB
IBMTEST USSCMD CMD=IBMTEST,FORMAT=BAL
      USSPARM PARM=P1,DEFAULT=10
      USSPARM PARM=P2,DEFAULT='0123456789ABCDEF'
LTC1    USSCMD CMD=LTC1,REP=LOGON,FORMAT=PL1
      USSPARM PARM=APPLID,DEFAULT=CODISC1
LTC2    USSCMD CMD=LTC2,REP=LOGON,FORMAT=PL1
      USSPARM PARM=APPLID,DEFAULT=CODISC2
MESSAGES EQU      *
      USSMSG MSG1,BUFFER=MESS01      ;WRONG FORMAT
      USSMSG MSG2,BUFFER=MESS02      ;UNKNOWN COMMAND
      USSMSG MSG3,BUFFER=MESS03      ;PARAMETER UNKNOWN
      USSMSG MSG4,BUFFER=MESS04      ;PARAMETER INVALID
      USSMSG MSG5,BUFFER=MESS05      ;FUNKTION NOT SUPPORTED
      USSMSG MSG6,BUFFER=MESS06      ;ORDER-MISTAKE
      USSMSG MSG7,BUFFER=MESS07      ;BIND REJECT FROM APL
      USSMSG MSG8,BUFFER=MESS08      ;VTAM HAS NOT ENOUGH MAIN
MEMORY
      USSMSG MSG12,BUFFER=MESS0C     ;OPERAND MISSING
      USSMSG MSG13,BUFFER=MESS0D     ;VTAM-ECHO
END
*
MESS01  EQU      *                      ;VTAM-MESSAGE 1
      DC      AL2(5)                  ;LENGTH
      DC      X'4100010141'          ;MESSAGE
MESS02  EQU      *                      ;VTAM-MESSAGE 2
      DC      AL2(5)                  ;LENGTH
      DC      X'4100010242'          ;MESSAGE
MESS03  EQU      *                      ;VTAM-MESSAGE 3
      DC      AL2(5)                  ;LENGTH
      DC      X'4100010343'          ;MESSAGE
MESS04  EQU      *                      ;VTAM-MESSAGE 4
      DC      AL2(5)                  ;LENGTH
      DC      X'4100010444'          ;MESSAGE
MESS05  EQU      *                      ;VTAM-MESSAGE 5
      DC      AL2(5)                  ;LENGTH
      DC      X'4100010545'          ;MESSAGE
MESS06  EQU      *                      ;VTAM-MESSAGE 6
      DC      AL2(5)                  ;LENGTH
      DC      X'4100010646'          ;MESSAGE
MESS07  EQU      *                      ;VTAM-MESSAGE 7
      DC      AL2(5)                  ;LENGTH
      DC      X'4100010747'          ;MESSAGE
MESS08  EQU      *                      ;VTAM-MESSAGE 8
      DC      AL2(5)                  ;LENGTH
      DC      X'4100010848'          ;MESSAGE
MESS0C  EQU      *                      ;VTAM-MESSAGE C
      DC      AL2(5)                  ;LENGTH
      DC      X'4100010C4C'          ;MESSAGE
MESS0D  EQU      *                      ;VTAM-MESSAGE D
      DC      AL2(5)                  ;LENGTH
      DC      X'4100010D4D'          ;MESSAGE
END

```

A.11. STANDARD ASSIGNMENT OF HOB COM DRIVER ROUTINES

The driver routines described in this manual are not part of all standard shipments of HOB COM, HOB-TEXT or HOB LIST. The following table shows you which driver routines are linked to the HOB products:

	HOB COM	HOB TEXT	HOB LIST
\$VM	✓	✓	✓
\$SPOOL		✓	✓
\$PUN	✓	✓	✓
\$PRINT	✓	✓	✓
\$SCREEN		✓	
\$TCT		✓	
\$DIALOG		✓	
\$APPCVPI	✓	✓	✓
\$APPCVPW	✓	✓	✓
\$VMFILEP	✓	✓	✓
\$VSAM		✓	

A.11 THE HOB COM CHARACTER SET

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0		⌈	⌊	⌈	⌊	⌈	⌊	⌈	⌊	⌈	⌊	⌈	⌊	⌈	⌊	⌈
1		⌈	⌊	⌈	⌊	⌈	⌊	⌈	⌊	⌈	⌊	⌈	⌊	⌈	⌊	⌈
2								←								
3			⌈	⌊	⌈	⌊	⌈	⌊	⌈	⌊	⌈	⌊	⌈	⌊	⌈	⌊
4			⌈	⌊	⌈	⌊	⌈	⌊	⌈	⌊	⌈	⌊	⌈	⌊	⌈	⌊
5	&		⌈	⌊	⌈	⌊	⌈	⌊	⌈	⌊	⌈	⌊	⌈	⌊	⌈	⌊
6	-	/	o	ø		u	e									
7	{	}	\	~												
8	Q	a	b	c	d	e	f	g	h	i	4	@	X	⌈	→	^
9	ù	j	k	l	m	n	o	p	q	r	•	£	¢	⌈	⌈	⌈
A	í	ß	s	t	u	v	w	x	y	z	↑	⌈	⌈	⌈	⌈	⌈
B	è	ˆ	É	é	æ	ê	â	ò	ì	û	↑	↓	⌈	⌈	⌈	⌈
C	ä	À	B	C	D	E	F	G	H	I	ç	Ñ		⌈		⌈
D	ü	J	K	L	M	N	O	P	Q	R	Ä	ñ		ä	Ö	⌈
E	Ö	È	S	T	U	V	W	X	Y	Z	Ì	Í	⌈	Ó	Ú	á
F	0	1	2	3	4	5	6	7	8	9	ì	ó	ü	ö	Á	

INDEX

\$

\$COP0100.....	95
\$DIALOG.....	113
\$NET.....	101
\$PDS.....	114
\$PRINT.....	86, 112
\$PUN.....	112
\$SCREEN.....	112
\$SPOOL.....	111
\$TCT.....	113
\$VSAM.....	113

A

ACB NAME.....	43
Anschluß des Token Ring-Terminals	39
AUTOINSTALL.....	32

C

CO.....	58
COBA.....	9
COBA MESSAGES.....	125
COM=.....	59
Connect	
Terminal.....	38
CONSOLE MESSAGES.....	116
COVTC.....	9
COVTC/COVTOP MESSAGES	127
COVTOP.....	9

D

Define	
3270 Printer.....	18
3270 Terminal	18
E - Terminal.....	19
Laptop.....	21
Logmode	19
Logmode foe Laptops.....	25
Majornode	29
NCP Entry	22
Switched Major Node	24
TCP/IP.....	27
Terminals and Printers	18
USSTAB	20
USSTABLT	25
VIRTUAL PRINTERS	35

Virtual Terminal.....	31
DISCON.....	98
Domainname	28
Driver 100	47
Driver 20	47
Drucken von HOB COM zu einem LPD	100

F

Funktionstasten	10
-----------------------	----

H

HCF	34
HOB COM-Passwort	98
HobcomUserId	80
HOBLINK 3270.....	98
hostname	28

I

IMS.....	34
Installation	12
First Installation.....	12
Loading the Tape.....	13
Properties	15
Tape Content.....	13
Installationsband	81

J

Jobname	28
---------------	----

L

LASTTE.....	98
Loading HOB COM	14
Loading the HOB COM-Programmphase.....	14
LOGM	98
Logmode.....	19, 81
LTKEY	67
LUTYPE.....	98

M

MVS CONSOLE MESSAGES	118
----------------------------	-----

N

NCP Entry	22
NOTE	9
NOTE MESSAGES	129

O

OPEN	27
OUTFILE	101
Overview	8
Books	9
Programs	9
Styles	10

P

PersNo	80
Personeneintrag in der HOB COM-TCT	79
Port	27
PR3287	9
PR3287 MESSAGES	131
PR3770	9
Print	
A LOCAL HARDCOPY	88
DFT terminal	83
FROM CICS ON E-TERMINAL PRINTER	84
FROM JES ON E TERMINAL PRINTER	86
HARDCOPY ON E-TERMINAL PRINTER	88
OVER TCP/IP	89
PRINT	83, 98
Print Client	28
Program Property Table	15
Properties	15

R

RDO	32
RJE station	9
ROSCOE	34

S

S-Drucker	95
Start HOB COM	16
Storage Requirements	12
Switched Major Node	24
SYSTEM	59

T

TASKSTA	59
TCP/IP	27, 90

TCT	27, 42
Structure	42
TERM	98
terminalname	58
TERMSTA	59
The Driver 100	98
TN3270-Drucker-Session	95
TSO	33
TYPE	98

U

USSTAB for SNA	20
USSTAB für Laptop	25
USSTABHS	81
USSTABLT	25

V

VCTCT	100
VM-HOB COM	95
VTAM	9

X

XCCOMASK	71
XCJCLTAB	64
XCPASSW	78
XCPERSTA	62
XCPRPAR	52
XCPRTAB	46
XCTCPIP2 MESSAGES	103, 139
XCTEGRO (Group Entries for Terminals)	48
XCTERMA	43
XCTPRI	95, 97
XCUPNAM	68
XCUSBTA	58
XCUSSCOM	51
XCUSOUT	50
XTCTGEN	100

Y

Y-PROTOCOL	79
------------------	----

